


CUBISCAN™ 200 SQ

Operation and service manual



Quantronix, Inc.
Cubing and Weighing Systems

314 South 200 West
Farmington, Utah 84025
U. S. A.

Phone: 801.451.7000

Website: <http://www.cubiscan.com>



CUBISCAN®

Cubiscan™ CUBISCAN 200 SQ operations and technical manual

Cubiscan® and the Quantronix logo are registered trademarks of Quantronix, Inc.

Scanning New Dimensions™, Qbit™, QbitWIN™, and The FWSYSTEM™ are trademarks of Quantronix, Inc.

Windows® is a registered trademark of Microsoft Corporation.

Cubiscan® software and firmware are protected by international and domestic copyrights.

Cubiscan® 150 measurement products are protected by one or more of U.S. Patents Re42,430 and D490,328 and foreign patents.

Cubiscan® 110 measurement products are protected by one or more of U.S. Patent Re42,430 and foreign patents.

Cubiscan® 125 measurement products are the subject of U.S. Patent 8,928,896. Another U.S. patent is pending.

Cubiscan® 225 measurement products are protected by one or more U.S. patents, refer to U.S. Patent 9435637.

This document and website Copyright © 2018 by Quantronix, Inc. All rights reserved.

LMI Technologies Proprietary

This document, submitted in confidence, contains proprietary information which shall not be reproduced or transferred to other documents or disclosed to others or used for manufacturing or any other purpose without prior written permission of LMI Technologies Inc.

No part of this publication may be copied, photocopied, reproduced, transmitted, transcribed, or reduced to any electronic medium or machine readable form without prior written consent of LMI Technologies, Inc.

Limited warranty Quantronix new product

Statement of Warranty. Quantronix, Inc.'s, warranty obligations are limited to the terms set forth below: Quantronix (hereinafter referred to as the "Seller") warrants that its new product is in accordance with Seller's published specifications (or those agreed upon with Buyer in writing) at the time of sale or lease and that it is free from non-cosmetic defects in materials and workmanship under normal use for a period of one (1) year from the date of sale or the commencement date under a written equipment lease or rental agreement (the "Warranty Period"). If a hardware defect arises and a valid claim is received within the Warranty Period, at its option, Seller will either (i) repair the hardware defect at no charge, using new or refurbished replacement parts, or (ii) exchange the product or defective part(s) with a product or part(s) that are new or which has been manufactured from new or serviceable used parts and is

at least functionally equivalent to the original product or part, or (iii) refund the purchase price of the product after Buyer has returned the product to Seller. For purposes of this warranty agreement, "Buyer" shall mean and refer to (i) the party which originally – whether from Seller directly, or from an authorized distributor, agent or reseller who is authorized by Seller – purchases, or leases under a written equipment lease or rental agreement, the Seller's product which is the subject of this warranty, or (ii) any subsequent purchaser or transferee that acquires valid title to the equipment within the Warranty Period.

In the event of the occurrence of a claim under this warranty, the Buyer shall have thirty (30) days to notify Seller in writing of the nature and specifics of the claimed defect; provided, however, that any and all claims must be received before the expiration of the Warranty Period. Failure to notify Seller within such time period shall void this warranty. Any claim of a warrantied defect is subject to inspection and analysis by Seller, prior to and/or after Buyer ships the product to Seller, to conclusively identify or confirm the nature and cause of failure and application of this warranty. In the event that the defect or damage is excluded from warranty the Seller may at its option either (i) provide Buyer with a quote to make any such repairs or replacements which are not covered under this warranty, or (ii) give Buyer twenty (20) days to pay for return shipping and upon receipt return the product to Buyer. If Buyer fails to pay for return shipping after twenty (20) days' notice and after repairs are made or warranty coverage is determined not applicable, Seller may dispose of or scrap the product.

This is a factory warranty and any defective components, mechanical or electrical, will be repaired or replaced, at the discretion and authorization of Seller, at Seller's facilities in Utah. It shall be the Buyer's responsibility to return the faulty equipment or components to Seller at Buyer's expense as well as pay for all return shipping. All replaced or exchanged parts becomes property of Seller. Buyer shall first receive written confirmation to ship the product before sending it. Written confirmation to ship is not a guarantee that the defect or damage to the product is covered by this warranty. Seller is not obligated to pay for labor, material, or service charges involved in the removal, return, or installation of equipment or components. Seller reserves the right to incorporate improvements in material and design of its products without notice and is not obligated to incorporate the same improvements in equipment previously manufactured.

Exclusions and Limitations. This limited one (1) year warranty is applicable exclusively to original equipment products and components that were manufactured by Seller. Seller also warrants its replacement parts, subject to the terms and conditions set forth herein, for the lesser period of ninety (90) days from the date of delivery or until the expiration of the original warranty, whichever is greater. Seller does not warrant, for any purpose, any external accessories, or integrated parts, including but not limited to computers, controllers and/or barcode scanners, that are manufactured by another manufacturer and sold under a separate label, even if they are packaged or sold with Seller's product. Seller's obligation and liability under this warranty is expressly limited to repair or replacement (at its option) of the warrantied equipment or components within the Warranty Period. A purchase by Buyer of equipment that it had first leased or rented shall not start a new Warranty Period. Seller does not warrant that the operation of the product will be uninterrupted or error-free.

This warranty shall not apply to equipment or components which has/have:

1. Been the subject of an accident, or repairs or modifications attempted or made and not authorized by Seller.
2. Been used with incompatible products.
3. Been operated under abnormal conditions, excessive heat or cold, highly corrosive environments, or in an unintended manner.
4. Not been operated or maintained in accordance with Seller's instructions.
5. Been subject to misuse or abuse, negligent handling, improper installation, accident, damage by fire, flood, snow, ice, water or other liquid damage, lightning, abnormal electrical condition and/or power surge, earthquake, or other act of God or events outside of Seller's control.
6. Had serial numbers altered, defaced or removed.
7. Been operated beyond capacity.
8. Not been manufactured by Seller including parts, accessories, or components which have been integrated into, used alongside of, or in conjunction with a product manufactured by Seller.

TO THE EXTENT PERMITTED BY LAW, THIS WARRANTY AND THE REMEDIES SET FORTH ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, REMEDIES AND CONDITIONS, WHETHER ORAL OR WRITTEN, STATUTORY, EXPRESS OR IMPLIED. TO THE MAXIMUM EXTENT ALLOWED BY LAW, SELLER SPECIFICALLY DISCLAIMS ANY AND ALL STATUTORY OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND WARRANTIES AGAINST HIDDEN OR LATENT DEFECTS. IF SELLER CANNOT LAWFULLY DISCLAIM STATUTORY OR IMPLIED WARRANTIES THEN TO THE EXTENT PERMITTED BY LAW, ALL SUCH WARRANTIES SHALL BE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS WARRANTY AND TO REPAIR OR REPLACEMENT SERVICE AS DETERMINED BY SELLER IN ITS SOLE DISCRETION. This statement sets forth the full extent of Seller's liability for breach of any warranty or deficiency in connection with the sale or use of the product. No employee, representative or reseller of Seller is authorized to change this warranty in any way or grant any other warranty.

EXCEPT AS PROVIDED IN THIS WARRANTY AND TO THE EXTENT PERMITTED BY LAW, SELLER IS NOT RESPONSIBLE FOR DIRECT, INDIRECT, SPECIAL, PUNITIVE, INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY OR CONDITION, OR UNDER ANY OTHER LEGAL THEORY, INCLUDING BUT NOT LIMITED TO LOSS OF USE; LOSS OF REVENUE; LOSS OF ACTUAL OR ANTICIPATED PROFITS (INCLUDING LOSS OF PROFITS ON CONTRACTS); LOSS OF THE USE OF MONEY; LOSS OF ANTICIPATED SAVINGS; LOSS OF BUSINESS; LOSS OF OPPORTUNITY; LOSS OF GOODWILL; LOSS OF REPUTATION; LOSS OF, DAMAGE TO OR CORRUPTION OF DATA; OR ANY INDIRECT OR CONSEQUENTIAL LOSS OR DAMAGE HOWSOEVER CAUSED INCLUDING THE REPLACEMENT OF EQUIPMENT AND PROPERTY, AND ANY COSTS OF RECOVERING,

PROGRAMMING, OR REPRODUCING ANY PROGRAM OR DATA STORED OR USED WITH SELLER PRODUCTS. BUYER WAIVES THE RIGHT TO SEEK TOTAL COMBINED DAMAGES FROM SELLER IN EXCESS TO THAT WHICH WAS PAID TO SELLER AND SELLER SHALL BE LIMITED FROM ANY AND ALL CLAIMS RELATED TO THIS WARRANTY TO BE NO MORE THAN WHAT WAS PAID TO SELLER FOR THE NEW PRODUCT.

CONSUMER PROTECTION LAWS. FOR CONSUMERS WHO ARE COVERED BY CONSUMER PROTECTION LAWS OR REGULATIONS IN THEIR COUNTRY OF PURCHASE OR, IF DIFFERENT, THEIR COUNTRY OF RESIDENCE, THE BENEFITS CONFERRED BY THIS WARRANTY ARE IN ADDITION TO ALL RIGHTS AND REMEDIES CONVEYED BY SUCH CONSUMER PROTECTION LAWS AND REGULATIONS. Some countries, states and provinces do not allow the exclusion or limitation of incidental or consequential damages or exclusions or limitations on the duration of implied warranties or conditions, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary by country, state or province.

This document was created with the purpose of providing the most accurate and complete information. If you have comments or suggestions for improving this manual, contact Quantronix at manual@cubiscan.com.

Manual updated September 19, 2022.

Important safety information



Important safety information includes important matters necessary for safe use of products and ensuring safety. Most accidents involving machine operation and maintenance are caused by failure to observe basic safety rules or precautions. An accident can often be prevented by recognizing potential hazards.

Follow all the safety precautions when checking, starting, operating, stopping, or performing any maintenance on the 200 SQ. The basic safety precautions given in this manual and the warning labels placed on the machine are:

DANGER Indicates a hazardous situation which, if not avoided, will result in death or serious injury.

WARNING Indicates a hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

The items that you need to know before using the product are explained on the next page. Be sure to read them before operation.

Danger

DANGER AREA Do not put hands and /or any part of your body on the conveyor.

**CONVEYOR
START UP** Make sure of the following conditions are met before starting the conveyor:

- No object is on the conveyor.
- Nobody is working near the conveyor.

**POWER
SOURCE** Use the machine with the prescribed power source and voltage indicated on the nameplate. Non-compliance could result in fire, accidental electrocution, and/or machine damage.

REPAIR **DO NOT** repair, convert, and/or dismantle the machine and parts except in the manner described in this manual. Non-compliance could result in fire, accidental electrocution, and/or machine damage.

Warning

PLUGGING AND UNPLUGGING

Do not handle the 200 SQ plug when connected to a live power supply with wet hands. Hold the plug, **NOT** the power cable, when unplugging. Failure to observe this may cause accidental electrocution and damage to plug.

POWER SUPPLY CABLE

Handle the power supply cable with care. **DO NOT** step or put any heavy objects on it. **DO NOT** place the cable near heated objects. **DO NOT** modify, bend, or pull the cable. In case of cable damage or tear, immediately turn off the 200 SQ and unplug from power source if doing so does not pose a risk to you.

INSTALLATION

The 200 SQ should not be installed in any environment where excessive heat, humidity, or dust is present.

FUSE REPLACEMENT

Replace the fuse only when specified in this manual, and be sure to disconnect the power plug from the outlet before replacing to avoid electric shock. When replacing, be sure to use the rated fuse attached to the product.

EARTH WIRES

Check if earth wires are properly set up. Failure to do so could result in fire, accidental electrocution, and/or machine damage. If the earth wires are not properly set, or you are unsure, contact your DIGI dealer.

ABNORMAL OPERATION

Turn off power to the 200 SQ and unplug it immediately if the machine experiences shock, emits foul smell, makes odd sound, overheats, or emits smoke. Call your DIGI service engineer to inspect machine before returning to operation. Failure to do so could result in fire, accidental electrocution, and/or machine damage.

Caution 1

1. Inspections are required twice a year to maintain product performance and prevent breakdowns.
2. Do not use the 200 SQ near electronic devices that handle high-precision control or weak signals as it may affect electronic devices leading to malfunction.
3. Do not install the 200 SQ in a location that is unstable or inclined as this may cause it fall, leading to injury or malfunction. Install it in a flat and stable location, where it can easily be leveled.

4. Do not install or store in a place with high temperature or humidity, or in a place with a lot of dust. Doing so may cause a malfunction, electric shock, or fire.
5. Do not allow foreign matter or liquids to get inside the 200 SQ. Doing so may cause short circuit or smoke, resulting in fire, electric shock, or malfunction. If foreign matter or liquid gets inside the 200 SQ, immediately turn off the machine and unplug it from the outlet.
6. If the 200 SQ is dropped or suffers a strong impact, immediately turn it off and unplug it from the outlet. Continued use may cause fire, electric shock, injury, or malfunction.
7. If you do not use the product for a long time, disconnect the power plug from the outlet to ensure safety. Allowing it to remain plugged in over a long period of time without use, may cause fire or electric shock.
8. Do not operate the touch panel with sharp objects. Pressing the touch panel strongly with a sharp object may cause damage, leading to malfunction.
9. Do not install the 200 SQ in direct sunlight.
10. Do not climb onto or lean on the 200 SQ. Doing so may cause injury.

Caution 2

1. The Cubiscan 200 SQ is made for use in Japan only. Do not use it outside of Japan.
2. The 200 SQ may have unique specifications designed for particular users. Please note that the handling of specially designed products may differ from what is described in this manual.
3. Use the optional equipment, connection parts, consumables, etc. specified by Teraoka Seiko for connecting to the 200 SQ. If the customer uses optional equipment, connection parts, or consumables that are not specified, Teraoka Seiko Co., Ltd., the seller will not be held responsible for any resulting failures and the warranty will be considered void even if it is within the warranty period of the product. All non-designated consumables, parts, etc. will be outside the scope of the maintenance contract.
4. The dimensions and specifications of this product are subject to change without notice. Please note that due to changes in the 200 SQ, optional equipment and parts may differ from the dimensions, specifications, and operations, etc.

5. Reproduction of all or part of the contents of this manual without permission is strictly prohibited.
6. The contents of this manual are subject to changes without notice.
7. The contents of this manual have been prepared with the utmost care attention to the needs of the customer. If questions arise that fall outside the scope of this manual or if mistakes, omissions, etc., are found, please contact the sales office in charge.
8. Please note that we are not responsible for the impact of the operation results regardless of items 3, 4, and 6.
9. For assured accuracy, the internal clock should be set once a month.
10. For products that can manage product data, sales data, customer information, etc., this data may be recorded in the FD, CD-R, USB memory, memory card, etc. connected to the 200 SQ. Please be careful when handling these memory devices to prevent loss of data.

Precautions for use and maintenance

This device weights and dimensions objects along a conveyor. Regular cleaning and calibration tests are required to maintain accurate measurements. Run calibration test after any maintenance work.

Pre-start inspection items by the customer:

As a pre-start inspection, clean the passage sensor and gate sensor while conveyor is stopped. Before operating the 200 SQ, conduct calibration tests in test mode to ensure accuracy of measurements.

Required confirmation issues after maintenance work:

- After turning on the power, check that each sensor responds normally in maintenance mode.
- Check the date / time.
- Check the weight and three-sided measurement value in the test mode.

TABLE OF CONTENTS

Important safety information

Danger	i
Warning	ii
Caution 1	ii
Caution 2	iii
Precautions for use and maintenance	iv

CHAPTER 1 DESCRIPTION 1

Basic performance	1
Precautions for use	1
Specifications	2
Basic Specifications	2
Display specifications	4
Power supply specifications	4
Dimensions	5
Part description	8
Conveyor main unit	8
Display	9
Safety sticker position	10
Switches description	11
Main switch (main breaker)	11
Emergency stop switch	12
Manual switch	12
Indicator specifications	14
Indicator overview	14
Operation table	14
Communication Specifications	15
FTP communication	15
Socket communication	16
Serial communication (RS-232C/RS-422)	18
Status in communication format	20
Communication timing (socket/serial)	24
DIO External input/output signal (optional)	26
Input connection diagram	27

CHAPTER 2 SETUP 31

Getting started	31
Tools for setup	31
Checklist for setup	31
200 SQ installation	32
Removal of shipping stopper	34
Console and scanner installation	38
Fixed scanner installation (optional)	43
Powering on	46
Sensor cover assembly	48
Date and Time setting	49
Conveyor setting	53
Scanner setting (optional)	54
TCP/IP setting (optional)	57
Weight setting	60
Scales setting	62
Setting data backup	65
Measurement confirmation	71

CHAPTER 3 MAINTENANCE MODE 74

Measurement screen	74
Status display icon details (status)	76
Select language details	77
Result details	77
Maintenance settings	78
Maintenance mode	79
Maintenance mode details	79
Exiting maintenance mode	83
Maintenance mode item details	88
Available selections for System info	88
Available selections for Log	94
Equipment test (available to admin/engineer)	98
Device setting (available to admin/engineer)	107
Adjustment	117

CHAPTER 4 DISASSEMBLING 128

Display	128
Removing display from main unit	128

Relay board	130
Removing the touchscreen	130
Removing indicator board	131
Mother board	132
Replacing LCD	134
Control box	139
Preparation before replacement	139
Mother board	141
Transport board	143
A/D Box	146
Preparation before replacement	146
Accessing A/D BOX	148
A/D board replacement	153
A/D control board	155
Gate sensor board	156
Bottom gate (receiver)	156
Gate side (receiving)	163
Gate side (emitting)	165
Upper gate (emitting)	168
Passage sensor board	170
Conveyor A emitter	170
Conveyor B emitter	173
Conveyor A receiver	177
Conveyor B receiver	181
Inverter	187
Drive belt	192
Conveyor A drive belt	192
Conveyor B drive belt	197
Main motor	203
Conveyor A main motor	203
Conveyor B main motor	205
Roller/ transport belt	208
Conveyor A driven roller	208
Conveyor A drive roller	212
Conveyor A transport belt	215
Conveyor B driven roller	218
Conveyor B drive roller	222
Conveyor B transport belt	225

CHAPTER 5 BOARDS & PARTS 227

Block diagram	227
Display	227
Inverter	228
Power supply	229
Main unit	230
Boards	230
Main board: TPB-3850	231
Transport board: TPB-3851	232
A/D board: TPB-3273	233
A/D control board: TPB-3852	233
Relay board: TPB-3853	234
Power distribution board: TPB-3854	234
Gate sensor (emitter) board: TPB-3282	235
Gate sensor (receiver) board: TPB-3283	236
Passage sensor (emitter) board: TPB-3863	236
Passage sensor (receiver) board: TPB-3864	237
Passage sensor (emitter) board: TPB-3865	237
Passage sensor (receiver) board: TPB-3866	237
Stack-lite board: TPB-3926	238
Switch/LED board: TPB-3948	238
Power board: SWF150P-24	240
Touch panel relay board: TSC-54/RU-F	240
SSD: AXM21ES3-64GM-B	241
Memory: PC3-12800 4GB	241
Motherboard: EMX-BYT2-A1-01R	242
Wire & Connectors	242
CNW-15445-00	243
CNW-15447-01	244
CNW-15448-01	245
CNW-15449-01	246
CNW-15450-01	247
CNW-15451-00	248
CNW-15452-01	249
CNW-15453-00	250
CNW-15454-01	251
CNW-15455-01	252
CNW-15456-00	253
CNW-15457-01	254
CNW-15458-01	255

CNW-15460-01	256
CNW-15461-00	257
CNW-15462-00	258
CNW-15463-00	259
CNW-15464-01	260
CNW-15465-01	261
CNW-15466-01	262
CNW-15467-01	263
CNW-15468-01	264
CNW-15469-00	265
CNW-15470-00	266
CNW-15471-00	267
CNW-15472-00	268
CNW-15473-00	269
CNW-15474-00	270
CNW-15475-01	271
CNW-15478-00	272
CNW-15480-00	273
CNW-15481-00	274
CNW-15482-00	275
CNW-15483-00	276
CNW-15484-01	277
CNW-15485-01	278
CNW-15486-00	279
CNW-15487-00	280
CNW-15488-00	281
CNW-15489-00	282
CNW-15490-00	283
CNW-15491-00	284
CNW-15492-00	285
CNW-15493-00	286
CNW-15494-00	287
CNW-15495-00	288
CNW-15496-01	289
CNW-15497-01	291
CNW-15498-01	293
CNW-15499-01	294
CNW-15500-01	296
CNW-15501-01	298
CNW-15502-01	299

CNW-15503-01	300
CNW-15505-00	301
CNW-15508-00	302
Recommended parts	302
Parts list	302

CHAPTER 6 LOG, FIRMWARE, DATA 305

Log acquisition	305
Common operation	305
Log acquisition operation	309
Device setting data	312
Common operation	312
Device setting data backup procedure	316
Adjustment setting data backup procedure	318
Device setting data restore procedure	320
Adjustment setting data restore procedure	325
Application installation	329
Firmware installation	332

CHAPTER 7 ADJUSTMENT 339

Forced startup method	339
Weight adjustment	340
2-Point span adjustment procedure	340
3-Point span adjustment procedure	346
Conveyor height/horizontal adjustment	352
Adjustment leg position	352
Leg height adjustment procedure	353
Horizontal confirmation adjustment method	354
Transport surface height adjustment	355
Conveyor belt slipping adjustment	357
Adjuster position for belt adjustment	357
Reference position	358
Belt slipping adjustment method	360

LIST OF FIGURES

Figure 1	Display specification: Range of motion	4
Figure 2	Power supply specification: Plug shape	5
Figure 3	Dimensions: Top view of the main body	5
Figure 4	Dimensions: View of display	6
Figure 5	Dimensions: Front view of the main body	6
Figure 6	Dimensions: Side view of the main body	7
Figure 7	Part description: Conveyor main unit	8
Figure 8	Part description: Display unit	9
Figure 9	Safety sticker position: Safety stickers	10
Figure 10	Switches description: Main switch cover	11
Figure 11	Switches description: Emergency stop switch	12
Figure 12	Switches description: Manual switch cover	13
Figure 13	Switches description: Manual switch	13
Figure 14	Indicator specifications: Indicator overview	14
Figure 15	Serial Communication: Connector details	18
Figure 16	Serial Communication: Connecting RS-422 interface	19
Figure 17	Rear package data output	24
Figure 18	Communication specifications: Front package data output	25
Figure 19	Communication specifications: PLC box cover closed	26
Figure 20	Communication specifications: Opening PLC box cover	27
Figure 21	Communication specifications: Terminal block connection diagram (input)	27
Figure 22	Communication specifications: Circuit diagram (input)	28
Figure 23	Communication specifications: Terminal block connection diagram (output)	29
Figure 24	Communication specifications: Circuit diagram (output)	29
Figure 25	Unloading and installation: Designated fork holes	33
Figure 26	Unloading and installation: How to lock casters	33
Figure 27	Removal of shipping stoppers: Shipping stoppers diagram (front)	34
Figure 28	Removal of shipping stoppers: Shipping stopper (back)	34
Figure 29	Removal of shipping stoppers: Shipping stopper (Conveyor A)	35
Figure 30	Removal of shipping stoppers: Shipping stopper (Conveyor B)	35

Figure 31	Removal of shipping stoppers: Removing plates G and H	36
Figure 32	Removal of shipping stoppers: Remove plates A, B, I, J	36
Figure 33	Removal of shipping stoppers: Remove plates C, D, E, and F	37
Figure 34	Removal of shipping stoppers: UPS shipping stopper removal	37
Figure 35	Removal of shipping stoppers: Removing zip ties and airpack	38
Figure 36	Console and scanner installation: Stand pole	38
Figure 37	Console and scanner installation: Securing display bracket	39
Figure 38	Console and scanner installation: Display bracket diagram (rear view)	39
Figure 39	Console and scanner installation: Connecting USB cable	40
Figure 40	Console and scanner installation: Installing console pole	40
Figure 41	Console and scanner installation: Secure console pole	41
Figure 42	Console and scanner installation: Hand scanner cradle	41
Figure 43	Console and scanner installation: Final console installation	42
Figure 44	Console and scanner installation: Console cables	42
Figure 45	Fixed scanner installation: 3 cap screws	43
Figure 46	Fixed scanner installation: Docking fixture	43
Figure 47	Fixed scanner installation: Cap screw holes	44
Figure 48	Fixed scanner installation: Securing fixed scanner	44
Figure 49	Fixed scanner installation: Removing connector caps	45
Figure 50	Fixed scanner installation: Connecting [POWER] and [IO] cables	45
Figure 51	Powering on: Plugging in	46
Figure 52	Powering on: Main switch cover	46
Figure 53	Powering on: Main switch	47
Figure 54	Sensor cover assembly: Locations for sensor covers	48
Figure 55	Sensor cover assembly: Securing sensor covers	48
Figure 56	Date and Time setting: Settings	49
Figure 57	Date and Time setting: Maintenance	49
Figure 58	Date and Time setting: Login screen	50
Figure 59	Date and Time setting: Entering passcode	50
Figure 60	Date and Time setting: Returning to login	51
Figure 61	Date and Time setting: Device setting	51
Figure 62	Date and Time setting: Clock settings	52
Figure 63	Date and Time setting: Setting date	52
Figure 64	Date and Time setting: Setting clock time	53

Figure 65	Conveyor setting: Conveyor screen	53
Figure 66	Conveyor setting: Settings	54
Figure 67	Scanner setting: Scanner option	54
Figure 68	Scanner setting: Fixed menu	55
Figure 69	Scanner setting: Enable hand scanner	55
Figure 70	Scanner setting: Barcode menu	56
Figure 71	Scanner setting: Combination menu	56
Figure 72	TCP/IP setting: TCP/IP menu	57
Figure 73	TCP/IP setting: Settings	57
Figure 74	TCP/IP setting: FTP menu	58
Figure 75	TCP/IP setting: FTP settings	59
Figure 76	Weight setting: Weight menu	60
Figure 77	Weight setting: Settings	60
Figure 78	Weight setting: Length menu	61
Figure 79	Weight setting: Length settings	61
Figure 80	Scale settings: Scales menu	62
Figure 81	Scale settings: Zeroing scale	62
Figure 82	Scale settings: Conveyor calibration points	63
Figure 83	Scale settings - logout screen	64
Figure 84	Scale settings - update screen	64
Figure 85	Setting data backup - USB ports	65
Figure 86	Setting data backup - Setting	66
Figure 87	Setting data backup - Maintenance	66
Figure 88	Setting data backup - Entering passcode	67
Figure 89	Setting data backup - Recovery menu	67
Figure 90	Setting data backup - Recovery setting history	68
Figure 91	Setting data backup - Select drive	68
Figure 92	Setting data backup - Confirmation popup	69
Figure 93	Setting data backup - Adjustment recovery	69
Figure 94	Setting data backup - Adjustment setting history	70
Figure 95	Setting data backup - Select drive	70
Figure 96	Setting data backup - Confirmation popup	71
Figure 97	Measurement confirmation - Start	71
Figure 98	Measurement confirmation - Conveyor warning message	72

Figure 99	Measurement confirmation - Ready for measurement	72
Figure 100	Measurement screen - Details	74
Figure 101	Measurement screen - Language selection	77
Figure 102	Measurement screen - Results page details	77
Figure 103	Measurement screen - Measurement screen details	78
Figure 104	Maintenance mode details - measurement screen	79
Figure 105	Maintenance mode details - Settings screen	80
Figure 106	Maintenance mode details - Administrator login	80
Figure 107	Maintenance mode details - Maintenance screen	81
Figure 108	Maintenance mode details - Service engineer login	81
Figure 109	Maintenance mode details - Password key window	82
Figure 110	Maintenance mode details - Passcode entered	82
Figure 111	Maintenance mode details - Service engineer maintenance	83
Figure 112	Exiting maintenance mode - User login	84
Figure 113	Exiting maintenance mode - Measurement screen	84
Figure 114	Exiting maintenance mode - Administrator login	85
Figure 115	Exiting maintenance mode - Finish setting	85
Figure 116	Exiting maintenance mode - Service engineer login	86
Figure 117	Exiting maintenance mode - Logout	86
Figure 118	Exiting maintenance mode - Logout checked	87
Figure 119	Exiting maintenance mode - Update register	87
Figure 120	Exiting maintenance mode - Destroy register	88
Figure 121	System info selections- Version	89
Figure 122	System info selections - Digital DIO	90
Figure 123	System info selections - Condition	91
Figure 124	System info selections- Gate Sensor	91
Figure 125	System info selections - Photo sensor	92
Figure 126	System info selections - Scale	93
Figure 127	System info selections - Inverter	93
Figure 128	Log selections - Measurement	94
Figure 129	Log selections - Mileage	95
Figure 130	Log selections - Error recordings	96
Figure 131	Log selections - Control services	96
Figure 132	Log selections - Display app.	97

Figure 133	Log selections - Maintenance log	98
Figure 134	Device testing selections - Sensor list	99
Figure 135	Device testing selections - Scales	100
Figure 136	Device testing selections - Gate sensor	101
Figure 137	Device testing selections - Photo sensor	102
Figure 138	Device testing selections - Motor encoder	103
Figure 139	Device testing selections - Signal light	104
Figure 140	Device testing selections - Corners conf.	105
Figure 141	Device testing selections - List of measurements	106
Figure 142	Device testing selections - Scanner	106
Figure 143	Device setting selections - Display	107
Figure 144	Device setting selections - Sound	108
Figure 145	Device setting selections - Conveyor	109
Figure 146	Device setting selections - Measuring	110
Figure 147	Device setting selections - Scanner	112
Figure 148	Device setting selections - Serial port	113
Figure 149	Device setting selections - Clock	114
Figure 150	Device setting selections - FTP	115
Figure 151	Device setting selections - TCP/IP	116
Figure 152	Device setting selections - Recovery	117
Figure 153	Adjustment selections - Span	118
Figure 154	Adjustment selections - Weight	119
Figure 155	Adjustment selections - Length	121
Figure 156	Adjustment selections - Conveyor	123
Figure 157	Adjustment selections - Weight correction	124
Figure 158	Adjustment selections - Device	125
Figure 159	Adjustment selections - Device	126
Figure 160	Adjustment selections - Firmware	127
Figure 161	Removing display - Connector screws	128
Figure 162	Removing display - Back of display	129
Figure 163	Removing display - Display internals	129
Figure 164	Removing display - Relay board	130
Figure 165	Removing display - Touchscreen removal	131
Figure 166	Removing display - Indicator board	132

Figure 167	Removing display - Mother board	133
Figure 168	Removing display - Motherboard connectors	133
Figure 169	Removing display - Removing memory	134
Figure 170	Removing display - Removing SSD	134
Figure 171	Removing display - Mother board removal	135
Figure 172	Removing display - Removing motherboard from LCD	136
Figure 173	Removing display - Removing LCD and frame	137
Figure 174	Removing display - Separating LCD from frame	137
Figure 175	Removing display - LCD removed from sheet metal	138
Figure 176	Control box - Main breaker	139
Figure 177	Control box - Main breaker	139
Figure 178	Control box - Removing side panel	140
Figure 179	Control box - Removing side panel	140
Figure 180	Control box - Board switches	141
Figure 181	Control box - Removing control box cover	142
Figure 182	Control box - Motherboard	142
Figure 183	Control box - Removing motherboard	143
Figure 184	Control box - Removing control box cover	144
Figure 185	Control box - Transport board	144
Figure 186	Control box - Removing transport board	145
Figure 187	A/D BOX - Main breaker cover	146
Figure 188	A/D BOX - Main breaker	146
Figure 189	A/D BOX - Removing side panel	147
Figure 190	A/D BOX - Board switches	147
Figure 191	A/D BOX - Right side cover	148
Figure 192	A/D BOX - Right side hexagonal screws	149
Figure 193	A/D BOX - Left side cover	149
Figure 194	A/D BOX- Left side hexagonal screws	150
Figure 195	A/D BOX - Removing A/D BOX	150
Figure 196	A/D BOX - UL clamps	151
Figure 197	A/D BOX - Side screws	151
Figure 198	A/D BOX - Removing box	152
Figure 199	A/D BOX - Cover	152
Figure 200	A/D BOX - A/D box cover removed	153

Figure 201	A/D BOX - A/D Board	154
Figure 202	A/D BOX - Removing A/D board	154
Figure 203	A/D BOX - Control board	155
Figure 204	A/D BOX - Removing control board	156
Figure 205	Gate sensor board - Accessing boards (bottom gate)	157
Figure 206	Gate sensor board - Removing covers (bottom gate)	158
Figure 207	Gate sensor board - Cap screws (bottom gate)	159
Figure 208	Gate sensor board - Gate connector (bottom gate)	160
Figure 209	Gate sensor board - Removing gate (bottom gate)	160
Figure 210	Gate sensor board - Removing gate (bottom gate)	161
Figure 211	Gate sensor board - Gate blinker (bottom gate)	161
Figure 212	Gate sensor board - Column head screws (bottom gate)	161
Figure 213	Gate sensor board - Board connectors (bottom gate)	162
Figure 214	Gate sensor board - Dip SW2	162
Figure 215	Gate sensor board - Side cover (receiving)	163
Figure 216	Gate sensor board - Sensor boards (receiving)	164
Figure 217	Gate sensor board - Board removal (receiving)	165
Figure 218	Gate sensor board - Dip SW2 (receiving)	165
Figure 219	Gate sensor board - Side cover (emitting)	166
Figure 220	Gate sensor board - Sensor boards (emitting)	166
Figure 221	Gate sensor board - Board removal (emitting)	167
Figure 222	Gate sensor board - Dip SW2 (emitting)	167
Figure 223	Gate sensor board - Cover screws (upper gate)	168
Figure 224	Gate sensor board - Connectors (upper gate)	169
Figure 225	Gate sensor board - Dip SW2 (upper gate)	169
Figure 226	Conveyor A emitter - Cover screws	170
Figure 227	Conveyor A emitter - Exposed boards	171
Figure 228	Conveyor A emitter - Accessing boards	171
Figure 229	Conveyor A emitter - TPB-3863 (small) board	172
Figure 230	Conveyor A emitter - TPB-3865 (large) board	172
Figure 231	Conveyor A emitter - SW1	173
Figure 232	Conveyor B emitter - Cover screws	174
Figure 233	Conveyor B emitter - Exposed boards	174
Figure 234	Conveyor B emitter - Accessing boards	175

Figure 235	Conveyor B emitter - TPB-3863 (small) board	175
Figure 236	Conveyor B emitter - Left TPB-3865 (large) board	176
Figure 237	Conveyor B emitter - SW1 (SENS - 6, 7)	176
Figure 238	Conveyor B emitter - Right TPB-3865 (large) board	177
Figure 239	Conveyor B emitter - SW1 (SENS-2, 3, 4, 5)	177
Figure 240	Conveyor A receiver - Cover screws	178
Figure 241	Conveyor A receiver - Hexagonal cap screws	178
Figure 242	Conveyor A receiver - Exposed boards	179
Figure 243	Conveyor A receiver - Accessing boards	179
Figure 244	Conveyor A receiver - TPB-3864 (small) board	180
Figure 245	Conveyor A receiver - TPB-3866 (large) board	180
Figure 246	Conveyor A receiver - SW5 (SENS-2, 3, 4, 5)	181
Figure 247	Conveyor B receiver - Cover screws	182
Figure 248	Conveyor B receiver - Hexagonal cap screws	182
Figure 249	Conveyor B receiver - Exposed boards	183
Figure 250	Conveyor B receiver - Accessing boards	183
Figure 251	Conveyor B receiver - TPB-3864 (small) board	184
Figure 252	Conveyor B emitter - Right TPB-3866 (large) board	184
Figure 253	Conveyor B receiver - SW5 (SNS - 6, 7)	185
Figure 254	Conveyor B emitter - Left TPB-3866 (large) board	185
Figure 255	Conveyor B emitter - SW5 (SENS-2, 3, 4, 5)	186
Figure 256	Inverter - Cover screws	187
Figure 257	Inverter - Cover removed	188
Figure 258	Inverter - Removing inverter	188
Figure 259	Inverter - Cable	189
Figure 260	Inverter - Terminals	189
Figure 261	Inverter - Revealing bottom terminals	190
Figure 262	Inverter - Sheet metal screws	190
Figure 263	Inverter - Connections revealed	191
Figure 264	Inverter - Removing frame	191
Figure 265	Conveyor A drive belt - Cover screws	192
Figure 266	Conveyor A drive belt - Motor pulley cover	193
Figure 267	Conveyor A drive belt - Encoder	193
Figure 268	Conveyor A drive belt - Main motor	194

Figure 269	Conveyor A drive belt - Left mount bolts	195
Figure 270	Conveyor A drive belt - Right mount bolts	195
Figure 271	Conveyor A drive belt - Sliding motor	196
Figure 272	Conveyor A drive belt - Removing belt	196
Figure 273	Conveyor B drive belt - Cover screws	197
Figure 274	Conveyor B drive belt - Motor pulley cover	198
Figure 275	Conveyor B drive belt - Encoder	199
Figure 276	Conveyor B drive belt - Main motor	200
Figure 277	Conveyor B drive belt - Left mount bolts	201
Figure 278	Conveyor B drive belt - Right mount bolts	201
Figure 279	Conveyor B drive belt - Sliding motor	202
Figure 280	Conveyor B drive belt - Removing belt	202
Figure 281	Conveyor A motor - Removing motor	203
Figure 282	Conveyor A motor - Removing connector (receiving end)	204
Figure 283	Conveyor A motor - Removing connector	204
Figure 284	Conveyor A motor - Hexagonal bolts	205
Figure 285	Conveyor B motor - Removing motor	206
Figure 286	Conveyor B motor - Removing connector (receiving end)	206
Figure 287	Conveyor B motor - Removing connector	207
Figure 288	Conveyor B motor - Hexagonal bolts	207
Figure 289	Conveyor A driven roller - Cover screws	208
Figure 290	Conveyor A driven roller - Removing guide (back side)	209
Figure 291	Conveyor A driven roller - Removing guide (front side)	209
Figure 292	Conveyor A driven roller - Marking adjustment	210
Figure 293	Conveyor A driven roller - Loosening adjusters	210
Figure 294	Conveyor A driven roller - Loosen belt tension	211
Figure 295	Conveyor A driven roller - Removing roller	212
Figure 296	Conveyor A roller - Removing back cover	213
Figure 297	Conveyor A roller - Removing pulley	213
Figure 298	Conveyor A roller - Bearing unit	214
Figure 299	Conveyor A roller - Removing drive roller	215
Figure 300	Conveyor A Transport belt - Removing top plate	216
Figure 301	Conveyor A Transport belt - Removing transport belt	217
Figure 302	Conveyor B driven roller - Cover screws	218

Figure 303	Conveyor B driven roller - Removing guide (back side)	218
Figure 304	Conveyor B driven roller - Removing guide (front side)	219
Figure 305	Conveyor B driven roller - Marking adjustment	219
Figure 306	Conveyor B driven roller - Loosening adjusters	220
Figure 307	Conveyor B driven roller - Loosen belt tension	221
Figure 308	Conveyor B driven roller - Removing roller	222
Figure 309	Conveyor B drive roller - Removing back cover	223
Figure 310	Conveyor B drive roller - Loosening immobilizers	223
Figure 311	Conveyor B drive roller - Removing pulley	224
Figure 312	Conveyor B drive roller - Bearing unit	224
Figure 313	Conveyor B drive roller - Removing drive roller	225
Figure 314	Conveyor B Transport belt - Removing top plate	225
Figure 315	Conveyor B Transport belt - Removing transport belt	226
Figure 316	Block diagram - Display	227
Figure 317	Block diagram - Inverter	228
Figure 318	Block diagram - Power supply	229
Figure 319	Block diagram - Main unit	230
Figure 320	Boards- Main board (TPB-3850)	231
Figure 321	Boards- Transport board (TPB-3851)	232
Figure 322	Boards- A/D board (TPB-3273)	233
Figure 323	Boards- A/D board (TPB-3852)	233
Figure 324	Boards- Relay board (TPB-3853)	234
Figure 325	Boards- Power distribution board (TPB-3854)	234
Figure 326	Boards- Gate sensor (emitter) board (TPB-3282)	235
Figure 327	Boards- Gate sensor (receiver) board (TPB-3283)	236
Figure 328	Boards- Passage sensor (emitter) board (TPB-3863)	236
Figure 329	Boards- Passage sensor (receiver) board (TPB-3864)	237
Figure 330	Boards- Large passage sensor (emitter) board (TPB-3865)	237
Figure 331	Boards- Large passage sensor (receiver) board (TPB-3866)	237
Figure 332	Boards- Stack-lite (TPB-3926)	238
Figure 333	Boards- Switch/LED board (TPB-3948)	238
Figure 334	Boards- Power board (SWF150P-24)	240
Figure 335	Boards- Touch panel relay board (TSC-54/RU-F)	240
Figure 336	Boards- SSD (AXM21ES3-64M-B)	241

Figure 337	Boards- Memory (PC3-12800 4GB)	241
Figure 338	Boards - Motherboard (EMX-BYT2-A1-01R)	242
Figure 339	Boards - CNW-15445-00	243
Figure 340	Boards- CNW-15447-01	244
Figure 341	Boards- CNW-15448-01	245
Figure 342	Boards - CNW-15449-01	246
Figure 343	Boards - CNW-15450-01	247
Figure 344	Boards- CNW-15451-00	248
Figure 345	Boards - CNW-15452-01	249
Figure 346	Boards - CNW-15453-00	250
Figure 347	Boards- CNW-15454-01	251
Figure 348	Boards - CNW-15455-01	252
Figure 349	Boards- CNW-15456-00	253
Figure 350	Boards- CNW-15457-01	254
Figure 351	Boards- CNW-15458-01	255
Figure 352	Boards- CNW-15460-01	256
Figure 353	Boards- CNW-15461-00	257
Figure 354	Boards- CNW-15462-00	258
Figure 355	Boards- CNW-15463-00	259
Figure 356	Boards- CNW-15464-01	260
Figure 357	Boards- CNW-15465-01	261
Figure 358	Boards- CNW-15466-01	262
Figure 359	Boards- CNW-15467-01	263
Figure 360	Boards- CNW-15468-01	264
Figure 361	Boards- CNW-15469-00	265
Figure 362	Boards- CNW-15470-00	266
Figure 363	Boards- CNW-15471-00	267
Figure 364	Boards- CNW-15472-00	268
Figure 365	Boards- CNW-15473-00	269
Figure 366	Boards- CNW-15474-00	270
Figure 367	Boards- CNW-15475-01	271
Figure 368	Boards- CNW-15478-00	272
Figure 369	Boards- CNW-15480-00	273
Figure 370	Boards- CNW-15481-00	274

Figure 371	Boards- CNW-15482-00	275
Figure 372	Boards- CNW-15483-00	276
Figure 373	Boards- CNW-15484-01	277
Figure 374	Boards- CNW-15485-01	278
Figure 375	Boards- CNW-15486-00	279
Figure 376	Boards- CNW-15487-00	280
Figure 377	Boards- CNW-15488-00	281
Figure 378	Boards- CNW-15489-00	282
Figure 379	Boards- CNW-15490-00	283
Figure 380	Boards- CNW-15491-00	284
Figure 381	Boards- CNW-15492-00	285
Figure 382	Boards- CNW-15493-00	286
Figure 383	Boards - CNW-15494-00	287
Figure 384	Boards- CNW-15495-00	288
Figure 385	Boards- CNW-15496-01	289
Figure 386	Boards- CNW-15497-01	291
Figure 387	Boards- CNW-15498-01	293
Figure 388	Boards - CNW-15499-01	294
Figure 389	Boards- CNW-15500-01	296
Figure 390	Boards - CNW-15501-01	298
Figure 391	Boards - CNW-15502-01	299
Figure 392	Boards - CNW-15503-01	300
Figure 393	Boards - CNW-15505-00	301
Figure 394	Boards - CNW-15508-00	302
Figure 395	Log acquisition - Measurement screen	305
Figure 396	Log acquisition - Maintenance	306
Figure 397	Log acquisition - Login	306
Figure 398	Log acquisition - Numeric keypad window	307
Figure 399	Log acquisition - Login	307
Figure 400	Log acquisition - USB ports	308
Figure 401	Log acquisition - USB ports	308
Figure 402	Log acquisition - Measurement screen	309
Figure 403	Log acquisition - Saving log data	310
Figure 404	Log acquisition - Retrieve all data logs	311

Figure 405	Log acquisition - Drive selection	311
Figure 406	Device setting data - Measurement screen	313
Figure 407	Device setting data - Maintenance	313
Figure 408	Device setting data - Login	314
Figure 409	Device setting data - Numeric keypad window	314
Figure 410	Device setting data - USB ports	315
Figure 411	Device setting data - Maintenance screen	316
Figure 412	Device setting data - Setting history	317
Figure 413	Device setting data - Destination drive select	317
Figure 414	Adjustment setting - Maintenance screen	318
Figure 415	Adjustment setting - Export	319
Figure 416	Adjustment setting- Destination drive select	319
Figure 417	Device setting data - Maintenance screen	320
Figure 418	Device setting data - Import	321
Figure 419	Device setting data - File explorer	322
Figure 420	Device setting data - Added Files	323
Figure 421	Device setting data - Recovery window	323
Figure 422	Device setting data - Logout	324
Figure 423	Device setting data - Update settings	324
Figure 424	Adjustment setting data - Maintenance screen	325
Figure 425	Adjustment setting data - Import	326
Figure 426	Adjustment setting data - File explorer	327
Figure 427	Adjustment setting data - Setting history	328
Figure 428	Adjustment setting data - Recovery window	328
Figure 429	Adjustment setting data - Update settings	329
Figure 430	Application installation - Measurement screen	330
Figure 431	Application installation - USB ports	330
Figure 432	Application installation - Update message	331
Figure 433	Application installation - Program installation	331
Figure 434	Firmware Installation - Measurement screen	332
Figure 435	Firmware Installation - - Login window	333
Figure 436	Firmware Installation - Numeric keypad window	333
Figure 437	Firmware Installation - Login	334
Figure 438	Firmware Installation - USB ports	334

Figure 439	Firmware Installation - Firmware screen	335
Figure 440	Firmware Installation - File selection window	336
Figure 441	Firmware Installation - Firmware file selection	337
Figure 442	Firmware Installation - Firmware update window	338
Figure 443	Forced startup method - Warm up notification	339
Figure 444	Forced startup method - Ready screen	340
Figure 445	2-Point span adjustment - Maintenance screen	341
Figure 446	2-Point span adjustment - Login	341
Figure 447	2-Point span adjustment - Passcode	342
Figure 448	2-Point span adjustment - Adjustment	343
Figure 449	2-Point span adjustment - Span adjustment prompt	344
Figure 450	2-Point span adjustment - Adjustment completed	344
Figure 451	2-Point span adjustment - Exit	345
Figure 452	2-Point span adjustment - Logout	345
Figure 453	2-Point span adjustment - Update settings	346
Figure 454	3-Point span adjustment - Maintenance screen	347
Figure 455	3-Point span adjustment - Login	347
Figure 456	3-Point span adjustment - Adjustment	348
Figure 457	3-Point span adjustment - Span adjustment prompt	349
Figure 458	3-Point span adjustment - Adjustment completed	349
Figure 459	3-Point span adjustment - Exit	350
Figure 460	3-Point span adjustment - Logout	350
Figure 461	3-Point span adjustment - Update settings	351
Figure 462	Adjustment leg position - Full conveyor view	352
Figure 463	Leg height adjustment - Loosening nut (B)	353
Figure 464	Leg height adjustment - Adjusting nut (C)	353
Figure 465	Horizontal confirmation - Leveling conveyor	354
Figure 466	Horizontal confirmation- Securing nut (B)	355
Figure 467	Transport surface height - Front and rear conveyor	356
Figure 468	Belt adjustment - Adjuster position	357
Figure 469	Reference position - B1: B conveyor front	358
Figure 470	Reference position - B2: B conveyor back	358
Figure 471	Reference position - A1: A conveyor front	359
Figure 472	Reference position - A2: A conveyor back	359

Figure 473	Belt slippage overview - Good tension	360
Figure 474	Belt slippage overview - Front side stretching	360
Figure 475	Belt slippage overview - Back side stretching	361
Figure 476	Conveyor A belt adjustment - A1: A conveyor front	361
Figure 477	Conveyor A belt adjustment - A2: A conveyor back	362
Figure 478	Conveyor A belt adjustment - Front adjustment	362
Figure 479	Conveyor A belt adjustment - Back adjustment	363
Figure 480	Conveyor B belt adjustment - B1: B conveyor front	363
Figure 481	Conveyor B belt adjustment - B2: B conveyor rear	364
Figure 482	Conveyor B belt adjustment - Front adjustment	364
Figure 483	Conveyor B belt adjustment - Rear adjustment	365

CHAPTER 1

DESCRIPTON

The Cubiscan 200 SQ is an automated weighing and dimensioning system designed to seamlessly measure length, width, height and weight of packages along a conveyor system. The efficient package management of the 200 SQ prevents measurement mistakes, reducing overall costs.

Basic performance



The 200 SQ is designed for the following functions:

1. Transport of goods by belt conveyor (variable speed).
2. Automatic dimensioning of packages (length, width, height).
3. Automatic weighing of package.
4. Instant display of measured values for quick reference.
5. Display of measurement errors to be addressed.
6. Output of the measurement data to a USB memory file.
7. Transfer of measurement data via FTP server (PC).
8. Export of measurement data to an external device through Serial Socket communication.
9. Start/Stop of conveyor remotely by external control device (requires optional DIO).
10. Recording of measurement and operation logs.
11. Facilitating remote operation from client PC on LAN.

Precautions for use

1. Do not install the 200SQ in direct sunlight.

2. Install system on a flat, horizontal surface with little vibration.
3. For 3D measurement, an installation area larger than the machine size is required.
4. Since the 200 SQ is a scale, any touching of the conveyor system during operation will cause error in measurement.

Specifications



Basic Specifications

Transport Section	Motor	G3L22N5N-IPM040NT : 400w x 2 units
	Inverter	VF-NC3M-2004PY-A30 : 2 units
	Transport Belt	Belt width: 880mm, Guide width: 910mm
	Roller diameter	Φ70mm
Measurement (weight)	Capacity	50kg
	Scale	50g(0~5kg)/100g(5kg~50kg)
	Detection method	Loadcell
	Tolerance	150g(0~5kg)/300g(5kg~50kg)
	Weighing range	200g~50kg
Measurement (size)	Scale	5mm
	Detection	Infrared transmission sensor
	Tolerance	±5mm
Maximum package size	L: 1530 mm, W: 900 mm, H: 900mm	
Minimum package size	L: 150 mm, W: 100 mm, H: 5 mm	
Transport speed	30~120 m/min	

Inching operation	<p>If the cargo is stopped or started while it is passing through the conveyor, the cargo may vibrate, fall, or slide. This can cause the following symptoms:</p> <ol style="list-style-type: none"> 1. Dimensions and weight are not measured correctly. 2. The output timing of measured values fluctuates in data communication. 3. Abnormal transport due to operation with a motor or inverter that is not rated.
Minimum transport interval	700mm
Transport surface height	500mm
Body dimensions	L: 1735mm, W: 1350mm, H: 1560mm
Body weight	About 460kg
Interface (standard)	RS-232C: D-Subs pin (RS-422 is optional)
Interface (option)	<p>RS-422: DIO terminal (RS-232C cannot be used at the same time).</p> <p>For control device connection DIO input:</p> <ul style="list-style-type: none"> • Transport, high speed, medium speed, low speed, reverse transport, emergency stop, inverter reset. <p>For control device connection DIO output:</p> <ul style="list-style-type: none"> • Power on, transporting, measurable, scale abnormality, sensor abnormality, inverter abnormality, emergency stop, conveyor inlet sensor, conveyor outlet sensor, Gate sensor, BCR trigger
Usage environment	<p>Operating temperature: 0~40°C (No condensation)</p> <p>Operating humidity: 15~85%RH (No condensation)</p>
Power-supply voltage	AC200~240V Three-phase (50/60Hz)
Consumption	1.1 kVA

Display specifications

Display	15-inch color LCD, touch panel
Interface	USB, Ethernet(100BASE-TX)
External dimensions	L : 136mm, W : 360mm, H : 344mm
Display mass	About 8kg
Installation	Directly attached to main body mount
Installation orientation range	From the front side to 90° left and right




Figure 1
Display specification: Range of motion

NOTE > Although the display can be rotated at an angle larger than 90°, the display should be installed within the range of 90° in order to prevent wire breakage.

Power supply specifications

Power plug shape: Three-phase 200V grounded 3P (Three-phase + earth)

Used plug model number: MH2584

Cable length: 5m from the main body




Figure 2
Power supply specification: Plug shape

Dimensions




Figure 3
Dimensions: Top view of the main body




Figure 4
Dimensions: View of display




Figure 5
Dimensions: Front view of the main body




Figure 6
Dimensions: Side view of the main body

Part description

Conveyor main unit




Figure 7
Part description: Conveyor main unit

1. Emergency stop button	Press this button to stop the machine in case of emergency.
2. Gate sensor	Sensors used for dimensioning packages (length, height, and width).
3. Main power switch	Switch for toggling the conveyors main power off and on.
4. Passage sensor	Sensor for detecting the movement of packages on the conveyor.
5. Manual switch	Switch to manually move conveyor forward or reverse.

Display




Figure 8
Part description: Display unit

1. Touch panel	You can press the button displayed on the screen.
2. USB port	Port for USB memory or handy scanner connection.
3. LAN port	Port for PC network connection.
4. Power switch	Press switch for SQ start up.
5. Connector for conveyor	Port of conveyor connection.
6. Indicator light	Indicates the proper functioning of the system.
7. Status LED	Indicates the functioning of the display.
8. RS232C connector	Port for PC connection.

Safety sticker position



A		B	
C		D	
E		F	




Figure 9
Safety sticker position: Safety stickers

Switches description

Main switch (main breaker)

Open the cover on the side of the conveyor to find the main power supply as illustrated below. The cover closes when you release the knob.




Figure 10
Switches description: Main switch cover

Main breaker	When off (lever lowered), all 200 SQ systems power is turned off.
Control breaker	When off, all 200 SQ systems power is turned off except for the optional scanner.

Emergency stop switch




Figure 11

Switches description: Emergency stop switch

In case of emergency or possible injury, use the emergency stop switch to immediately shutdown conveyor function. Press the emergency stop switch button to stop the conveyor. In order to restart the conveyor, turn the button clockwise.

Manual switch

Use the manual switch to maneuver the conveyor in case of emergency where conveyor does not move do to malfunction. If the conveyor power unit (motor/inverter) malfunctions, the conveyor will not operate even if switch is used.

To access the switch, loosen the screw and remove cover.




Figure 12

Switches description: Manual switch cover

The switch may be turned to the FORWARD or REVERSE position. If the switch is in the FORWARD position, the conveyor moves in the forward direction. In the REVERSE position, the conveyor moves in the reverse direction.



Figure 13

Switches description: Manual switch

Indicator specifications

Indicator overview




Figure 14
Indicator specifications: Indicator overview

Operation table

Green indicator	Red indicator	Alarm	Status
Blinking	Blinking	Silent	Warm up
Off	Off	Silent	Conveyor is stopped
Off	Blinking	Ringing	Warning for conveyor starting
On	Off	Silent	Measurement in process
Off	On	Ringing	Measurement error
Off	Blinking	Silent	System error

Communication Specifications



FTP communication

Operation

1. The 200 SQ operates as an FTP client with a PC operating as the FTP server.
2. File transfers (PUT) from the 200 SQ occur at intervals of 1 to 1440 minutes (24 hours).
3. If there is no measurement record, the data file will not be transferred.
4. The format of the file to be sent is CSV format, separated by commas.
5. The file name is "xxxx_YYYYMMDDhhmmss.csv".
6. In the file name, xxxx is an arbitrary string assigned by the system, YYYYMMDD is the date (Year, Month, Day), hhmmss is the time (hour, minute, second).
7. The 200 SQ supports two modes of communication: passive mode and SSL mode.

File format

	Item	Format	ASCII	Notes
1.	Date	variable length	2017/5/12	
2.	Time	variable length	8:23:05	
3.	Header	"MA"	4Dh, 41h	
4.	Machine number	00-99		
5.	Measurement number	000.0-9999		
6.	Length header	"L"	4Ch	
7.	Length	0000-999.9		
8.	Length status	00-99		More details
9.	Width header	"W"	57h	

	Item	Format	ASCII	Notes
10.	Width	000.0-999.9		
11.	Width status	00-99		More details
12.	Height header	"H"	48h	
13.	Height	000.0-999.9		
14.	Height status	00-99		More details
15.	Measurement unit	"mm", "cm", "m", or "in"		
16.	Weight header	"M"	4Dh	
17.	Weight	0.00-99.99		
18.	Weight status	00-99		More details
19.	Weight unit	"kg" or "lb"		
20.	Error number	00-99		More details
21.	Barcode header	"B"	42h	
22.	Barcode value			
23.	Barcode status	00-99		More details

NOTE >

When reading two or more barcodes per measurement, the number of columns in the file will increase by the number of barcode values with each barcode value separated by a comma.

Socket communication

Operation

1. The 200 SQ operates as a server with a PC operating as a client.
2. Measurement result packets are sent to the PC when the server port is open.
3. A dummy packet is sent to the client once every 30 seconds.

Outgoing packet format

	Item	Format	ASCII	Notes
1.	Start text	STX	02h	
2.	Header	"MA"	4Dh, 41h	

	Item	Format	ASCII	Notes
3.	Machine number	00-99		
4.	Measurement number	0000-9999		
5.	Length header	"L"	4Ch	
6.	Length	000.0-999.9		
7.	Length status	00-99		More details
8.	Width header	"W"	57h	
9.	Width	000.0-999.9		
10.	Width status	00-99		More details
11.	Height header	"H"	48h	
12.	Height	000.0-999.9		
13.	Height status	00-99		More details
14.	Measurement unit	"mm", "cm", "m", or "in"		
15.	Weight header	"M"	4Dh	
16.	Weight	0.00-99.99		
17.	Weight status	00-99		More details
18.	Weight unit	"kg" or "lb"		
19.	Error number	00-99		More details
20.	Barcode header	"B"	42h	
21.	Barcode value			
22.	Barcode status	00-99		More details
23.	End text	ETX	03h	

NOTE 

When reading two or more barcodes per measurement, the number of columns in the file will increase by the number of barcode values with each barcode value separated by a comma.

Dummy packet format

	Item	Format	ASCII	Remarks
1.	STX	02h	1 digit	
2.	Identification code	"DA"	2 digit	Dummy packet
3.	ETX	03h	1 digit	

Serial communication (RS-232C/RS-422)

RS-232C Interface

When connecting to a PC, use the optional cable (PLU: 23299).




Figure 15
Serial Communication: Connector details

Connector A to 200 SQ		
No.	Signal	Color
2	RXD	red
3	TXD	purple
5	GND	green
7	RTS	purple
8	CTS	gray

Connector B to PC		
No.	Signal	Color
2	RXD	purple
3	TXD	red
5	GND	green
7	RTS	gray
8	CTS	purple

RS-422 Interface (optional)

The optional RS-422 interface connects to the DIO external connection terminal block using the ports: TX+, TX-, and GNDS (numbered respectively as 14, 15, and 16).

SQ side tube marked																													
POW_ON	ENV_R	STATE	ERR_SCL	ERR_SEN	INV_ERR	MES_ERR	E-STOP	MES_OK	MES_NG	SEN1	SEN2	TRG_BCR	TX+	TX-	GNDS	GNDP	MSE_ERR	SPP2	SPP3	SPP4	SPP5	.	.
①	②	③	④	⑤	⑥	⑦	⑧	⑨	⑩	⑪	⑫	⑬	⑭	⑮	⑯	⑰	⑱	⑲	⑳	㉑	㉒	㉓	㉔	㉕	㉖	㉗	㉘	㉙	㉚
①	②	③	④	⑤	⑥	⑦	⑧	⑨	⑩	⑪	⑫	⑬	⑭	⑮	⑯	⑰	⑱	⑲	⑳	㉑	㉒	㉓	㉔	㉕	㉖	㉗	㉘	㉙	㉚
(DIO output terminal)																													

Figure 16
Serial Communication: Connecting RS-422 interface

Communication Specifications

Transmission method	Synchronous pace
Transmission speed (bps)	4800, 9600 (default), 19200, 38400, 115200
Data bit	7bit, 8bit (default)
Parity bit	None, Even (default), odd
Stop bit	1bit (default), 2bit
Flow control	None (default), hardware, Xon/Xoff

Communication format

	Item	Format	ASCII	Notes
1.	Start text	STX	02h	
2.	Header	"MA"	4Dh, 41h	
3.	Machine number	00-99		
4.	Measurement number	0000-9999		
5.	Length header	"L"	4Ch	
6.	Length	000.0-999.9		
7.	Length status	00-99		More details

	Item	Format	ASCII	Notes
8.	Width header	"W"	57h	
9.	Width	000.0-999.9		
10.	Width status	00-99		More details
11.	Height header	"H"	48h	
12.	Height	000.0-999.9		
13.	Height status	00-99		More details
14.	Measurement unit	"mm", "cm", "m", or "in"		
15.	Weight header	"M"	4Dh	
16.	Weight	0.00-99.99		
17.	Weight status	00-99		More details
18.	Weight unit	"kg" or "lb"		
19.	Error number	00-99		More details
20.	Barcode header	"B"	42h	
21.	Barcode value			
22.	Barcode status	00-99		More details
23.	Checksum	00-FF		ASCII code the last 2 digits of the hexadecimal addition of data from 2 to 22
24.	End text	ETX	03h	

NOTE >

When reading two or more barcodes per measurement, the number of columns in the file will increase by the number of barcode values with each barcode value separated by a comma.

Status in communication format

Measuring status (L/W/H)

Code	Status	Error number
00	Normal measurement	
01	Size error	E17, E93, E95, E97
11	Size error	E16, E92, E94, E96
21, 22	Luggage spacing is too short.	E18, E19

Code	Status	Error number
31	Reduced or increased transport speed.	E10, E11
51	One of the passage sensors 1 to 8 could not detect the article normally.	E20~E34
71	<ul style="list-style-type: none"> • The article could not be detected. • Tracking by the passage sensor could not be performed correctly. • The value of the article length changed during tracking. • Error during measurement and weighing calculation. • When the detection status of the passage sensor and the gate sensor do not match. 	E01~E08, E40~E49
72	Article passed outside the measurable area.	E09
73	The article is judged to be atypical.	E12~E15

Weighing status (M)

Code	Status	Error number
00	Normal weighing	
01	Weight error (Items exceed weight limit)	E99
11	Size error (Items below minimum weight)	E98
21, 22	Luggage spacing is too short.	E18, E19
31	Reduced or increased transport speed.	E10, E11
51	One of the passage sensors 1 through 8 could not detect the article normally.	E20~E34

Code	Status	Error number
71	<ul style="list-style-type: none"> The article could not be detected. Tracking by the passage sensor could not be performed correctly. The value of the article length changed during tracking. Error during measurement and weighing calculation. The detection status of the passage sensor and the gate sensor do not match. 	E01~E08, E40~E49
72	Article judged to be atypical.	E09

Barcode status

Code	Status	Error number
00	Normal read	
89	Communication error with barcode scanner	E89
90	No read	E90
91	Multi read	E91

Error barcode status

Code	Error details
00	Normal measurement completed
01-05	E01-05: Could not recognize the cargo properly. Please measure again.
06	E06: Gate sensor error
07	E07: Invalid error
08	E08: Could not recognize the cargo properly. Please measure again.
09	E09: Cargo passed through areas outside the measurement range. Please measure again at the center of conveyor.
10	E10: During the measurement, a decrease in the transport speed was detected. Please measure again.

Code	Error details
11	E11: During measurement, an increase in the transport speed was detected. Please measure again.
12-15	E12-15: It was judged to be non-cubic.
16	E16: The length of the cargo is too short.
17	E17: The length of the cargo is too long.
18-19	E18-19: The gap between the cargo is too short. Please remeasure it.
20-21	E20-21: The photosensor (1) could not detect the cargo. Please measure again.
22-23	E22-23: The photosensor (2) could not detect the cargo. Please measure again.
24-25	E24-25: The photosensor (3) could not detect the cargo. Please measure again.
26-27	E26-27: The photosensor (4) could not detect the cargo. Please measure again.
28-29	E28-29: The photosensor (5) could not detect the cargo. Please measure again.
30-31	E30-31: The photosensor (6) could not detect the cargo. Please measure again.
32-33	E32-33: The photosensor (7) could not detect the cargo. Please measure again.
34-35	E34-35: The photosensor (8) could not detect the cargo. Please measure again.
40	E40: Cargo is too small.
41	E41: It is possible that the length of the cargo could not be measured correctly. Please measure again.
42	E42: Invalid error.
43	E43: Weight calculation timeout error. Please measure again.
44	E44: Weight calculation timeout error. Please measure again.
45-46	E45-46: Could not recognize the cargo properly. Please measure again.
47	E47: Size measurement calculation error. Please measure again.
48	E48: Cargo detection error.
49	E49: The gate sensors have been intercepted.
89	E50: Injection error (not ready)
90	E90: Scanner: no read
91	E91: Scanner: multi read
92	E92: Cargo length too short
93	E93: Cargo length too long

Code	Error details
94	E94: Cargo width too short
95	E95: Cargo width too long
96	E96: Cargo height is too low
97	E97: Cargo height is too high
98	E98: Cargo is too light
99	E99: Cargo is too heavy

Communication timing (socket/serial)

Data output for rear of package

Depending on system settings, specifications may vary. Typical data output follows:

Maintenance ⇨ Device setting ⇨ Weighing ⇨ Output timing

- Set timing output result will be "0: normal output" or "1: time delay output" is set.




Figure 17
Rear package data output

- After the article passes through the passage sensor at the end of the main unit, data transmission will start in *1msec. The error at the time of output is *2msec plus/minus.

*1	Maintenance⇒Device setting⇒Weighing⇒Output timing of result: Delay time setting.
*2	Maintenance⇒Device setting⇒Weighing⇒Output timing of result: Tolerance setting value.

NOTE >

If the conveyor is stopped or started during or after the baggage has passed, or if the transport speed is not synchronized with the main body due to the start/stop of the post-stage conveyor, the article may tip over or slide, causing the specified transmission timing to shift.

Data output for front of package

Depending on system settings, specifications may vary. Typical data output follows:

Maintenance ⇒ Device setting ⇒ Weighing ⇒ Output timing

- Set timing output result will be "2: Reference position output".




Figure 18
Communication specifications: Front package data output

- Data transmission begins when the head of the item reaches the specified position (*1). This position can be set to any location that is at least the length of the item. The error at the time of output is *2msec.

*1	Maintenance⇒Device setting⇒Weighing⇒Output timing of result: Delay time setting.
*2	Maintenance⇒Device setting⇒Weighing⇒Output timing of result: Tolerance setting value.

NOTE >

If the conveyor is stopped or started during or after the baggage has passed, or if the transport speed is not synchronized with the main body due to the start/stop of the post-stage conveyor, the article may tip over or slide, causing the specified transmission timing to shift.

DIO External input/output signal (optional)

Terminal block mounting position




Figure 19

Communication specifications: PLC box cover closed




Figure 20

Communication specifications: Opening PLC box cover

Input connection diagram




Figure 21

Communication specifications: Terminal block connection diagram (input)




Figure 22

Communication specifications: Circuit diagram (input)

No.	Mark tube	Signal	Short	Open	Notes
31	RH	High speed transport	High speed transport	...	
32	RM	Medium speed transport	Medium speed transport	...	
33	RL	Low speed transport	Low speed transport	...	
34	REV	Transport direction	Reversal	Forward rotation	
35	RST	Inverter reset	Reset	...	Reset to inverter
36	RUN	Transport command	Transport	Stop	
37	ESW	Emergency stop	Emergency stop	...	

No.	Mark tube	Signal	Short	Open	Notes
38	ESW	Emergency stop (spare)	Emergency stop	...	
39	GND	For common GND			

Output connection diagram




Figure 23
Communication specifications: Terminal block connection diagram (output)




Figure 24
Communication specifications: Circuit diagram (output)

No.	Mark tube	Signal	Short	Open	Notes
1	POW_ON	Power on	Power on	Power off	
2	CNV_R	In transit	In transit	Stop	
3	STATE	Measurable	Possible	Impossible	
4	ERR_SCL	Abnormal scale	Normal	Abnormal	Error No. 5002-5009

No.	Mark tube	Signal	Short	Open	Notes
5	ERR_SEN	Abnormal sensor	Normal	Abnormal	Error No. 5013-5022
6	INV_ERR	Abnormal inverter	Normal	Abnormal	Error No. 6101-6284
7	MES_ERR	Other abnormalities	Normal	Abnormal	Error No. 9001-9804
8	E_STOP	Emergency stop	In operation	Emergency stop	
9	MES_OK	Usage prohibited			
10	MES_NG	Usage prohibited			
11	SEN1	Conveyor entrance sensor	Detection	Not detected	
12	SEN2	Conveyor exit sensor	Detection	Not detected	
13	TRG_BCR	BCR trigger	Detection	Not detected	
14	TX+	RS-422 output +			
15	TX-	RS-422 input -			
16	GNDS	RS-422 GND			
17	GNDP	Common GND			

Getting started



Tools for setup

Before setting up the 200 SQ, please prepare the following tools:

- Phillips screwdriver
- Hex wrench (5mm-6mm)
- Wrench (8mm)
- Level
- USB memory device

Checklist for setup

SQ installation checklist

Please record the following information before setup:

User Name	
Model Name	
N10 Ver.	
FPGA (Main) Ver.	
FPGA (Relay) Ver.	
Installation date	
Serial No.	
SH Ver.	
FPGA (Conveyor) Ver.	
SQ Disp. APP Ver.	

Use the following checklist to help with the setup process. Put a check mark next to each completed item:

Setup Procedure			
1.	The 200 SQ installation	To prevent injury, please move the 200 SQ by forklift.	<input type="checkbox"/>
2.	Taking the shipping stopper off	Take the 10 shipping stoppers and remove the zip tie and remove the air package for the UPS.	<input type="checkbox"/>
3.	Installation of the sensor cover	Set the conveyor covers for each conveyor (A and B).	<input type="checkbox"/>
4.	Installation of console and hand scanner (optional)	If using a optional hand scanner, mount bracket to frame.	<input type="checkbox"/>
5.	Installation of fixed scanner	If installing fixed scanner, affix the scanner to the top bracket of the frame.	<input type="checkbox"/>
6.	Check the power cable and 200 SQ start up	Plug the 200 SQ outlet in, then check the application booting.	<input type="checkbox"/>
7.	Date and time setting	Check the date and time setting in maintenance mode.	<input type="checkbox"/>
8.	Device setting	Check the device setting in the maintenance mode.	<input type="checkbox"/>
9.	Weight setting	Check the weight setting in the maintenance mode.	<input type="checkbox"/>
10.	Weight adjustment	Use 50kg weight placed on select point in middle and each corner of the scale platform to assure weighing accuracy.	<input type="checkbox"/>
11.	Backup maintenance setting data	Back up the setting file to USB memory in maintenance mode.	<input type="checkbox"/>
12.	Operation confirmation in test mode	Check that all data is correct by moving the item on the conveyor.	<input type="checkbox"/>

200 SQ installation

Unloading and installation of the main unit

Since the 200 SQ is a large machine, a forklift is required for unloading. Any attempt to move the main unit without a forklift may result in injury or damage to unit. When moving on a flat surface, casters are provided to make movement of the unit easier.

When maneuvering with a forklift, position the forks in the designated holes indicated in the following figure:



Figure 25
Unloading and installation: Designated fork holes

After unloading, unlock each of the four casters while positioning on a flat surface. Please make sure there are no stairs or inclines nearby when moving the unit.

With the four caster unlocked position the unit in the desired location. When the unit is properly positioned in the installation location, lock each of four casters again. This will prevent unwanted movement of unit.




Figure 26
Unloading and installation: How to lock casters

Removal of shipping stopper

Location of shipping stoppers

Remove all shipping stoppers as depicted in the figure below:




Figure 27

Removal of shipping stoppers: Shipping stoppers diagram (front)




Figure 28

Removal of shipping stoppers: Shipping stopper (back)




Figure 29
Removal of shipping stoppers: Shipping stopper (Conveyor A)




Figure 30
Removal of shipping stoppers: Shipping stopper (Conveyor B)

Removal procedure of shipping stopper

1. Take off plates G and H by removing the two screws with hex wrench.



Figure 31

Removal of shipping stoppers: Removing plates G and H

2. Take off plates A, B, I, and J by removing the four screws with hex wrench.



Figure 32

Removal of shipping stoppers: Remove plates A, B, I, J

3. Take off plates C, D, E, and F by removing the four screws with hex wrench.




Figure 33

Removal of shipping stoppers: Remove plates C, D, E, and F

UPS shipping stopper removal (optional)

1. Cut the zip tie securing the UPS
2. Remove the air pack wrapping.




Figure 34

Removal of shipping stoppers: UPS shipping stopper removal



Figure 35

Removal of shipping stoppers: Removing zip ties and airpack

Console and scanner installation

1. Remove the 4 cup screws to fix stand pole to console.




Figure 36

Console and scanner installation: Stand pole

2. Affix the console to the pole stand. Attach the display bracket and set the stand pole on inside of scanner stand. Once positioned properly, tighten the 4 cup screws to secure the console in place. Refer to the figures below.




Figure 37

Console and scanner installation: Securing display bracket




Figure 38

Console and scanner installation: Display bracket diagram (rear view)

NOTE >

The console angle may be adjusted at anytime by loosening the side screws and repositioning. Make sure to tighten screws once properly positioned.

3. Connect the USB cable under the cradle for the hand scanner before mounting to console bracket.



Figure 39

Console and scanner installation: Connecting USB cable

4. Loosen bolts on side of scanner stand bracket. Insert the pole of the console into the bracket.




Figure 40

Console and scanner installation: Installing console pole

5. Tighten the hex bolts to secure console pole in place.




Figure 41

Console and scanner installation: Secure console pole

6. Attach the cradle for the optional hand scanner by securing the cradle to the console via screws on underside.




Figure 42

Console and scanner installation: Hand scanner cradle

7. Ensure console is installed parallel to 200 SQ as shown in the figure:




Figure 43

Console and scanner installation: Final console installation

8. Connect the USB cable from the cradle and LAN cable for PC to the USB ports in the right side of the console.




Figure 44

Console and scanner installation: Console cables

Fixed scanner installation (optional)

1. Remove the 3 cap screws from the fixed scanner.




Figure 45

Fixed scanner installation: 3 cap screws

2. Position the scanner under the bracket and secure in place by raising the docking fixture through the corresponding hole and sliding into place.




Figure 46

Fixed scanner installation: Docking fixture

3. Replace the 3 cap screws by threading through the corresponding hole in the bracket.




Figure 47
Fixed scanner installation: Cap screw holes




Figure 48
Fixed scanner installation: Securing fixed scanner

4. Remove caps from [POWER] and [I/O] connectors by turning clockwise.



Figure 49

Fixed scanner installation: Removing connector caps

5. Connect the blue cable from main unit to [I/O] connector and the black cable to [POWER] connector.




Figure 50

Fixed scanner installation: Connecting [POWER] and [IO] cables

6. Power on scanner and look for the laser emission to ensure the scanner is functioning properly.

7. Once the 200 SQ is fully set up, position adjustments may be made to ensure reliability.

Powering on

1. Turn the power on after inserting the power plug. Ensure the power source is designed to handle 20A and 250V. After the plug is inserted into the outlet, turn clockwise to secure in place. This prevents the plug from being unintentionally pulled from the wall.




Figure 51
Powering on: Plugging in

2. Open the cover to the main switch located at the side of the unit. Toggle the switch to the ON position. The unit should power on.




Figure 52
Powering on: Main switch cover




Figure 53
Powering on: Main switch

3. It may take about 8 minutes (480 seconds) for the 200 SQ operation system to boot up and the scale to finish its warming up procedure. A countdown clock will appear on the screen. Once the notification disappears, the unit is ready for product.

Sensor cover assembly

1. Place 4 covers over sensors in the areas designated in the figure:




Figure 54

Sensor cover assembly: Locations for sensor covers

2. Secure covers with screws in the 14 locations shown in the figure:




Figure 55

Sensor cover assembly: Securing sensor covers

Date and Time setting

1. In order to modify the date and time, go to **[Setting]** from main control screen.



Figure 56
Date and Time setting: Settings

2. Select **[Maintenance]** in the right panel.



Figure 57
Date and Time setting: Maintenance

- At the Login screen, check the box next to **Maintenance**, then tap in the **Password** text field to enter passcode.



Figure 58
Date and Time setting: Login screen

- A passcode window will appear. Enter the passcode **8715** followed by [Enter].




Figure 59
Date and Time setting: Entering passcode

- The Login dialog box will return. Ensure that the box next to **Maintenance** is checked and tap **[Login]**.



Figure 60
Date and Time setting: Returning to login

- In the **Setting** menu, select **Device setting** by tapping the [+].



Figure 61
Date and Time setting: Device setting

Select **Clock**, from the **Device setting** options.



Figure 62
Date and Time setting: Clock settings

7. Use the calendar to set the date as shown in the figure:



Figure 63
Date and Time setting: Setting date

- Use the [+] and [-] buttons to set the Hour, Minute, and Second.



Figure 64
Date and Time setting: Setting clock time

- Tap [Set] after date and time settings are entered.

Conveyor setting

- From the **Device setting** menu found within the **Setting** panel, select **Conveyor**.



Figure 65
Conveyor setting: Conveyor screen

2. Ensure that the Conveyor setting matches those shown in the following figure:




Figure 66
Conveyor setting: Settings

Scanner setting (optional)

1. Select **Scanner** from the **Device setting** menu.



Figure 67
Scanner setting: Scanner option

2. If using the fixed scanner, select the **Fixed** tab.




Figure 68
Scanner setting: Fixed menu

3. If using the hand scanner, select the **Handy** tab. Once the scanner connects tap **[Enable]**. The box next to **Enable** should be checked.




Figure 69
Scanner setting: Enable hand scanner

NOTE >

Be sure to enable the scanner after it is properly connected. If scanner can not be found, ensure the device is properly connected. If problem persist please **contact Cubiscan Technical Assistance at 801.451.7000** for assistance.

- Once the scanner connects, select the **Barcode** tab and choose the barcode type from the drop down menu under **Symbol1**.




Figure 70
Scanner setting: Barcode menu

- Select the **Combination** tab and uncheck the box under **Essential**.



Figure 71
Scanner setting: Combination menu

TCP/IP setting (optional)

1. Select TCP/IP under Device setting in the side menu.



Figure 72
TCP/IP setting: TCP/IP menu

2. Ensure that the settings for IP address, Mask, and Gateway match those in the figure below:





Figure 73
TCP/IP setting: Settings

3. Once the settings are entered correctly, save the setting by tapping [Apply settings now].
4. Next, select **FTP** under **Device setting** from the side menu.



Figure 74
TCP/IP setting: FTP menu

5. Ensure the **FTP** settings match those from your network. The Password will be blanked out in the text box. The default password is "matehan".



The screenshot shows a configuration window titled "Result upload server". It contains the following fields and controls:

- Result upload:** A dropdown menu with "FTP" selected.
- Transmission interval:** A numeric input field containing "5", with minus and plus buttons, followed by the text "Minute".
- Address:** A text input field containing "192.168.1.1".
- File name:** A text input field containing "YYYYMMDDhhmmss.csv".
- User:** A text input field containing "FTPServerLoginID".
- Password:** A text input field with four dots, indicating a masked password.
- Passive mode:** A checkbox that is currently unchecked.
- SSL mode:** A checkbox that is currently unchecked.

Figure 75
TCP/IP setting: FTP settings

Weight setting

1. Expand the **Adjustment** menu by tapping the **[+]** and select **Weight** from the expanded options.



Figure 76
Weight setting: Weight menu

2. Ensure all settings in the **Weight** menu match those in the following figure:




Figure 77
Weight setting: Settings

3. Select **Length** under **Adjustment** in the left side menu.



Figure 78
Weight setting: Length menu

4. Ensure all setting match those in the following figure.



Figure 79
Weight setting: Length settings

Scales setting

1. Expand the **Device setting** menu by tapping [+], and select **Scales** from the expanded menu.



Figure 80
Scale settings: Scales menu

2. Tap **[Zero]** to set scale to 0.



Figure 81
Scale settings: Zeroing scale

- Use the calibration weight of 50kg to calibrate the scale in the 10 key points along the conveyor as depicted in the following figure.:




Figure 82
Scale settings: Conveyor calibration points

- To calibrate, zero the scale, then place the weight on one of the 10 positions along the conveyor. Record the weight, and then remove. Record the measured weight after removing the calibration weight. Use a table like the following to record the values:

Weight calibration results				
	0 kg	50 kg	0 kg	Scale
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				

NOTE >

Acceptable weight tolerance is within $\pm 100g$. If weight exceeds the tolerance limit, check the conveyor and its cable to ensure that nothing is touching the main unit as this may interfere with correct measurement.

5. To leave the scale screen, tap **[Exit]**. A pop-up message will appear with an option to logout. Check the box next to **Logout** and tap **[OK]**.




Figure 83
Scale settings - logout screen

6. If you have adjusted any settings, another pop-up message will appear to update settings. Enter your name or username in the text box next to **Signature**. This will allow the system to track who made changes to the scale settings. Next, tap **[Update]** to save changes to the settings.



Figure 84
Scale settings - update screen

Setting data backup

Maintenance recovery

1. To backup data to a USB memory drive, plug the drive into one of the USB ports on the side of the console unit.




Figure 85
Setting data backup - USB ports

If the system security is active, a software keyboard and password authentication screen will appear shortly after the USB memory drive is plugged in. Enter the password to be able to save on the drive.

- Once the USB drive is properly connected to the console, open the **Maintenance** menu by tapping **[Setting]**.



Figure 86
Setting data backup - Setting

- When the **Setting** screen appears, tap **[Maintenance]**.



Figure 87
Setting data backup - Maintenance

- Next, tap in the **Password** text box. A touchpad will appear. Enter the passcode **8715**, then tap **[Enter]**.




Figure 88
Setting data backup - Entering passcode

Tap **[+]** next to **Device setting** in the side panel and select **Recovery** from the drop down list.



Figure 89
Setting data backup - Recovery menu

5. A list of the most recent data will appear in **Setting history** with the date of the recording. Select the data of the latest date and tap **[Export]**.



Figure 90
Setting data backup - Recovery setting history

6. A pop of menu will appear requesting the drive to which the data will be backed up. Select the drive for the USB memory drive and tap **[OK]**.



Figure 91
Setting data backup - Select drive

- Another popup will appear requesting confirmation. Tap **[Yes, I understood]** to complete the recovery process.



Figure 92
Setting data backup - Confirmation popup

- The file will be found on the memory drive in a folder designated with the machine number. The file name will follow the format **YYMMDDhhmmss.ini**, where Y=year, M=month, D=day, h=hour, m=minute, or s=second.

Adjustment data backup

- Adjustment data can be backed up similar to maintenance data. To back up adjustment data, open the **Adjustment** drop down menu by tapping **[+]**. Then, tap **[Recovery]**.



Figure 93
Setting data backup - Adjustment recovery

2. A list of the most recent adjustment data will appear in **Setting history** with the date of the recording. Select the data of the latest date and tap **[Export]**.




Figure 94
Setting data backup - Adjustment setting history

3. A pop of menu will appear requesting the drive to which the data will be backed up. Select the drive for the USB memory drive and tap **[OK]**.



Figure 95
Setting data backup - Select drive

- Another popup will appear requesting confirmation. Tap **[Yes, I understood]** to complete the recovery process.



Figure 96
Setting data backup - Confirmation popup

- The file will be found on the memory drive in a folder designated with the machine number. The file name will follow the format **YYMMDDhhmmss.ini**, where Y=year, M=month, D=data, h=hour, m=minute, or s=second.

Measurement confirmation

- To confirm the accuracy of measurements, use a calibration cube or a box with known measurements. Tap **[Start]** on the console.



Figure 97
Measurement confirmation - Start

- The **Conveyor warning** message will appear to warn that the conveyor is moving with an option to stop the conveyor. The message will soon disappear as the conveyor starts.



Figure 98

Measurement confirmation - Conveyor warning message

- When **[Zero]** and **[Ready]** indicators both turn green, the sensor is ready for measurement. Place the object for calibration on the edge of conveyor A. The measurement results will display.



Figure 99

Measurement confirmation - Ready for measurement

4. Run the same calibration object on the conveyor about ten times.
Record the measurements in a table like the following:

Test sampling					
Measurement	Width	Length	Height	Weight	Barcode
Actual					
1					
2					
3					
4					
5					
6					
7					
8					
9					
10					

NOTE >

Acceptable weight tolerance is within $\pm 5\text{mm}$. If the box does not have a barcode, a "No Read" error may trigger. If the box has multiple barcodes, a "Multi Read" error will display. In both cases the conveyor will stop.

CHAPTER 3 MAINTENANCE MODE

Measurement screen




Figure 100
Measurement screen - Details

1.	System information	System error or any information is displayed.
2.	Conveyor speed	Displays the speed of either conveyor A or B
3.	Status	There are 3 icons that explain the status: <ul style="list-style-type: none"> • Scanner (No icon when not in use) • Serial communication (No icon when not in use) • LAN communication (No icon when not in use)
4.	Language	Displays current language.
5.	Barcode	Displays the measured barcode data.

6.	Weight	Displays weight of measured object.
7.	Volume weight	Displays volume of measured object. Note: Volume weight = Volume/coefficient (default coefficient is 6000).
8.	Length	Displays length of measured object.
9.	Width	Displays width of measured object.
10.	Height	Displays height of measured object.
11.	Error	Displays any errors that occurred during measurement. If no errors occurred, box will be left blank.
12.	Shape	Displays a 3-dimensional representation of the measured object.
13.	Zero point	Indicator light is on when all scales are in zero tracking state (zero point).
14.	READY	Indicator light is on when the conveyor is unobstructed and ready to receive. The following conditions must be met: <ul style="list-style-type: none"> • Conveyor runs at 30-70mm/min • The scale is in zero state • No objects within 700mm along the conveyor. • No current system errors.
15.	Zero reset	Tap to reset the scale to zero. This function is not available while conveyor is in operation.
16.	Start	Tap to activate the conveyor.
17.	Results	Tap to access the data history screen.
18.	Maintenance	Tap to access the maintenance mode.
19.	Stop	Tap to stop conveyor.

Status display icon details (status)

Scanner		Error occurrence status
		Read standby state
		Receiving barcode data
Serial		Error occurrence status
		Read standby state
		Sending measurement data
LAN		Error occurrence status
		Read standby state
		Sending measurement data

Select language details

Tap the desired language from the list of country options:



Figure 101
Measurement screen - Language selection

Result details




Figure 102
Measurement screen - Results page details

1.	Measurements and mileage	Displays the cumulative number of measurements and total conveyor mileage for the past week.
2.	Run time	Displays the total run time since the power was last turned on.
3.	List of conveyance results	Displays list of measurement results for the day.
4.	Exit	Tap to return to the measurement screen.

Maintenance settings



Figure 103
Measurement screen - Measurement screen details

1.	Maintenance settings	Tap to display maintenance items in the right side panel.
2.	Language	Tap to select desired language.
3.	Maintenance	Tap to access the maintenance mode.
4.	System info	Displays all firmware version and details.
5.	Exit	Tap to return to the measurement screen.

Maintenance mode



Maintenance mode details

User login

The following steps are for user login access:

1. From the **Measurement** screen, tap **[Settings]**.



Figure 104

Maintenance mode details - measurement screen

2. This will display the **Settings** screen. From here, other login options can be accessed through the **Maintenance** option.

Administrator (manager) login

The following steps are for administrator or manager login access:

1. With the **Settings** screen displayed, tap **[Maintenance]**.



Figure 105
Maintenance mode details - Settings screen

2. A pop-up Login window will appear. Check the box next to **Manager** by tapping it, then tap **[Login]**.



Figure 106
Maintenance mode details - Administrator login

3. The **Maintenance** screen for manger will now be displayed.



Figure 107
Maintenance mode details - Maintenance screen

Service engineer login

The following steps are for service engineer login access:

1. Access the **Login** window by tapping **[Maintenance]** at the **Settings** screen. Check the box next to **Maintenance** by tapping it. Then tap in the text field next to **Password**.



Figure 108
Maintenance mode details - Service engineer login

- The password key window will display. Enter the passcode **8715** by tapping the associated numbers in the key window. Then, tap **[Enter]**.




Figure 109
Maintenance mode details - Password key window

- This will return you to the **Login** window. From here, tap **[Login]** to finalize the login for service engineer.



Figure 110
Maintenance mode details - Passcode entered

- The **Maintenance** screen for service engineer will now be displayed.



Figure 111

Maintenance mode details - Service engineer maintenance

Exiting maintenance mode

With User login

The following steps are for exiting the maintenance mode with **User** login:

1. From the **Settings** screen, tap **[Exit]**.



Figure 112
Exiting maintenance mode - User login

2. This will return you to the **Measurement** screen.



Figure 113
Exiting maintenance mode - Measurement screen

With Administrator (manager) login

The following steps are for exiting the **Maintenance** mode with **Administrator** (manager) login:

1. From the **Settings** screen, tap **[Exit]**.



Figure 114
Exiting maintenance mode - Administrator login

2. A popup message will appear, prompting to “Finish setting”. Tap **[OK]** to continue.




Figure 115
Exiting maintenance mode - Finish setting

3. From the **Settings** screen, tap **[Exit]**. This will return you to the **Measurement** screen.

With Service engineer login

The following steps are for exiting the maintenance mode with **Service engineer** login:

1. From the **Settings** screen, tap **[Exit]**.



Figure 116
Exiting maintenance mode - Service engineer login

A popup message will appear, prompting “**Finish setting**”. A checkbox is available for logout. If **[OK]** is tapped without checking the box next to **Logout**, the **Maintenance** screen may be accessed again without a password during a 10 minute window. If more than 10 minutes transpire, you will be forced to log out.




Figure 117
Exiting maintenance mode - Logout

- To logout immediately, check the box next to **Logout** and tap [OK].




Figure 118

Exiting maintenance mode - Logout checked

- If changes have been made to the settings, the **Update** settings window will appear. If your settings require the user to register, input **teraoka** in the text box next to **Signature**. Then, tap [Update].



Figure 119

Exiting maintenance mode - Update register

4. If setting do not require user to register, no signature is need. Simply, tap **[Destruction]**. The register will be destroyed.



The screenshot shows a dialog box titled "Update settings". It contains the following fields and values:

Field	Value
Date	2021/10/19 18:40:42
Authority	Maintenance
Note	Recovery-Device setting
Signature	teraoka

At the bottom of the dialog, there are three buttons: "Update" (blue), "Destruction" (red), and "Cancel" (grey).

Figure 120
Exiting maintenance mode - Destroy register

5. After successfully logging out, the **Measurement** screen will appear.

Maintenance mode item details

Available selections for System info

The following options are available under **System Info**:

Version



Figure 121
System info selections- Version

The **Version** screen displays the most recently updated version of each program and library file currently running on the system. The following is a short description of each file:

N10: Communication control firmware

SH: Weighing measurement control firmware

FPGA (Main): N10-SH Communication control firmware

FPGA (Conveyor): Conveyor transfer control firmware

FPGA (Relay): PLC-7Seg-Emergency stop control firmware

FPGA (Display): Display control firmware

SH (DSP): A/D control firmware

SQDispAPP.exe: Conveyor control execution application

SQMesSrv.exe: Conveyor control execution application

IniFile.dll: Files for reading .ini files

SPK_Logging.dll: Files for log output

SPK_Mmlf.dll: Files to access shared memory

SQControlLib.dll: Screen design files.

SQComApp.exe: APP that outputs COM results

SQFtpDId.exe: APP that outputs FTP results

Digital DIO



Figure 122
System info selections - Digital DIO

The **Digital DIO** screen displays the status of each PLC terminal. When there is an input/output signal, the terminal displays red.

Condition




Figure 123
System info selections - Condition

The **Condition** screen displays a list of currently occurring errors.

Gate sensor




Figure 124
System info selections- Gate Sensor

The **Gate** sensor screen displays any errors due to defective parts associated with the gate sensor. The defective part of the gate sensor is displayed with a red line. If there are no defective parts, the red line will not be displayed.

Photo sensor




Figure 125

System info selections - Photo sensor

The **Photo** sensor screen displays any errors due to defective parts associated with the photo sensor. The defective part of the photo sensor is displayed with a red line. If there are no defective parts, the red line will not be displayed.

Scale




Figure 126
System info selections - Scale

The **Scale** screen displays the location where a scale error has occurred. Any scales with errors are highlighted in red.

Inverter



Figure 127
System info selections - Inverter

The **Inverter** screen displays the inverter status and error (alarm) occurrence status. Check the box next to the inverter **A** or **B** to check the

status of that inverter. When there is an input/output signal, the terminal displays red.

Available selections for Log

The following options are available under **Log**:

Measurement



Figure 128
Log selections - Measurement

The **Measurement** screen displays all measurement logs for a selected period. Use the down arrow next to the **Date** text field to select a date range. The data can be transferred to a prepared USB memory by tapping [Send data].

Mileage




Figure 129
Log selections - Mileage

The **Mileage** screen displays maintenance information to aid in the upkeep of the system. The following information is displayed:

Energizing time: Displays the cumulative time that the system has been active.

Transport distance: Displays the cumulative transfer distance of each conveyor (A and B).

Expected belt replacement date: Displays the estimated belt replacement dates for conveyor A and B.

Daily record: Displays the number of packages measured, run time, and A/B conveyor transport distance for each date.

text field to select a date range. The data for the chosen date can be transferred to a prepared USB memory drive by tapping [Save]. Alternatively, all data can be transferred to a prepare USB memory drive by tapping [Save all].

Display app.



Figure 132
Log selections - Display app.

The **Display app.** screen displays a list of measurements of the display app. program for a selected period. Like the **Control services**, the down arrow next to the **Date** text field allows for the selection of a date range. The data for the chosen date can also be transferred to a prepared USB memory drive by tapping [Save] or all data can be transferred by tapping [Save all].

Maintenance log (service engineer only)




Figure 133

Log selections - Maintenance log

The **Maintenance** log is a listed history of all changes made during maintenance. The data may be transferred to a prepared USB memory drive by tapping [Save].

Equipment test (available to admin/engineer)

The following options are available to administrator and service engineer logins under **Device testing**:

Sensor list



Figure 134

Device testing selections - Sensor list

The **Sensor list** selection displays the status of each sensor for the CS 200 SQ. The following describes each section of the **Sensor list** screen:

Gate sensor: Displays the horizontal and vertical status of the gate. If all gate sensors are ready to receive, **255-255** will display. If a gate sensor is blocked, the numbered range of the blocked sensor will display instead.

Gate cover: Displays the cover-on status for the gate both horizontally and vertically. If the cover is removed, the indicator will display open. If the cover is attached, the indicator will display closed.

Passenger sensor: The status of each passage sensor is displayed. If any of the passaged sensors are blocked, the respective indicator for that sensor will display red.

Motor speed: Displays the current transport speed of both conveyor A and conveyor B in units of **meters per minute**.

Mileage: Displays the cumulative transport distance of conveyor A and conveyor B in units of meters.

Temperature: Displays the average temperature of the **Main board** and **DSP board** in units of °C.

Scale: Displays the weight value of each of the scales in units of **grams**.

Scales



Figure 135

Device testing selections - Scales

The **Scales** screen displays the status of each scale for the CS 200 SQ. The current weight of each scale is displayed in units of **kilograms**. An **Enabled** option exists for each weight.

When the check box next to **Enabled** is unchecked, the scale value will not be reflected on the graph. Those scale weights that are enabled will be included in the graph.

Tap **[Zero]** to reset the scales to their zero value.

Gate sensor



Figure 136

Device testing selections - Gate sensor

The **Gate sensor** screen displays detailed information about the status of the gate sensor. The gate sensor indicators are detailed as follows:

When the red line is displayed, the gate sensor is blocked. The position of the red line indicates the position of the blocked sensor.

A displayed red square indicates the sensor board for the sensor that is blocked.

The numbers at the bottom of the screen correspond with the sensors along the gate. When a sensor is blocked, the corresponding sensor number will not appear in the list.

NOTE ➤

If the sensor number continues to appear in the list even when the corresponding sensor is blocked, the sensor can be determined to be defective.

The indicators may be placed in two different modes:

Normal mode: The red line indicator will be displayed in real time. It will only stay on as long as the sensor is blocked.

Latch mode: Unlike the indicator in Normal mode which is only on when the sensor is blocked, Latch mode allows the indicator to remain even after the sensor is no longer blocked. Once the sensor is blocked the red line indicator will turn on and will not toggle off until cleared.

By checking the box next to **Beep**, the system will emit an indicator sound when a sensor is blocked.

Photo sensor




Figure 137

Device testing selections - Photo sensor

The **Photo sensor** screen displays status of the passage sensors. Along the right panel under **Photosensor** are indicators for each of the passage sensors. When a sensor is unobstructed, the indicator displays **OFF**. When a sensor is blocked, the indicator displays **ON**.

Like the gate sensor the photo sensor indicators have two different modes:

Normal mode: The indicator will be displayed in real time. It will display **ON** as long as the sensor is blocked. When it is unobstructed it will return to displaying **OFF**.

Latch mode: When Latch mode is selected, the sensor will display **ON** when blocked and will remain in that state even when the sensor is no longer blocked. The sensor will not toggle off until cleared.

Motor encoder



Figure 138

Device testing selections - Motor encoder

The **Motor encoder** screen displays the test operation of the main motor for the conveyor. The following information is displayed:

Current speed: Displays the real time speed each conveyor (A and B) is displayed in units of meters per minute.

Conveyor operation: Displays conveyor operation controls used to adjust the speed and operation of each conveyor. The following controls are available:

- Check the box next to the conveyor to display the operation.
- Use the down arrow to select either forward motion of the conveyor (A → B) or reverse motion (B → A).
- Select the speed of the conveyor by tapping the corresponding button. Speeds range from **10 m/min** to **120 m/min**.
- Tap [**Stop**] to halt the conveyors and stop transfer.

Signal light



Figure 139
Device testing selections - Signal light

The **Signal light** screen displays the test operations of the indicator light. The following toggles are available to test the indicator light:

Red	Tap [Off] to turn off the red lamp.
	Tap [On] to turn on the red lamp in continuous mode.
	Tap [Blink] to turn on the red lamp in blinking mode.
Green	Tap [Off] to turn off the green lamp.
	Tap [On] to turn on the green lamp in continuous mode.
	Tap [Blink] to turn on the green lamp in blinking mode.
Buzzer	Tap [Off] to stop buzzer.
	Tap [On] to emit a continuous buzzer sound.

Corners conf.




Figure 140

Device testing selections - Corners conf.

The **Corners conf.** screen displays indicators and controls for testing the four corners and weight value of each scale. Perform the following steps when testing the scales:

1. Ensure the scales (A,B, and C) are free of objects. Tap **[Zero reset and next]**.
2. A message will appear prompting the placement location for the calibration weight. Place the weight where indicated, then tap **[Record]**.

NOTE >

Tap [Skip] at any time to skip measuring a location on the scale. A prompt will appear for the next location.

- After checking all items, tap **[Report]** to display a detailed list of all measurements from each of the scales.

Scale A						Scale B				
	1	2	3	4	5	6	7	8	9	10
0Kg						0.0	0.0	0.0	0.0	0.0
10Kg						10.0	10.0	10.0	10.0	10.0
20Kg						20.0	20.0	20.0	20.0	20.0
30Kg						30.0	30.0	30.0	30.0	30.0
40Kg						40.0	40.0	40.0	40.0	40.0
50Kg						50.0	50.0	50.0	50.0	50.0
40Kg						40.0	40.0	40.0	40.0	40.0
30Kg						30.0	30.0	30.0	30.0	30.0
20Kg						20.0	20.0	20.0	20.0	20.0
10Kg						10.0	10.0	10.0	10.0	10.0
0Kg						0.0	0.0	0.0	0.0	0.0

Scale C					
	1	2	3	9	10
0Kg	0.0	0.0	0.0	0.0	0.0
10Kg	10.0	10.0	10.0	10.0	10.0
20Kg	20.0	20.0	20.0	20.0	20.0
30Kg	30.0	30.0	30.0	30.0	30.0
40Kg	40.0	40.0	40.0	40.0	40.0
50Kg	50.0	50.0	50.0	50.0	50.0
40Kg	40.0	40.0	40.0	40.0	40.0
30Kg	30.0	30.0	30.0	30.0	30.0
20Kg	20.0	20.0	20.0	20.0	20.0
10Kg	10.0	10.0	10.0	10.0	10.0
0Kg	0.0	0.0	0.0	0.0	0.0

Figure 141
Device testing selections - List of measurements

Scanner




Figure 142
Device testing selections - Scanner

The **Scanner** screen displays time and data of any measurements taken by the scanner connected to the device whether hand scanner or fixed.

Device setting (available to admin/engineer)

The following options are available to administrator and service engineer logins under **Device setting**:

Display




Figure 143

Device setting selections - Display

The **Display** screen provides various setting options for the CS 200 SQ display interface. The following are the available settings:

Machine number: The machine number setting allows a numeric value between **1** and **99** to be assigned to the machine. If no number is set, the machine will default to **1**.

Measurement display: By tapping the down arrow, the measurement display may be set to either **Volume weight** or **Total dimension**.

Design: There are three design preferences that can be adjusted: **the background color, background image, or logo image.**

Background color: Tap [**Color**] to adjust the set background color for the display.

Background image: Tap [**Import**] to upload an image to display in the background. Images must be in a recognizable format with dimension of **1024x724 pixels.**

Logo image: Tap **[Import]** to upload an image to display as a logo in the display. Images must be in a recognizable format with dimension of **598x95 pixels**.

Scale warm-up time: At start up, the scales need time to warm up before accurate measurements may be taken. For this reason, the system provides a warm-up time before items are allowed to run. The default warm-up time is **480 seconds**, but a time value between **0 and 3600 seconds** can be set.

Conveyor start warning time: The conveyor start warning time sets the time at which the buzzer will sound, alerting everyone in the area that the machine is now in use. The default is **5 seconds**, but a value can be set between **0 and 60 seconds**.

Login passcode: The login passcode setting allows for a password to be set when logging in as an administrator. The default is a null value, but any passcode may be entered from **0 to 99999999**.

System reboot: The system reboot set a time at which the system will reboot.

Sound



Figure 144
Device setting selections - Sound

The **Sound** screen displays settings for sound. Use the adjustment bar to set the volume setting. Tap **[Test 1]** or **[Test 2]** to preview the indicator sound.

Conveyor



Figure 145

Device setting selections - Conveyor

The **Conveyor** screen provides settings for the conveyor. The following are the available settings:

Preset speed: The preset speed sets the transport speed of the conveyor in units of meters per minute. The default speed is **50 m/min**, but can be set to a value between **-160 m/min** and **160 m/min**.

Event to stop the conveyor: the event to stop the conveyor section provides a list of events that will result in an automatic stop of the conveyor. By checking the box next to the event, the system will automatically stop when the event is triggered. The default state for each event is unchecked.

The following stop event options are available:

System error: The conveyor stops when a system error occurs.

Measurement error: Conveyor stop will occur in the event of an error in measuring length.

Weighing error: Conveyor stop will occur in the event of an error in measuring weight.

Scanner error (receiving): If data received from the scanner is interrupted, the conveyor stops.

Scanner error (no read): If the scanner has an error that prevents it from reading the barcode, the conveyor stops.

Scanner error (multi read): If the scanner receives multiple reads, the conveyor stops.

Digital speed: With the Digital speed setting, the conveyor speed can be set for three states: **RH**, **RM**, and **RL**. If the signal for one of the three states is **ON**, the conveyor will transport at the corresponding speed. Each state can be set to a value between **-160 to 160 m/min**. By default the **RH**, **RM**, and **RL** states are set to **90**, **70**, and **45 m/min**, respectively.

Analog speed: With the analog setting, the conveyor speed can be set for the two analog input states: **0V** and **10V**. Each state can be set to a value between **-160 to 160 m/min**. By default the **0V** state is set to **30 m/min** and the **10V** state is set to **90 m/min**.

Motor acceleration/deceleration time: Start and stop time for the conveyor can be set by motor acceleration/deceleration time setting. The start and stop time can be set to a value between **0.5 to 10.0 seconds**. The default for both start and stop times is **6.0 seconds**.

Measuring



Figure 146
Device setting selections - Measuring

The **Measuring** screen provides settings for measuring and measurement outputs. The following are the available settings:

Enable error: The enable error setting displays a list of available error triggers. Set the desired trigger by checking the box next to the respective error. The following are the available error triggers:

Belt speed: An error is triggered when the transport speed fluctuates beyond acceptable values during operation. The belt speed error is active by default.

Non-cuboidal: An error is triggered if dimensions or weight measured varies by 25% above accepted values. The error is not active by default.

Enable protrusion check: An error is triggered when rubbing occurs on the conveyor. The error is active by default.

Enable gate cover sensor: An error is triggered if cover is not in place at start up. The error is active by default.

Timing for outputting measurement results: Tap ▾ to select one of three modes: rear output, output delay, and front output.

	Mode	Default	Value Range
0	Rear output	100 mm	0 to 9999 mm
1	Output delay	100 s	0 to 9999 s
2	Front output	2000mm	0 to 9999 mm

Units toggle: The units toggle allows for the setting of measuring units between Metric and Imperial with metric as default.

Minimum distance between box: The distance between one object and the next along the convey may be set with default set to 700 mm.

Scanner



Figure 147
Device setting selections - Scanner

The **Scanner** screen provides settings for the scanners that are connected to the system. Tap the down arrow (∇) to select a scanner to connect.

Selecting the Fixed tab will display the following setting options for a fixed scanner:

Selection	Setting options	Default setting
Baud rate (bps)	4800, 9600, 19200, 38400, 115200	115200
Data bit	7, 8	8
Sop bit	1, 2	1
Parity	even, odd, none	none
Flow control type	none, hardware, XON/XOFF	none
Minimum	-10,000 to 10,000	-1000
Maximum	-10,000 to 10,000	0

Selecting the Handy tab will display a scanner setting barcode with the option to enable a hand-held scanner. To enable the barcode check the box next to **Enable**.

Serial Port



Figure 148
Device setting selections - Serial port

To enable output of measurement result via the RS-232 serial port, check the box next to **Enabled**. The following options are available for output:

Selection	Setting options	Default setting
Baud rate (bps)	4800, 9600, 19200, 38400, 115200	115200
Data bit	7, 8	8
Sop bit	1, 2	1
Parity	even, odd, none	none
Flow control type	none, hardware, XON/XOFF	none

Clock



Figure 149

Device setting selections - Clock

From the **Clock** screen, the time and calendar setting may be set. Use the left and right arrows above the calendar to select a month. Highlight the day by tapping the date in the displayed calendar month. Use the **[+]** and **[-]** buttons to set the **Hour**, **Minute**, and **Second**. Once the time is entered correctly, tap **[Set]** to save settings.

FTP



Figure 150
Device setting selections - FTP

The FTP screen displays options for FTP transmission of data. The following settings are available:

Result upload: Enable FTP transmission of measured values.

Transmission interval: Use the [+] and [-] buttons to set the interval of transmissions in minute increments.

Address: Enter the IP Address of the connection destination in the text field.

File name: Enter the output file name in the text field.

User: Enter the user name for the FTP connection in the text field.

Password: Enter the password for the FTP connection in the text field.

Passive mode: Check the box to enable passive mode where available. The default setting is no check (active mode).

SSL mode: Check the box to enable active encryption.

Communication define file: Define the communication file by tapping the down arrow (∇) and selecting from the list.

TCP/IP



Figure 151

Device setting selections - TCP/IP

The TCP/IP screen displays option for TCP/IP transmission of data. The following settings are available:

Use DHCP: Check the box to enable Dynamic Host Configuration Protocol (DHCP) to automatically distribute IP address for transmission. If not enabled, a fixed user defined address will be used.

IP address: Use the [+] and [-] buttons to set the SQ IP address.

Mask: Use the [+] and [-] buttons to set the SQ subnet mask.

Gateway: Use the [+] and [-] buttons to set the SQ gateway.

Use DNS: Check the box to enable the use of Domain Name System (DNS) to translate domain names to IP addresses.

Apply setting now: Tap to apply current settings to system.

Recovery



Figure 152

Device setting selections - Recovery

The Recovery screen displays a history of setting changes. This screen can be used to recover previous settings and import/export settings. The following options are available:

Recovery: Select from the history of setting changes the settings you wish to recover. Tap **[Recovery]** to set selected changes from history as the new settings.

Import: Tap **[Import]** to upload setting from another system.

Export: Tap **[Export]** to send the selected setting values to a prepared USB memory.

Adjustment

The following selections are available to all logins under the **Adjustment** menu:

Span



Figure 153
Adjustment selections - Span

The **Span** screen displays settings for weight adjustment. The following options are available:

Select the adjustment method: Choose from 2-point adjustment (zero and span adjustment in one position) and 3-point adjustment (zero and span adjustment in two positions).

Specify the weight of the weight for span adjustment: When 2-point adjustment is selected, one weight must be set. When 3-point adjustment is selected, two weights must be set.

Choose the units by tapping the down arrow (∇). Use the [+] and [-] buttons to set the weight.

Please remove all baggage from the top of the scale: Ensure nothing is currently on the scale, then check the box next to "Confirm that nothing on the scale". Tap [Start the span adjustment] to begin adjustment.

Weight



Figure 154
Adjustment selections - Weight

The Weight screen displays measurement settings for weight data. Depending on the measurement system selected in **Device setting -> Measurement** (see “Measuring” on page 110). The following are options:

Rounding: Tap the down arrow (∇) to select the method for rounding values. Available options are **invalid**, **truncate**, **rounding**, and **round up**. The default is *rounding*.

Unit: Tap the down arrow (∇) to select the units for measurement. Available options are **g**, **kg**, and **lb**.

Multi-range: Use the **[+]** and **[-]** buttons to set weight ranges for measurements. The weight ranges can be set for **Scale (light)**, **Boundary**, and **Scale (heavy)**.

	Default (metric)	Default (Imperial)
Scale (light)	50 g	0.1 lb
Division	5000 g	10.0 lb
Scale (heavy)	100 g	0.2 lb

Maximum/Minimum: Use the [+] and [-] buttons to set maximum and minimum ranges for weight measurement.

	Default (metric)	Default (Imperial)
Minimum measured value	0 g	0.0 lb
Maximum measured value	50,000 g	110.0 lb

Tracking range: Use the [+] and [-] buttons to set the tracking range for weight measurement.

	Setting range	Default
Metric	0.1 to 10,000 g	25.0 g
Imperial	0.1 to 100.00 lb	0.05 lb

Volume weight: Use the [+] and [-] buttons to set the volume weight factor for weight measurement.

	Setting range	Default
Metric	1 to 10,000 g	6,000 g
Imperial	1 to 1,000 lb	138 lb

Action: Boxes may be checked to enable the actions **automatic rezero**, **“scale C when tracking, B is zero”**, and **do tracking**.

- **Automatic rezero:** If the target object is transported 20m and the gate sensor does not respond, it will automatically reset the scale to zero. The option is enabled by default.
- **Scales C tracking B zero:** When scale C is zero, scale B will automatically be set to zero. The option is enabled by default.
- **Enable tracking:** Set the scale to tracking. The option is enabled by default.

Weight moving average filter: Tap the down arrow (∇), to select the weight filter method used by the scales. Available options are **short span** (old method) and **long span** (new method). The default is *long span*.

Length




Figure 155
Adjustment selections - Length

The Length screen displays measurement settings for dimensioning data. Depending on the measurement system (metric or imperial) selected in **Device setting -> Measurement** (see "Measuring" on page 110). The following are options:

Rounding: Tap the down arrow (∇) to select the method for rounding values. Available options are **invalid**, **truncate**, **rounding**, and **round up**. The default is *rounding*.

Unit: Tap the down arrow (∇) to select the units for measurement. Available options are **mm**, **cm**, **m**, and **in**. The default is *mm* for metric and *in* for imperial.

Multi-range: Use the **[+]** and **[-]** buttons to set dimensioning ranges for measurements. The dimensioning ranges can be set for **Scale (short)**, **Division**, and **Scale (long)**.

	Default (metric)	Default (Imperial)
Scale (short)	5 mm	0.2 in
Division	2000 mm	70.0 in
Scale (long)	5 mm	0.2 in

Maximum/Minimum: Use the [+] and [-] buttons to set maximum and minimum ranges for dimensioning measurement.

	Default (metric)	Default (Imperial)
Minimum measured value (width)	100 mm	4.0 in
Maximum measured value (width)	900 mm	35.4 in
Minimum measured value (length)	150 mm	6.0 in
Maximum measured value (length)	1530 mm	60.0 in
Minimum measured value (height)	60 mm	2.4 in
Maximum measured value (height)	920 mm	36 in

Offset of the box size: Use the [+] and [-] buttons to set the desired universal offset for box size.

	Setting range	Default
width (metric)	-100.0 to 100.0 mm	0.0 mm
width (imperial)	-10.00 to 10.00 in	0.00 in
length (metric)	-100.0 to 100.0 mm	0.0 mm
length (imperial)	-10.00 to 10.00 in	0.00 in
height (metric)	-100.0 to 100.0 mm	0.0 mm
height (imperial)	-10.00 to 10.00 in	0.00 in

Conditional offset of box size: Offsets to box size may be set for specified conditions: **speed** and **length**.

Condition 1 creates a desired offset if the speed reaches or exceeds a set amount. Condition 2 creates a desired offset when target exceeds a set length. Check the box next to the condition you wish to enable.

	Setting range	Default
Condition 1 (metric)	0 to 160 m/min	100 m/min
Condition 1 (imperial)	0 to 450 ft/min	300 ft/min
Condition 2 (metric)	0 to 2000 mm	2000 mm
Condition 2 (imperial)	0 to 80.00 in	0.00 in

Use the [+] and [-] buttons to set the desired conditional offset for box size.

	Setting range	Default
width (metric)	-100.0 to 100.0 mm	0.0 mm
width (imperial)	-10.00 to 10.00 in	0.00 in
length (metric)	-100.0 to 100.0 mm	0.0 mm
length (imperial)	-10.00 to 10.00 in	0.00 in
height (metric)	-100.0 to 100.0 mm	0.0 mm
height (imperial)	-10.00 to 10.00 in	0.00 in

Conveyor



Figure 156
Adjustment selections - Conveyor

The Conveyor screen displays settings for adjusting conveyor controls. Adjustments can be made to the conveyor **motor speed ratio** and **encoder**.

Motor speed ratio adjustment: Use the [+] and [-] buttons to set the ratio of the speed output to the conveyor motor.

	Setting range	Default
Conveyor A	-100 to 100%	0.0%
Conveyor B	-100 to 100%	0.0%

Encoder adjustment: Use the [+] and [-] buttons to set the conveyor coefficient setting to be used to calculate the conveyor speed.

	Setting range	Default
Conveyor A	1 to 9999	1628
Conveyor B	1 to 9999	1628

Weight correction




Figure 157
Adjustment selections - Weight correction

The **Weight** screen provides options for the adjustment of weight measurements for specific weight ranges and conditions.

Weight: Use the [+] and [-] buttons next to each weight range to set weight correction for that weight range.

Temperature correction: Check the box next to “Enable temperature correction” to allow weight correction for different target weights.

Select the scale to adjust, then tap the down arrow (∇) to select a temperature. Available temperature options include: 0°C, 5°C, 10°C, 20°C, and 40°C.

- **Substrate temp:** Use the [+] and [-] buttons to set the thermistor detection temperature of the A/D control board at each temperature. The set temperature will determine the temperature compensation table to be used.
- **Basic adjust:** Use the [+] and [-] buttons to set the base correction value for each temperature.

- **Target weight:** Use the [+] and [-] buttons to select weight to be adjusted.
- **Adjust weight:** Use the [+] and [-] buttons to set weight adjustment for each target weight.

Device



Figure 158
Adjustment selections - Device

The **Device** screen displays settings to adjust the number of gate sensor boards for each scale.

Enable scale: Check the box next to **Enable scale** to select the scales you wish to adjust. By default, scales B and C are enabled.

Number of gates: Use the [+] and [-] buttons to set the number of vertical and horizontal gates. By default, each are set to 3 gates.

Recovery



Figure 159

Adjustment selections - Device

The **Recovery** screen displays the Maintenance setting history. This screen can be used to recover previous settings and import/export settings. The following options are available:

Recovery: Select from the Maintenance setting history the settings you wish to recover. Tap **[Recovery]** to set that as the new settings.

Import: Tap **[Import]** to upload setting from another system.

Export: Tap **[Export]** to send the selected setting values to a prepared USB memory drive.

Firmware



Figure 160
Adjustment selections - Firmware

The **Firmware** screen displays the current firmware installed on the 200 SQ and provides options for importing and deleting firmware files.

Import: Tap [**Import**] to generate a text file for the installation and displays it in the list.

Delete: Select the text file displayed in the list you wish to delete, then tap [**Delete**].

Update: Select the desired text file displayed in the list, then tap [**Update**] to update the firmware.

Display

Removing display from main unit

Complete the following steps to remove the display from the CS 200 SQ:

1. To disconnect the input connectors from the conveyor to the display, unplug **connectors A, B, and C** from the display as shown in the figure.




Figure 161
Removing display - Connector screws

2. **Connector A** is secured at two points on either side of the connector head by screws. Use a precision screwdriver to remove the screws and disconnect the cable.
3. Remove the **9 screws** on the back of the display. Once these screws are removed, the display can be removed from the main unit.




Figure 162
Removing display - Back of display

4. With the display removed from the main unit, the internal components of the display may be accessed, including: **the indicator board, touchscreen relay board, and mother board.**




Figure 163
Removing display - Display internals

Relay board

1. Remove the display from the main unit (see "Removing display from main unit" on page 128).
2. Peel off the filament tape connected to the touchscreen relay board. Do not throw away the tape as it will be reused with the new board.
3. Remove the 4 screws securing the relay board to the display, then turn it over.
4. Unplug the flat cable from the relay board.




Figure 164
Removing display - Relay board

Removing the touchscreen

Before removing the touchscreen, SHEET AA(DISP_15LCD) must be removed and cannot be reused. When replacing the touchscreen, be sure to order SHEET AA(DISP_15LCD) along with the touchscreen (part number: 41025908000100).

1. Disconnect the touchscreen relay board (see "Relay board" on page 130).
2. Peel off the surface sheet with the TERAOKA logo. This sheet will need to be replaced.

3. Remove the touch panel.



Figure 165
Removing display - Touchscreen removal

Removing indicator board

1. Remove the display from the main unit (see "Removing display from main unit" on page 128).
2. Disconnect the cable from the board.

3. Remove the 4 screws securing the board to the display, then remove board.




Figure 166
Removing display - Indicator board

Mother board

1. Remove the display from the main unit (see "Removing display from main unit" on page 128).

- Remove the **2 screws** shown in the figure, then turn the sheet metal over as illustrated in the figure:




Figure 167
Removing display - Mother board

- Carefully disconnect the **12 connectors** illustrated in the following figure:




Figure 168
Removing display - Motherboard connectors

4. Remove the **4 screws** at the four corners to remove the mother board from the display.
5. Remove the floating memory by spreading the pin in the direction shown in the figure.



Figure 169
Removing display - Removing memory

6. To remove the **SSD**, first remove the 2 screws securing it to the mother board. Once free, the SSD may be removed.



Figure 170
Removing display - Removing SSD

7. Install the SSD and memory in the new mother board.

Replacing LCD

1. Remove the display from the main unit (see "Removing display from main unit" on page 128).

2. Remove the touchscreen relay board (see "Relay board" on page 130).
3. Remove the 2 screws shown in the figure, then turn the sheet metal over as illustrated in the figure.




Figure 171
Removing display - Mother board removal

4. Remove the 4 screws at the four corners to remove the mother board from the display.

NOTE >

The cables and wires do not need to be removed from the mother board. Once the 4 screws are removed, it can be set aside so that the LCD may be accessed.

5. Peel off the **2 pieces of filament tape** securing the cables indicated in the figure. Do not throw the tape away as it will be reused.




Figure 172
Removing display - Removing motherboard from LCD

6. Disconnect the indicated cables from the back of the LCD and turn the mother board toward you. This will prevent cables from becoming entangled.

7. Remove the **4 screws** at each corner of the LCD, then remove the LCD and the sheet metal frame containing it from the display.




Figure 173
Removing display - Removing LCD and frame

8. Remove the **4 screws** that secure the LCD in the sheet metal frame.




Figure 174
Removing display - Separating LCD from frame

9. The LCD is now free from the display and can be replaced.



Figure 175
Removing display - LCD removed from sheet metal

Control box

Preparation before replacement

1. Pinch the knob on the power switch cover on the back of the main unit and pull it to open the cover. When you release the knob on the power switch cover the door will close automatically.




Figure 176
Control box - Main breaker

2. Toggle the main breaker to **OFF** to completely turn off the CS 200 SQ.



Figure 177
Control box - Main breaker

NOTE >

To stop everything but the transport of the conveyor, cut the power supply of each board and continue the conveyor movement. Weighing will not take place while the boards are powered off.

3. Remove the **7 screws** on the side panel.
4. Remove cover by gently lifting and pulling toward you.



Figure 178
Control box - Removing side panel



Figure 179
Control box - Removing side panel

5. To turn off the power to the main board, press the **SW1 button**. To turn off the power of the transfer board, press the **SW2 button**. When the

switch is toggled off, the red LED directly above the switch will turn off, indicating the power is off.




Figure 180
Control box - Board switches

Mother board

The control box contains the mother board and transport board. Before servicing the mother board, ensure the power is turned off to the control box (see "Preparation before replacement" on page 139). Perform the following steps to access and service the mother board:

1. Locate the control box under the gate on the back of the conveyor.

2. Remove the **7 screws** on the cover of the control box.



Figure 181
Control box - Removing control box cover

3. Gently lift and pull the cover to remove.
4. The main board is on the left side. When the LED is lit, the main board is energized.




Figure 182
Control box - Motherboard

5. Remove the **11 connectors** indicated in the figure.

NOTE >

When replacing the board, be sure to remove the MicroSD card attached to the original board and attach it to the main board after replacement.

6. Remove the main board after removing the **4 screws** at the four corners.




Figure 183
Control box - Removing motherboard

Transport board

Before servicing the transport board, ensure the power is turned off to the control box (see "Preparation before replacement" on page 139). Perform the following steps to access and service the transport board:

1. There is a control box under the gate on the back.

2. Remove the 7 **screws** securing the cover.



Figure 184
Control box - Removing control box cover

3. Gently lift and pull cover to remove.
4. The transport board is on the right side of the control box. When the LED is lit, the main board is energized.




Figure 185
Control box - Transport board

5. Remove the connectors indicated by the figure.

6. Remove the transport board after removing the **4 screws** at the corners of the board.




Figure 186
Control box - Removing transport board

A/D Box

Preparation before replacement

1. Pinch the knob on the power switch cover on the back of the main unit and pull it to open the cover. When you release the knob on the power switch cover the door will close automatically.




Figure 187
A/D BOX - Main breaker cover

2. Toggle the main breaker to **OFF** to completely turn off the CS 200 SQ.



Figure 188
A/D BOX - Main breaker

NOTE >

To stop everything but the transport of the conveyor, cut the power supply of each board and continue the conveyor movement. Weighing will not take place while the boards are powered off.

3. Remove the **7 screws** on the side panel.
4. Remove cover by gently lifting and pulling toward you.




Figure 189
A/D BOX - Removing side panel

5. To turn off the power to the **A/D board**, press the **SW1 button**. When the switch is toggled off, the red LED directly above the switch will turn off, indicating the power is off.




Figure 190
A/D BOX - Board switches

Accessing A/D BOX

The A/D BOX contains an A/D board and an A/D control board. Before servicing the A/D BOX, ensure the power is turned off (see "Preparation before replacement" on page 146). Perform the following steps to access and service the components of the A/D Box:

1. Open the power box cover housing the A/D BOX.
2. Remove the **4 screws** securing the sheet metal covering on the right side of the A/D BOX and slide the sheet metal out.




Figure 191
A/D BOX - Right side cover

3. Remove the **2 hexagonal cap screws** at the bottom right of the A/D BOX as indicated in the figure.




Figure 192
A/D BOX - Right side hexagonal screws

4. Remove the **4 screws** securing the sheet metal on the left side of the A/D Box and slide out the sheet metal.




Figure 193
A/D BOX - Left side cover

5. Remove the 2 hexagonal cap screws at the bottom left as indicated in the figure.




Figure 194
A/D BOX- Left side hexagonal screws

6. Lift the power supply box up slightly and tilt the A/D BOX toward you.



Figure 195
A/D BOX - Removing A/D BOX

7. Remove the **2 UL clamps** on the right side of the A/D BOX as indicated in the figure. This will free the wires on the back of the A/D BOX.




Figure 196
A/D BOX - UL clamps

8. Remove the **4 hexagonal cap screws** on the sides of the A/D BOX. This will allow the A/D BOX to move freely.




Figure 197
A/D BOX - Side screws

- Carefully remove the A/D BOX, pulling it slowly toward you.



Figure 198
A/D BOX - Removing box

- Remove the 4 screws securing the upper cover of the A/D BOX, then slide the cover off.




Figure 199
A/D BOX - Cover

11. Slide cover off to reveal AD board.



Figure 200
A/D BOX - A/D box cover removed

A/D board replacement

Before performing replacement work for the A/D board, ensure the power has been toggled off (see "Preparation before replacement" on page 146) and remove the A/D BOX for easy access (see "Accessing A/D BOX" on page 148). Complete the following steps to replace the A/D board:

1. The A/D board for scale B and C are secured with **2 screws** each.

2. Remove these screws along with the **4 screws** at the bottom of the board to detach the A/D board from the sheet metal frame.




Figure 201
A/D BOX - A/D Board

3. Disconnect the cable indicated in the figure and remove the indicated load cell wires soldered to the board. The board can now be removed.




Figure 202
A/D BOX - Removing A/D board

A/D control board

Before performing replacement work for the A/D control board, ensure the power has been toggled off (see "Preparation before replacement" on page 146) and remove the A/D BOX for easy access (see "Accessing A/D BOX" on page 148). Complete the following steps to replace the A/D control board:

1. Remove the **2 screws** on either side of the A/D Box to free it from the sheet metal frame.
2. Turn the box over to expose the backside.




Figure 203
A/D BOX - Control board

3. Remove the **6 screws** securing the control board to the A/D BOX and disconnect the **8 connectors** as indicated in the figure.




Figure 204
A/D BOX - Removing control board

4. The control box may now be replaced.

Gate sensor board

Bottom gate (receiver)

The receiving side of the gate consists of three sensor boards. These sensors receive light emitted by the upper gate. Together with the side gates, the sensor data obtained determines the dimensions of an object in 3-dimensional space. When servicing the sensor(s), only remove the board(s) being serviced.

1. Lift up the handle of the lower gate cover.

2. Pull the cover toward you and remove it.




Figure 205
Gate sensor board - Accessing boards (bottom gate)

3. To remove the front and back covers, remove the **8 screws** securing each cover.




Figure 206
Gate sensor board - Removing covers (bottom gate)

4. Remove the 2 hexagonal cap screws on the front and back side.




Figure 207
Gate sensor board - Cap screws (bottom gate)

5. Remove the connector on the front side as shown in the figure.




Figure 208
Gate sensor board - Gate connector (bottom gate)

6. Lift the gate sensor unit slightly and pull out to remove.




Figure 209
Gate sensor board - Removing gate (bottom gate)

7. Remove the acrylic covering from the gate sensor. Then, lift out the sensor.




Figure 210
Gate sensor board - Removing gate (bottom gate)

NOTE > The gate sensor consists of three boards. Only remove the board(s) that require(s) servicing.

8. To replace the gate sensor board, remove the **4 screws** securing the blinker to the board.



Figure 211
Gate sensor board - Gate blinker (bottom gate)

9. Remove the **4 hexagonal column head screws** to detach the board.



Figure 212
Gate sensor board - Column head screws (bottom gate)

10. Turn over the board to reveal the connection underneath. Disconnect the connectors as indicated in the figure to remove board.




Figure 213
Gate sensor board - Board connectors (bottom gate)

11. When installing new board, set **DipSW2** according to the placement of the board as follows:

Board Placement	SW1	SW2	SW3	SW4
Back side	OFF	OFF	ON	OFF
Center	OFF	ON	OFF	OFF
Front side	OFF	OFF	OFF	OFF




Figure 214
Gate sensor board - Dip SW2

Gate side (receiving)

The receiving side of the gate consists of three sensor boards. These sensors receive light emitted by the opposite side gate. Together with the top and bottom gates, the sensor data obtained determines the dimensions of an object in 3-dimensional space. When servicing the sensor(s), only remove the board(s) being serviced.

1. Remove the **8 screws** on the receiving side of the main unit.




Figure 215
Gate sensor board - Side cover (receiving)

2. Remove the **8 screws** along the receiving side of the gate. Slide to remove cover, exposing the sensor boards.



Figure 216
Gate sensor board - Sensor boards (receiving)

3. Remove the **4 screws** at each corner of the board to be serviced.

- Turn board over to detach the connectors and remove board. The center and lower boards have two connectors.




Figure 217
Gate sensor board - Board removal (receiving)

- When installing the new board, set **DipSW2** according to the placement of the board as follows:

Board Placement	SW1	SW2	SW3	SW4
Upper	OFF	OFF	ON	OFF
Center	OFF	ON	OFF	OFF
Lower	OFF	OFF	OFF	OFF




Figure 218
Gate sensor board - Dip SW2 (receiving)

Gate side (emitting)

The emitting side of the gate consists of three light emitting boards. These boards emit light that will be received by the opposite side gate. Together

with the top and bottom gates, the sensor data obtained determines the dimensions of an object in 3-dimensional space. When servicing the sensor(s), only remove the board(s) being serviced.

1. Remove the **8 screws** on the emitting side of the main unit.




Figure 219
Gate sensor board - Side cover (emitting)

2. Remove the **8 screws** along the emitting side of the gate. Slide to remove cover, exposing the sensor boards.




Figure 220
Gate sensor board - Sensor boards (emitting)

3. Remove the **4 screws** at each corner of the board to be serviced.
4. Turn board over to detach the connectors and remove. The upper board has one connector. The center and lower boards have two connectors.




Figure 221

Gate sensor board - Board removal (emitting)

5. When installing new board, set **Dip SW2** according to the placement of the board as follows:

Board Placement	Level 1	Level 2	Level 3	Level 4
SW1	OFF	OFF	OFF	OFF
SW2	OFF	OFF	ON	ON
SW3	OFF	ON	OFF	ON
SW4	ON - master/ OFF - slave			




Figure 222

Gate sensor board - Dip SW2 (emitting)

Upper gate (emitting)

The upper gate consists of three light emitting boards. These boards emit light that will be received by the bottom gate. Together with the side gates, the sensor data obtained determines the dimensions of an object in 3-dimensional space. When servicing the sensor(s), only remove the board(s) being serviced.

1. Remove the **8 screws** along the top of the upper gate, then gently take off cover.



Figure 223

Gate sensor board - Cover screws (upper gate)

2. Disconnect the connectors for the board you are servicing. The backside board has one connector. The center and front boards have two connectors.

- Remove the **4 screws** at each corner of the board and replace with new board.




Figure 224
Gate sensor board - Connectors (upper gate)

- When installing new board, set **Dip SW2** according to the placement of the board as follows:

Board Placement	Level 1	Level 2	Level 3	Level 4
SW1	OFF	OFF	OFF	OFF
SW2	OFF	OFF	ON	ON
SW3	OFF	ON	OFF	ON
SW4	ON - master on front board/ OFF - slave on center and back board			



Figure 225
Gate sensor board - Dip SW2 (upper gate)

Passage sensor board

Along both **conveyor A** and **convey B**, a series of sensors are positioned on either side to detect the presence of an object. One side contains emitter boards and the other contains receiver boards. These make up the passage sensors.

Conveyor A emitter

Conveyor A contains two types of emitters: **TPB-3863 (small)** and **TPB-3865 (large)**. Complete the following steps to service the emitter boards for conveyor A:

1. Remove the **3 screws** along the top of the emitter side rail of conveyor A, then remove cover.




Figure 226
Conveyor A emitter - Cover screws

2. Remove the **3 screws** on the top side and the **2 screws** at the side of the inner rail component. Gently remove the cover.

- Both the **TPB-3865 (large)** and **TPB-3863 (small)** board will be exposed. Each board requires its own procedure to remove.




Figure 227
Conveyor A emitter - Exposed boards

- Remove the **4 screws** securing the sheet metal frame to the main unit as indicated in the figure.
- Tilt the sheet metal up to gain better access to the boards.




Figure 228
Conveyor A emitter - Accessing boards

Removing the TPB-3863 (small) board

1. When servicing the TPB-3863 (small) board, remove the connector indicated in the figure.



Figure 229

Conveyor A emitter - TPB-3863 (small) board

2. Remove the **4 screws** at each corner of the board to detach the board from the sheet metal frame.
3. Replace with new board.

Replacing the TPB-3865 (large) board

1. When servicing the TPB-3865 (large) board, remove the **2 connectors** indicated in the figure.
2. Remove the **8 screws** securing the board to the sheet metal frame.




Figure 230

Conveyor A emitter - TPB-3865 (large) board

- Before replacing the board, set **SW1** on the new board. The **SW1** setting differs depending on the installation location. Set the switch on the left side (**SENS-2, 3, 4, 5**).




Figure 231
Conveyor A emitter - SW1

Conveyor B emitter

Conveyor B contains two types of emitters: TPB-3863 (small) and TPB-3865 (large). Complete the following steps to service the emitter boards for conveyor B:

1. Remove the **4 screws** along the top of the emitter side rail of conveyor B. Then, remove cover.




Figure 232
Conveyor B emitter - Cover screws

2. Remove the **5 screws** on the top side and the **4 screws** at the side of the inner rail component. Gently remove the cover.
3. Boards left **TPB-3865 (large)**, right **TPB-3865 (large)** and **TPB-3863 (small)** boards will be exposed. Each board requires its own procedure to remove.



Figure 233
Conveyor B emitter - Exposed boards

4. Remove the **5 screws** securing the sheet metal frame to the main unit as indicated in the figure.

5. Tilt the sheet metal up to gain better access to the boards.




Figure 234
Conveyor B emitter - Accessing boards

Removing the TPB-3863 (small) board

1. When servicing the TPB-3863 (small) board, remove the connector indicated in the figure.




Figure 235
Conveyor B emitter - TPB-3863 (small) board

2. Remove the 4 screws at each corner of the board to detach the board from the sheet metal frame.
3. Replace with new board.

Replacing the left TPB-3865 (large) board

1. When servicing the left TPB-3865 (large) board, remove the 2 connectors indicated in the figure.

- Remove the **8 screws** securing the board to the sheet metal frame.



Figure 236
Conveyor B emitter - Left TPB-3865 (large) board

- Before replacing the board, set **SW1** on the new board. The **SW1** setting differs depending on the installation location. Set the switch on the right side (**SENS-6,7**).




Figure 237
Conveyor B emitter - SW1 (SENS - 6, 7)

Replacing the right TPB-3865 (large) board

- When servicing the TPB-3865 (large) board, remove the **2 connectors** indicated in the figure.

- Remove the **8 screws** securing the board to the sheet metal frame.



Figure 238
Conveyor B emitter - Right TPB-3865 (large) board

- Before replacing the board, set **SW1** on the new board. The **SW1** setting differs depending on the installation location. Set the switch on the left side (**SENS-2, 3, 4, 5**).




Figure 239
Conveyor B emitter - SW1 (SENS-2, 3, 4, 5)

Conveyor A receiver

Conveyor A contains two types of receivers: **TPB-3864 (small)** and **TPB-3866 (large)**. Complete the following steps to service the boards for conveyor A:

1. Remove the **3 screws** along the top of the receiver side rail of conveyor A. Then, remove cover.




Figure 240
Conveyor A receiver - Cover screws

2. Remove the **2 screws** on the upper side and the **2 screws** at the side of cover next to gate.
3. Remove the **2 hexagonal cap screws** indicated in the figure and remove the cover next to the gate.




Figure 241
Conveyor A receiver - Hexagonal cap screws

4. Remove the **3 screws** on the top side and the **2 screws** at the side of the inner rail component. Gently remove the cover.
5. Both the **TPB-3866 (large)** and **TPB-3864 (small) board** will be exposed. Each board requires its own procedure to remove.




Figure 242
Conveyor A receiver - Exposed boards

6. Remove the **4 screws** securing the sheet metal frame to the main unit as indicated in the figure.
7. Tilt the sheet metal up to gain better access to the boards.



Figure 243
Conveyor A receiver - Accessing boards

Removing the TPB-3864 (small) board

1. When servicing the **TPB-3863 (small) board**, remove the connector indicated in the figure.

2. Remove the **4 screws** at each corner of the board to detach the board from the sheet metal frame.



Figure 244
Conveyor A receiver - TPB-3864 (small) board

3. Replace with new board.

Replacing the TPB-3866 (large) board

1. When servicing the **TPB-3866 (large) board**, remove the **2 connectors** indicated in the figure.
2. Remove the **10 screws** securing the board to the sheet metal frame.




Figure 245
Conveyor A receiver - TPB-3866 (large) board

- Before replacing the board, set **SW5** on the new board. The **SW5** setting differs depending on the installation location. Set the switch on the left side (**SENS-2, 3, 4, 5**).




Figure 246
Conveyor A receiver - SW5 (SENS-2, 3, 4, 5)

Conveyor B receiver

Conveyor B contains two types of receivers: **TPB-3864 (small)** and **TPB-3866 (large)**. Complete the following steps to service the boards for conveyor B:

1. Remove the **4 screws** along the top of the receiver side rail of conveyor B, then remove cover.




Figure 247
Conveyor B receiver - Cover screws

2. Remove the **2 screws** on the upper side and the **2 screws** at the side of cover next to gate.
3. Remove the **2 hexagonal cap screws** indicated in the figure. Then, remove the cover next to the gate.




Figure 248
Conveyor B receiver - Hexagonal cap screws

4. Remove the **5 screws** on the top side and the **4 screws** at the side of the inner rail component. Gently remove the cover.
5. Boards left **TPB-3866 (large)**, right **TPB-3866 (large)** and **TPB-3864 (small) boards** will be exposed. Each board requires its own procedure to remove.




Figure 249
Conveyor B receiver - Exposed boards

6. Remove the **5 screws** securing the sheet metal frame to the main unit as indicated in the figure.
7. Tilt the sheet metal up to gain better access to the boards.




Figure 250
Conveyor B receiver - Accessing boards

Removing the TPB-3864 (small) board

1. When servicing the **TPB-3864 (small) board**, remove the connector indicated in the figure.

2. Remove the **4 screws** at each corner of the board to detach the board from the sheet metal frame.




Figure 251
Conveyor B receiver - TPB-3864 (small) board

3. Replace with new board.

Replacing the right TPB-3866 (large) board

1. When servicing the left TPB-3866 (large) board, remove the **2 connectors** indicated in the figure.
2. Remove the **10 screws** securing the board to the sheet metal frame.




Figure 252
Conveyor B emitter - Right TPB-3866 (large) board

- Before replacing the board, set **SW5** on the new board. The **SW5** setting differs depending on the installation location. Set the switch on the right side (**SENS-6,7**).




Figure 253
Conveyor B receiver - SW5 (SNS - 6, 7)

Replacing the left TPB-3866 (large) board

- When servicing the TPB-3866 (large) board, remove the 2 connectors indicated in the figure.
- Remove the 10 screws securing the board to the sheet metal frame.



Figure 254
Conveyor B emitter - Left TPB-3866 (large) board

3. Before replacing the board, set **SW5** on the new board. The **SW5** setting differs depending on the installation location. Set the switch on the left side (**SENS-2, 3, 4, 5**).




Figure 255
Conveyor B emitter - SW5 (SENS-2, 3, 4, 5)

Inverter



1. Remove the **5 screws** securing the cover for the conveyor's inverter and gently lift and pull off cover.



Figure 256
Inverter - Cover screws

2. Remove the 2 hexagonal cap screws that secure the inverters to the sheet metal frame.




Figure 257
Inverter - Cover removed

3. Detach the inverter and sheet metal frame from the main unit.




Figure 258
Inverter - Removing inverter

NOTE >

Once the inverter is detached from the main unit, the removal procedure is the same for both conveyors A and B.

4. Open the inverter cover and disconnect the communication cable.



Figure 259
Inverter - Cable

5. Loosen the screws on the 5 terminals CC, F, R, S1, and S2.
6. Pull out each wire.




Figure 260
Inverter - Terminals

NOTE >

Each wire is labeled according to its corresponding terminal and the conveyor it connects to, i.e. "CC A" connects to terminal CC of conveyor A.

7. Insert the driver into the hole at the bottom of the inverter, indicated in the figure.

8. Slide to remove the cover, revealing connector terminals.




Figure 261
Inverter - Revealing bottom terminals

9. Remove the 3 screws along the sheet metal to disconnect the wires as indicated in the figure.




Figure 262
Inverter - Sheet metal screws

10. Push cover as shown in the figure and remove by lifting it diagonally upward. Three more terminals marked with blue will be revealed.

11. Remove the **6 screws** holding the red and blue wires in place.




Figure 263
Inverter - Connections revealed

12. Remove the **2 hexagonal cap screws** on the upper left and lower right of the inverter as indicated in the figure. This will free the inverter from the sheet metal.



Figure 264
Inverter - Removing frame

Drive belt

Conveyor A drive belt

The drive belt for conveyor A is located on the receiving side of the CS 200 SQ. Complete the following steps to remove the drive belt for servicing.

1. Remove the **2 screws** on the upper side and the **2 screws** at the side of the cover next to gate.
2. Remove the **2 hexagonal cap screws** indicated in the figure. Then, remove the cover next to the gate.




Figure 265
Conveyor A drive belt - Cover screws

3. Remove the main motor pulley cover.
4. Remove the **3 hexagonal cap screws** on the left side of the motor pulley cover and the **2 hexagonal cap screws** on the top.

5. Gently, pull off cover revealing the motor pulley system.




Figure 266
Conveyor A drive belt - Motor pulley cover

6. Remove the 2 hexagonal cap screws securing the sheet metal frame for the encoder.




Figure 267
Conveyor A drive belt - Encoder

7. Carefully, pull the encoder and sheet metal frame away from the main unit. The main motor will now be exposed.

8. Mark the position of the main motor mount with a marker. It is important to indicate this position, so the motor can be repositioned correctly after belt replacement.




Figure 268
Conveyor A drive belt - Main motor

9. There are **4 sheet metal bolts** securing the motor to the main unit. Loosen the **2 bolts** on the left side by making **4 to 5 turns**.




Figure 269
Conveyor A drive belt - Left mount bolts

10. After loosening the left mount bolts, loosen the right mount bolts by making **4 to 5 turns**.




Figure 270
Conveyor A drive belt - Right mount bolts

11. Slide the motor to the right along with the marked sheet metal.




Figure 271
Conveyor A drive belt - Sliding motor

12. Carefully, pull the belt from the motor pulley and rollers, sliding it away from the main unit. Once free, the belt may be serviced or replaced.




Figure 272
Conveyor A drive belt - Removing belt

Conveyor B drive belt

The drive belt for conveyor B is located on the receiving side of the CS 200 SQ. Complete the following steps to remove the drive belt for servicing.

1. Remove the **2 screws** on the upper side and the **2 screws** at the side of cover next to gate.
2. Remove the **2 hexagonal cap screws** indicated in the figure and remove the cover next to the gate.




Figure 273
Conveyor B drive belt - Cover screws

3. Remove the main motor pulley cover.
4. Remove the **3 hexagonal cap screws** on the right side of the motor pulley cover and the **2 hexagonal cap screws** on the top.

5. Gently, pull off cover revealing the motor pulley system.




Figure 274
Conveyor B drive belt - Motor pulley cover

6. Remove the **2 hexagonal cap screws** securing the sheet metal frame for the encoder.

7. Carefully, pull the encoder and sheet metal frame away from the main unit. The main motor will now be exposed.




Figure 275
Conveyor B drive belt - Encoder

8. Mark the position of the main motor mount with a marker. It is important to indicate this position, so the motor can be repositioned correctly after belt replacement.




Figure 276
Conveyor B drive belt - Main motor

9. There are **4 sheet metal bolts** securing the motor to the main unit. Loosen the **2 bolts** on the right side by making **4 to 5 turns**.




Figure 277
Conveyor B drive belt - Left mount bolts

10. After loosening the right mount bolts, loosen the **2 left mount bolts** by making **4 to 5 turns**.




Figure 278
Conveyor B drive belt - Right mount bolts

11. Slide the motor to the left along with the marked sheet metal.




Figure 279
Conveyor B drive belt - Sliding motor

12. Carefully, pull the belt from the motor pulley and rollers, sliding it away from the main unit. Once free, the belt may be serviced or replaced.




Figure 280
Conveyor B drive belt - Removing belt

Main motor

Conveyor A main motor

The main motor is located within the main motor pulley system. To remove the main motor, first remove the encoder and belt for conveyor A (see "Conveyor A drive belt" on page 192).

NOTE > *Even though the belt is not being replaced, it is still important to mark the position of main motor mount before removing the belt. These markings will be used when the belt is reattached following motor servicing.*

1. Before pulling out the main motor, unplug the connector as shown in the figure.
2. Tilt the front facing side of the main motor slightly upward, then pull together with the sheet metal frame to remove it.




Figure 281
Conveyor A motor - Removing motor

3. Remove the motor connector from the sheet metal frame by holding the side pins of the receiving end of the connector with pliers while pulling through the frame.




Figure 282
Conveyor A motor - Removing connector (receiving end)

4. Detach the rest of the connector from the sheet metal frame by loosening the plastic clamp securing it.
5. Remove the **hexagonal cap screw** securing the ground wire to the sheet metal frame.




Figure 283
Conveyor A motor - Removing connector

6. Remove the 4 **hexagonal bolts** securing the main motor to sheet metal frame.




Figure 284
Conveyor A motor - Hexagonal bolts

7. Remove main motor for servicing or replacement.

Conveyor B main motor

The main motor is located within the main motor pulley system. To remove the main motor, first remove the encoder and belt for conveyor B (see "Conveyor B drive belt" on page 197).

NOTE >

Even though the belt is not being replaced, it is still important to mark the position of main motor mount before removing the belt. These markings will be used when the belt is reattached following motor servicing.

1. Before pulling out the main motor, unplug the connector as shown in the figure.

2. Tilt the front facing side of the main motor slightly upward, then pull together with the sheet metal frame to remove it.




Figure 285
Conveyor B motor - Removing motor

3. Remove the motor connector from the sheet metal frame by holding the side pins of the receiving end of the connector with pliers while pulling through the frame.




Figure 286
Conveyor B motor - Removing connector (receiving end)

4. Detach the rest of the connector from the sheet metal frame by loosening the plastic clamp securing the connector.
5. Remove the **hexagonal cap screw** securing the ground wire to the sheet metal frame.




Figure 287
Conveyor B motor - Removing connector

6. Remove the 4 **hexagonal bolts** securing the main motor to sheet metal frame.




Figure 288
Conveyor B motor - Hexagonal bolts

7. Remove main motor for servicing or replacement.

Roller/ transport belt

Conveyor A driven roller

1. Remove the **6 screws** and pull off the cover.




Figure 289
Conveyor A driven roller - Cover screws

2. Remove the guide on the back side of the main unit by removing the 3 hexagonal cap screws.




Figure 290
Conveyor A driven roller - Removing guide (back side)

3. Remove the guide on the front side of the main unit by removing the 3 hexagonal cap screws.




Figure 291
Conveyor A driven roller - Removing guide (front side)

4. Use sticker/tape and pen to mark the position of each adjuster as illustrated in the figure.




Figure 292
Conveyor A driven roller - Marking adjustment

5. Loosen the 4 hexagonal screws that secure each adjuster (8 screws in total).




Figure 293
Conveyor A driven roller - Loosening adjusters

6. Loosen the hexagonal nut that secures the frame to the position of the bolt head.
7. To loosen belt tension, tighten the hexagonal bolt near the adjuster by turning it in the direction indicated by the arrow in the figure.




Figure 294
Conveyor A driven roller - Loosen belt tension

8. Remove each adjuster by removing the 4 loosened hexagonal screws.

9. Lift the driven roller up and pull toward the side as depicted in the figure.




Figure 295
Conveyor A driven roller - Removing roller

10. The driven roller is now free to be serviced or replaced.

Conveyor A drive roller

1. Remove the driven roller (see "Conveyor A driven roller" on page 208).
2. Remove the drive roller belt (see "Conveyor A drive belt" on page 192).

3. Remove the **8 screws** and remove the back cover.




Figure 296
Conveyor A roller - Removing back cover

4. Loosen the **2 immobilizers** and pull out the pulley from the roller.
5. Pinch the key attached to the roller with pliers and remove.




Figure 297
Conveyor A roller - Removing pulley

6. Remove the 4 hexagonal screws at each end of the bearing unit and remove unit.




Figure 298
Conveyor A roller - Bearing unit

7. Lift the drive roller and pull to remove it as indicated in the figure.




Figure 299
Conveyor A roller - Removing drive roller

Conveyor A transport belt

1. Remove the driven roller (see "Conveyor A driven roller" on page 208).
2. Remove the drive roller (see "Conveyor A drive roller" on page 212).

3. Remove the 4 hexagonal screws that secure the top plate.




Figure 300
Conveyor A Transport belt - Removing top plate

4. Lift one side of conveyor and pull transport belt to remove.




Figure 301
Conveyor A Transport belt - Removing transport belt

5. After removing the transport belt, gently set top plate back in place.

Conveyor B driven roller

1. Remove the **8 screws** and pull off the cover.




Figure 302
Conveyor B driven roller - Cover screws

2. Remove the guide on the back side of the main unit by removing the **6 hexagonal cap screws**.




Figure 303
Conveyor B driven roller - Removing guide (back side)

3. Remove the guide on the front side of the main unit by removing the 6 hexagonal cap screws.




Figure 304
Conveyor B driven roller - Removing guide (front side)

4. Use sticker/tape and pen to mark the position of each adjuster as illustrated in the figure.




Figure 305
Conveyor B driven roller - Marking adjustment

5. Loosen the 4 hexagonal screws that secure each adjuster (8 screws in total).




Figure 306
Conveyor B driven roller - Loosening adjusters

6. Loosen the hexagonal nut that secures the frame to the position of the bolt head.

7. To loosen belt tension, tighten the hexagonal bolt near the adjuster by turning it as shown in the figure.




Figure 307
Conveyor B driven roller - Loosen belt tension

8. Remove each adjuster by removing the 4 loosened hexagonal screws.

9. Lift the driven roller up and pull toward the side as depicted in the figure.




Figure 308
Conveyor B driven roller - Removing roller

10. The driven roller is now free to be serviced or replaced.

Conveyor B drive roller

1. Remove the driven roller (see "Conveyor B driven roller" on page 218).
2. Remove the drive roller belt (see "Conveyor B drive belt" on page 197).

3. Remove the **8 screws** and remove the back cover.




Figure 309
Conveyor B drive roller - Removing back cover

4. Loosen the **2 immobilizers** and pull out the pulley from the roller.




Figure 310
Conveyor B drive roller - Loosening immobilizers

5. Pinch the key attached to the roller with pliers and remove.




Figure 311
Conveyor B drive roller - Removing pulley

6. Remove the 4 hexagonal screws at each end of the bearing unit and remove unit.




Figure 312
Conveyor B drive roller - Bearing unit

7. Lift the drive roller and pull to remove it as indicated in the figure.




Figure 313
Conveyor B drive roller - Removing drive roller

Conveyor B transport belt

1. Remove the driven roller (see "Conveyor B driven roller" on page 218).
2. Remove the drive roller belt (see "Conveyor B drive belt" on page 197).
3. Remove the 4 **hexagonal screws** that secure the top plate.




Figure 314
Conveyor B Transport belt - Removing top plate

4. Lift one side of conveyor and pull transport belt to remove.




Figure 315
Conveyor B Transport belt - Removing transport belt

5. After removing the transport belt, gently set top plate back in place.

CHAPTER 5 BOARDS & PARTS

Block diagram

Display




Figure 316
Block diagram - Display

Inverter




Figure 317
Block diagram - Inverter

Power supply




Figure 318
Block diagram - Power supply

Main unit




Figure 319
Block diagram - Main unit

Boards



Main board: TPB-3850




Figure 320
Boards- Main board (TPB-3850)

Transport board: TPB-3851




Figure 321
Boards- Transport board (TPB-3851)

A/D board: TPB-3273




Figure 322
Boards- A/D board (TPB-3273)

A/D control board: TPB-3852




Figure 323
Boards- A/D board (TPB-3852)

Gate sensor (emitter) board: TPB-3282




Figure 326
Boards- Gate sensor (emitter) board (TPB-3282)

Gate sensor (receiver) board: TPB-3283




Figure 327
Boards- Gate sensor (receiver) board (TPB-3283)

Passage sensor (emitter) board: TPB-3863




Figure 328
Boards- Passage sensor (emitter) board (TPB-3863)

Passage sensor (receiver) board: TPB-3864




Figure 329

Boards- Passage sensor (receiver) board (TPB-3864)

Passage sensor (emitter) board: TPB-3865




Figure 330

Boards- Large passage sensor (emitter) board (TPB-3865)

Passage sensor (receiver) board: TPB-3866




Figure 331

Boards- Large passage sensor (receiver) board (TPB-3866)

Stack-lite board: TPB-3926




Figure 332
Boards- Stack-lite (TPB-3926)

Switch/LED board: TPB-3948




Figure 333
Boards- Switch/LED board (TPB-3948)

Details of each switch

SWLED ON is active state, OFF is inactive state.

SW0 Power supply board (main power supply): Toggling switch stops power to the power supply board (main).

SW1 Main board: Toggling switch stops power supply to the main board.

SW2 Transport board: Toggling switch stops power to the transfer board.

SW3 Relay board: Toggling switch stops power to the relay board.

❖ *When replacing the relay board, turn off SW3 and SW5.*

SW4 **Mother board:** Toggling switch stops power to the mother board.

❖ *When replacing the motherboard, turn SW4 and SW5 OFF.*

SW5 **Backup battery:** Toggling switch stops power to the relay board from mother board.

Power board: SWF150P-24



Figure 334
Boards- Power board (SWF150P-24)

Touch panel relay board: TSC-54/RU-F




Figure 335
Boards- Touch panel relay board (TSC-54/RU-F)

SSD: AXM21ES3-64GM-B




Figure 336
Boards- SSD (AXM21ES3-64M-B)

Memory: PC3-12800 4GB



Figure 337
Boards- Memory (PC3-12800 4GB)

Motherboard: EMX-BYT2-A1-01R




Figure 338
Boards - Motherboard (EMX-BYT2-A1-01R)

Wire & Connectors



CNW-15445-00




Figure 339
Boards - CNW-15445-00

Parts Number: 20CNW001544500					
A: TPB-03850 (CN15)			B: TPB-03851 (CN10)		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
A1	VCC5ENC	WT	A20	TEST_CONVEYOR	
A2	ENC1_A	RD	B2	ENC1AO	
A3	ENC1_B	OR	B3	ENC1BO	
A4	ENC2_A	YE	B4	ENC2AO	
A5	ENC2_B	GN	B5	ENC2BO	
A6	SEN1A	BL	B6	SEN1	
A7	GNDS	PL	B7	GNDS	
A8	GNDS	GR	B8	GNDS	
A9	VCC24CONV	WT	B9	VCC24MAIN	
A10	VCC24CONV	BK	B10	VCC24MAIN	
A11	GNDP	BR	B11	GNDP	
A12	GNDP	RD	B12	GNDP	
A13	RXMAIN	OR	B13	TXMAIN	
A14	TXMAIN	YE	B14	RXMAIN	
A15	TXD_FPGABOTH	GN	B15	RXD_FPGFLASH	
A16	RXD_FPGAINV	BL	B16	TXD_FPGAFLASH	
A17	SELCONV1	PL	B17	SELCONV1	
A18	SELCONV2	GR	B18	SELCONV2	
A19	GNDP	WT	B19	GNDP	

CNW-15447-01




Figure 340
Boards- CNW-15447-01

Parts Number: 20CNW001544701					
A: TPB-03851 (CN3)			B: Direction Indicator Switch		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
A1	VCC24IN	WT	A6	TEST-SW	
A2	FWD	-	B1	FWD	
A3	REV	-	B2	REV	
A4	CM	-	C	CM	
C	CM	BK	B3	CM	
A5	FG	GN	-	SHIELD	

CNW-15448-01




Figure 341
Boards- CNW-15448-01

Parts Number: 20CNW001544801					
A: TPB-03851 (CN5)			B: VF-nC3M		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
A4	D+INVA	WT	B4	D+	
A5	D-INVA	-	B5	D-	
A8	SG	-	B8	SG	

CNW-15449-01




Figure 342
Boards - CNW-15449-01

Parts Number: 20CNW001544901					
A: TPB-03851 (CN7)			B: VF-nC3M		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
A4	D+INVA	WT	B4	D+	
A5	D-INVA	-	B5	D-	
A8	SG	-	B8	SG	

CNW-15450-01




Figure 343
Boards - CNW-15450-01

Parts Number: 20CNW001545001					
A: TPB-03851 (CN8)			B,C: CNW-15508 (ENCORDER ASSY)		
A connector			B/C connector		
No.	Signal	CLR	No.	Signal	
A1	VCC5ENC	WT	A16	TEST_ENC	
A2	VCC5ENC		B1	P0	
A4	ENC1AI		B2	YA	
A5	GNDS		B3	CM	
A6	ENC1BI		B4	YB	
A7	GNDS		B5	CM	
	SHIELD	GN	B6	SHIELD	
A8	GNDP	GN		SHIELD	
A9	VCC5ENC		C1	P0	
A11	ENC2AI		C2	YA	
A12	GNDS		C3	CM	
A13	ENC2BI		C4	YB	
A14	GNDS		C5	CM	
	SHEILD	GN	C6	SHIELD	
A15	GNDP	GN		SHIELD	

CNW-15451-00




Figure 344
Boards- CNW-15451-00

Parts Number: 20CNW001545100					
A: CNW-15499			B,C: CNW-15508 (ENCORDER ASSY)		
D: CNW-15499			E,F: CNW-15474		
A/B/C/D/E connector			B/C/E/F connector		
No.	Signal	CLR	No.	Signal	
A1	VCC24		E1	IN24V	
A2	VCC24		E2	IN24V	
B1	VCC24_IN	WT	B8	TEST_MSTOP	
B5	VCC24_LED		E5	LED24V	
B7	GNDP		E6	GND	
E3	OUT24V		F1	IN24V	
E4	OUT24V		F2	IN24V	
C1	VCC24_IN	WT	C9	TEST_ISTOP	
C7	VCC24_LED		F5	LED24V	
C8	GNDP		F6	GND	

Parts Number: 20CNW001545100				
A: CNW-15499			B,C: CNW-15508 (ENCORDER ASSY)	
D: CNW-15499			E,F: CNW-15474	
A/B/C/D/E connector			B/C/E/F connector	
No.	Signal	CLR	No.	Signal
D1	STOP		F3	OUT24V
D2	STOP		F4	OUT24V

CNW-15452-01




Figure 345
Boards - CNW-15452-01

Parts Number: 20CNW001545201				
A: CNW-15503 B, B: TPB-03850 (CN20), C: EARTH,				
D: CNW-15491, E:TPB-03850 (CN1)				
A connector			B/C connector	
No.	Signal	CLR	No.	Signal
A1	NRXD		B1	U1-TXD
A2	NTXD		B2	U1-RXD
A3	GND		B7	GNDS
	SHIELD	GN	C1	SHIELD
D1	D+	GN	E1	USB+
D2	D-	WT	E2	USB-
D4	GND	BK	E4	GNDS

Parts Number: 20CNW001545201				
A: CNW-15503 B, B: TPB-03850 (CN20), C: EARTH,				
D: CNW-15491, E:TPB-03850 (CN1)				
A connector			B/C connector	
No.	Signal	CLR	No.	Signal
D5	VBUS	RD	E5	USBVBUS
D3	SHIELD	GN		SHIELD
	SHIELD	GN	E3	SHIELD

CNW-15453-00




Figure 346
Boards - CNW-15453-00

Parts Number: 20CNW001545300				
A: TPB-03850 (CN10)			B: CNW-15454	
A connector			B/C connector	
No.	Signal	CLR	No.	Signal
A1	VCC24IN	WT	A20	TEST_GATE_SNSH
A2	GATE_H1-		B1	CLK-
A3	GATE_H2-		B2	DATA-
A4	GATE_H1+		B3	CLK+
A5	GATE_H2+		B4	DATA+
A6	VCC24GATE	BL	B5	VCC24GATE
A7	VCC24GATE	PL	B6	VCC24GATE
A8	VCC24GATE	GR	B7	VCC24GATE
A11	GND		B10	GND
A12	GND		B11	GND

Parts Number: 20CNW001545300				
A: TPB-03850 (CN10)			B: CNW-15454	
A connector			B/C connector	
No.	Signal	CLR	No.	Signal
A13	GND		B12	GND
A14	GND		B13	GND
A15	STARHI-		B14	STARHI-
A16	STARHI+		B15	STARHI+
A19	FG	GN		SHIELD

CNW-15454-01




Figure 347
Boards- CNW-15454-01

Parts Number: 20CNW001545401				
A: CNW-15453			B: TPB-03283 (CN6)	
A connector			B connector	
No.	Signal	CLR	No.	Signal
A1	CLK-		B1	CLK-
A2	DTATA-		B2	DTATA-
A3	CLK+		B3	CLK+
A4	DATA+		B4	DATA+
A5	VCC24GATE		B5	VCC24GATE
A6	VCC24GATE		B6	VCC24GATE
A7	VCC24GATE		B7	VCC24GATE
A8	VCC24GATE		B8	VCC24GATE
A9	VCC24GATE		B9	VCC24GATE

Parts Number: 20CNW001545401					
A: CNW-15453			B: TPB-03283 (CN6)		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
A11	GND		B10	GND	
A12	GND		B11	GND	
A13	GND		B12	GND	
A14	GND		B13	GND	
A15	STARHI-		B14	RID1-	
A15	STARHI+		B15	RID1+	
A16	FG	GN	B16	SHIELD	

CNW-15455-01




Figure 348
Boards - CNW-15455-01

Parts Number: 20CNW001545501					
A: TPB-03850 (CN8)			B: TPB-03282 (CN6)		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
A1	VCC24IN		B1	TEST_GATE_LEDH	
A2	VCC24GATE		B2	VCC24GATE	
A3	VCC24GATE		B3	VCC24GATE	
A4	VCC24GATE		B4	VCC24GATE	
A5	VCC24GATE		B5	VCC24GATE	
A6	GATELED_H-		B6	GATELED_H-	
A7	GATELED_H+		B7	GATELED_H+	
A8	GND		B8	GND	

Parts Number: 20CNW001545501					
A: TPB-03850 (CN8)			B: TPB-03282 (CN6)		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
A9	GND		B9	GND	
A11	GND		B10	GND	
A12	GND		B11	GND	
A13	FG		B12	GND	

CNW-15456-00




Figure 349
Boards- CNW-15456-00

Parts Number: 20CNW001545600					
A: TPB-03850 (CN9)			B: CNW-15457		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
A1	VCC24IN	WT	B1	TEST_GATE_SNSV	
A2	GATE_V1-		B2	CLK-	
A3	GATE_V2-		B3	DATE-	
A4	GATE_V1+		B4	CLK+	
A5	GATE_V2+		B5	DATE+	
A6	VCC24GATE		B6	VCC24GATE	
A7	VCC24GATE		B7	VCC24GATE	
A9	VCC24GATE		B8	VCC24GATE	
A10	VCC24GATE		B9	VCC24GATE	

Parts Number: 20CNW001545600				
A: TPB-03850 (CN9)			B: CNW-15457	
A connector			B connector	
No.	Signal	CLR	No.	Signal
A11	GND		B10	GND
A12	GND		B11	GND
A13	GND		B12	GND
A14	GND		B13	GND
A16	STARTVI-		B14	STARTV-

CNW-15457-01




Figure 350
Boards- CNW-15457-01

Parts Number: 20CNW001545701				
A: CNW-15456			B: TPB-03283 (CN6)	
A connector			B connector	
No.	Signal	CLR	No.	Signal
A1	CLK-		B1	CLK-
A2	DATA-		B2	DATE-
A3	CLK+		B3	CLK+
A4	DATA+		B4	DATE+
A5	VCC24GATE		B5	VCC24
A6	VCC24GATE		B6	VCC24
A7	VCC24GATE		B7	VCC24
A8	VCC24GATE		B8	VCC24
A9	VCC24GATE		B9	VCC24

Parts Number: 20CNW001545701				
A: CNW-15456			B: TPB-03283 (CN6)	
A connector			B connector	
No.	Signal	CLR	No.	Signal
A10	GND		B10	GND
A11	GND		B11	GND
A12	GND		B12	GND
A13	GND		B13	GND
A14	STARTVI-		B15	RID1-
A15	STARTVI+		B16	RID1+
A16	FG	GN		SHIELD

CNW-15458-01




Figure 351
Boards- CNW-15458-01

Parts Number: 20CNW001545801				
A: TPB-03850 (CN7)			B: TPB-03282 (CN6)	
A connector			B connector	
No.	Signal	CLR	No.	Signal
A1	VCC24IN	WT	A12	TEST_GATE_LEDV
A2	FG	GN		SHIELD
A3	VCC24GATE		B1	VCC24GATE
A4	VCC24GATE		B2	VCC24GATE
A5	VCC24GATE		B3	VCC24GATE
A6	GATELED_V-		B6	GATELED_V-
A7	GATELED_V+		B7	GATELED_V+
A8	GND		B8	GND

Parts Number: 20CNW001545801					
A: TPB-03850 (CN7)			B: TPB-03282 (CN6)		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
A9	GND		B9	GND	
A10	GND		B10	GND	
A11	GND		B11	GND	

CNW-15460-01




Figure 352
Boards- CNW-15460-01

Parts Number: 20CNW001546001					
A: AC outlet			B: BREAKER(BW32AAG-3P020)		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
A1	X	RD	B1	BR-2	
A2	Y	BL	B2	BR-4	
A3	Z	BK	B3	BR-6	
A4	E	YE/GN	B4	GRAND	

CNW-15461-00




Figure 353
Boards- CNW-15461-00

Parts Number: 20CNW001546100					
A: BREAKER(BW32AAG-3P020)			B: NoiseFilter(TAH-20-683)		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
1	BR-1	RD	1	NF-1	
2	BR-3	WT	2	NF-2	
3	BR-5	BK	3	NF-3	

CNW-15462-00




Figure 354
Boards- CNW-15462-00

Parts Number: 20CNW001546200					
A: NoiseFilter(TAH-20-683)			B: Terminal(ML-20-8P)		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
1	NF-4	RD	1	T-1	
2	NF-5	WT	2	T-3	
3	NF-6	BK	3	T-5	

CNW-15463-00




Figure 355
Boards- CNW-15463-00

Parts Number: 20CNW001546300					
A: Terminal (ML-20-8P)			B: electronic switch (SC-05/G)		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
1	T-2	RD	1	L1	
2	T-4	WT	2	L2	
3	T-6	BK	3	L3	

CNW-15464-01




Figure 356
Boards- CNW-15464-01

Parts Number: 20CNW001546401				
A: terminal			B: circuit protector (BAC-201201)	
A connector			B connector	
No.	Signal	CLR	No.	Signal
1	T-1	WT	1	SP-1
2	T-3	BK	2	SP-2

CNW-15465-01




Figure 357
Boards- CNW-15465-01

Parts Number: 20CNW001546501				
A: circuit protector(BAC201201) B: switch/LED board, C: sub power board (SWF-150P-24)				
A connector			B/C connector	
No.	Signal	CLR	No.	Signal
A1	SP-3	WT	B1	N
A1	SP-3	WT	C1	N
A2	SP-4	BK	B3	L
A2	SP-4	BK	C3	L
D1	PG	GN	B5	PG
D2	PG	GN	C5	PG

CNW-15466-01




Figure 358
Boards- CNW-15466-01

Parts Number: 20CNW001546601				
A: switching power supply (SWF150P-24 CN101)			B: switch board CN2	
A connector			B connector	
No.	Signal	CLR	No.	Signal
A1	AC (L)	WT	B1	L
A2	AC (N)	BK	B2	N
A3	PG	GN	B5	PG

CNW-15467-01




Figure 359
Boards- CNW-15467-01

Parts Number: 20CNW001546701					
A: TPB-3854 (CN6), B: SWF150P-24 (CN601), C: SWF150P-24 (CN602)					
A connector			B/C connector		
No.	Signal	CLR	No.	Signal	
A1	VCC24A	OR	B1	V+	
A2	VCC24A	OR	B2	V+	
A3	VCC24A	OR	B3	V+	
A4	VCC24A	OR	B4	V+	
A5	GND	BK	C1	V-	
A6	GND	BK	C2	V-	
A7	GND	BK	C3	V-	
A8	GND	BK	C4	V-	

CNW-15468-01




Figure 360
Boards- CNW-15468-01

Parts Number: 20CNW001546801				
A: TPB-3854 (CN7), B: SWF150P-24 (CN601), C: SWF150P-24 (CN602)				
A connector			B/C connector	
No.	Signal	CLR	No.	Signal
A1	VCC24A	OR	B1	V+
A2	VCC24A	OR	B2	V+
A3	VCC24A	OR	B3	V+
A4	VCC24A	OR	B4	V+
A5	GND	BK	C1	V-
A6	GND	BK	C2	V-
A7	GND	BK	C3	V-
A8	GND	BK	C4	V-

CNW-15469-00




Figure 361
Boards- CNW-15469-00

Parts Number: 20CNW001546900					
A: Power switch (SC-4-1/G)			B: TPB-03854 (CN8)		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
B6	EM_RELAY_CONECT	WT	B1	VCC_24N	
A1	A1	RD	B2	ESW_IN	
A1	A1	OR	B3	ESW_IN	
A2	A2	YE	B4	GND	
A2	A2	GN	B5	GND	

CNW-15470-00




Figure 362
Boards- CNW-15470-00

Parts Number: 20CNW001547000					
A: Power switch (SC-05/G)			B: INV BOX terminal (ML-20-8P)		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
A1	T1	RD	B1	T1	
A2	T3	WT	B2	T3	
A3	T5	BK	B3	T5	
A4	E	YE/GN	B4	EARTH	
A5	SHIELD	GN	B5	SHIELD	

CNW-15471-00




Figure 363
Boards- CNW-15471-00

Parts Number: 20CNW001547100					
A: TPB-03854 (CN4)			B: switch/LED board		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
A1	VCC24_3	WT	A28	PWR_BD_SW_CN	
A2	MAIN_PWR_SW	OR	B1	MAIN_PWR_SW	
A3	MAIN_PWR_SW	OR	B2	MAIN_PWR_SW	
A4	GNDP	BL	B3	GNDP	
A5	GNDP	BL	B4	GNDP	
A6	VCC24	RD	B5	VCC24	
A7	LEDK	BK	B6	LEDK	
A8	MOTO_PWR_SW	OR	B7	MOTO_PWR_SW	
A9	MOTO_PWR_SW	OR	B8	MOTO_PWR_SW	
A10	GNDP	BL	B9	GNDP	
A11	GNDP	BL	B10	GNDP	
A12	VCC24	RD	B11	VCC24	
A13	LED_K	BK	B12	LED_K	
A14	RLY_PWR_SW	OR	B13	RLY_PWR_SW	
A15	RLY_PWR_SW	OR	B14	RLY_PWR_SW	
A9	MOTO_PWR_SW	OR	B8	MOTO_PWR_SW	

CNW-15472-00




Figure 364
Boards- CNW-15472-00

Parts Number: 20CNW001547200					
A: TPB-03854 (CN3)			B: TPB-03853 (CN6)		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
A1	VCC24_3	BR	B2	VCC24_3	
A2	MAIN_PWR_CONECT	RD	B3	MAIN_PWR_CONECT	
A3	E-SW MON	OR	B4	E-SW MON	
A4	E-SW CUT	YE	B5	E-SW CUT	
A5	E_SW CUT	GN	B6	E_SW CUT	
A6	E-SW Q	BL	B7	E-SW Q	
A7	E-SW Q	PL	B8	E-SW Q	
A8	EM_RELAY_CONECT	GR	B9	EM_RELAY_CONECT	
A9	PWR_BD_MB_CN	WT	B10	PWR_BD_MB_CN	
A10	PWR_BD_SW_CN	BK	B12	PWR_BD_SW_CN	
A11	LOST24V	BR	B13	LOST24V	
A12	LOST24V	RD	B14	LOST24V	
A13	GNDP	OR	B15	GNDP	
B1	VCC24_3	WT	B16	VCC24_3	

CNW-15473-00




Figure 365
Boards- CNW-15473-00

Parts Number: 20CNW001547300					
A: TPB-03854 (CN5)			B: TPB-03853 (CN1)		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
A1	VCC24RLY	OR	B1	VCC24	
A2	VCC24RLY	OR	B2	VCC24	
A3	VCC24RLY	OR	B3	VCC24	
A4	GNDP	BK	B4	GNDP	
A5	GNDP	BK	B5	GNDP	
A6	GNDP	BK	B6	GNDP	
A7	VCC12	RD	B7	VCC12	
A8	VCC12	RD	B8	VCC12	
A9	GNDP	BK	B9	GNDP	
A10	GNDP	BK	B10	GNDP	

CNW-15474-00




Figure 366
Boards- CNW-15474-00

Parts Number: 20CNW001547300					
A: TPB-03854 (CN5)			B: TPB-03853 (CN1)		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
A1	IN24V	BR	B1	1	
A2	IN24V	RD	B1	1	
A3	OUT24V	OR	B2	2	
A4	OUT24V	YE	B2	2	
A5	LED24V	GN	C1	3	
A6	GNDP	BL	C2	X2	
D1	4	PL	D2	X1	

CNW-15475-01




Figure 367
Boards- CNW-15475-01

Parts Number: 20CNW001547401					
A: TPB-03853 (CN4)			B: switch/LED board (CN4)		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
A1	VCC24_3	WT	A9	SW_CONECT	
A2	VCC12_SW	OR	B2	VCC12_SW	
A3	VCC12_SW	OR	B3	VCC12_SW	
A4	GNDS	BL	B4	GNDS	
A5	GNDS	BL	B5	GNDS	
A7	LED_A	RD	B7	LED_A	
A8	LED_K	BK	B8	LED_K	

CNW-15478-00




Figure 368
Boards- CNW-15478-00

Parts Number: 20CNW001547800					
A: EMX-BYT2 COM5			B: RS_232C I/F		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
A1	NRXD	BR	B2	232RXD	
A3	NDTR	OR	B4	232DTR	
A4	NTXD	YE	B3	232TXD	
A5	NDSR	GN	B6	232DSR	
A6	GND	BL	B5	GND	
A7	NCTS	PL	B8	232CTS	
A8	NRTS	GR	B7	232RTS	

CNW-15480-00




Figure 369
Boards- CNW-15480-00

Parts Number: 20CNW001546800				
A: TPB-3854 (CN7), B: SWF150P-24 (CN601), C:SWF150P-24 (CN602)				
A connector			B connector	
No.	Signal	CLR	No.	Signal
1	TEST1	-	1	TEST_LED_A
2	UP_1	-	2	LED1_UP_A
3	LOW_1	-	3	LED1_LOW_A
4	UP_2	-	4	LED2_UP_A
5	LOW_2	-	5	LED2_LOW_A
6	UP_3	-	6	
7	LOW_3	-	7	
8	UP_4	-	8	
9	LOW_4	-	9	
10	UP_5	-	10	LED_5UP_A
11	LOW_5	-	11	LED_5_LOW_A
12	VCC10IN	-	12	VCC10A_2
13	VCC10IN	-	13	VCC10A_2
14	VCC10IN	-	14	VCC10A_2
15	GND	-	15	GNDP

CNW-15481-00




Figure 370
Boards- CNW-15481-00

Parts Number: 20CNW001548100				
A: TPB-03865 (CN2)			B: TPB-03852 (CN5)	
A connector			B connector	
No.	Signal	CLR	No.	Signal
1	TEST1	-	1	TEST_LED_B
2	UP_1	-	2	LED1_UP_B
3	LOW_1	-	3	LED1_LOW_B
4	UP_2	-	4	LED2_UP_B
5	LOW_2	-	5	LED2_LOW_B
6	UP_3	-	6	LED3_UP_B
7	LOW_3	-	7	LED3_LOW_B
8	UP_4	-	8	LED4_UP_B
9	LOW_4	-	9	
10	UP_5	-	10	LED_5UP_A
11	LOW_5	-	11	LED_5_LOW_A
12	VCC10IN	-	12	VCC10A_2
13	VCC10IN	-	13	VCC10A_2
14	VCC10IN	-	14	VCC10A_2
15	GND	-	15	GNDP

CNW-15482-00




Figure 371
Boards- CNW-15482-00

Parts Number: 20CNW001548200				
A: TPB-03866 (CN2)			B: TPB-03852 (CN11)	
A connector			B connector	
No.	Signal	CLR	No.	Signal
1	TEST1	-	1	TEST_SENS_A
2	UP_1	-	2	SENS1_UP_A
3	LOW_1	-	3	SENS1_LOW_A
4	UP_2	-	4	SENS2_UP_A
5	LOW_2	-	5	SENS2_LOW_A
6	UP_3	-	6	
7	LOW_3	-	7	
8	UP_4	-	8	
9	LOW_4	-	9	
10	UP_5	-	10	SENS5_UP_A
11	LOW_5	-	11	SENS5_LOW_A
12	VCC10IN	-	12	VCC10A_2
13	VCC10IN	-	13	VCC10A_2
14	VCC10IN	-	14	VCC10A_2
15	GND	-	15	GNDP
9	LOW_4	-	9	

CNW-15483-00




Figure 372
Boards- CNW-15483-00

Parts Number: 20CNW001548300					
A: TPB-03866 (CN1)			B: TPB-03852 (CN12)		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
1	TEST1	-	1	TEST_SENS_B	
2	UP_1	-	2	SENS1_UP_B	
3	LOW_1	-	3	SENS1_LOW_B	
4	UP_2	-	4	SENS2_UP_B	
5	LOW_2	-	5	SENS2_LOW_B	
6	UP_3	-	6	SENS3_UP_B	
7	LOW_3	-	7	SENS3_LOW_B	
8	UP_4	-	8	SENS4_UP_B	
9	LOW_4	-	9	SENS4_LOW_B	
10	UP_5	-	10	SENS5_UP_B	
11	LOW_5	-	11	SENS5_LOW_B	
12	VCC10IN	-	12	VCC10B_2	
13	VCC10IN	-	13	VCC10B_2	
14	VCC10IN	-	14	VCC10B_2	
15	GND	-	15	GNDP	
9	LOW_4	-	9	SENS4_LOW_B	

CNW-15484-01




Figure 373
Boards- CNW-15484-01

Parts Number: 20CNW001548401					
A: TPB-03865 or TPB-03866			B: TPB-03863 or TPB-03854		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
A1	TEST1	BR	B1	TEST1	
A2	LED5UP	RD	B2	LED5UP	
A3	LED5LOW	OR	B3	LED5LOW	
A4	VCC5	YE	B4	VCC5	
A5	VCC5	GN	B5	VCC5	
A6	GND	BL	B6	GND	
A7	GND	PL	B7	GND	
A8	VCC10IN	GR	B8	VCC10IN	
A9	GND	WT	B9	GND	
A10	TEST2	BK	B10	TEST2	

CNW-15485-01




Figure 374
Boards- CNW-15485-01

Parts Number: 20CNW001548501					
A: TPB-03865 or TPB-03866			B: TPB-03865 or TPB-03866		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
1	TEST1	BR	1	TEST1	
2	UP_1	RD	2	UP_1	
3	LOW_1	OR	3	LOW_1	
4	UP_2	YE	4	UP_2	
5	LOW_2	GN	5	LOW_2	
6	UP_3	BL	6	UP_3	
7	LOW_3	PL	7	LOW_3	
8	UP_4	GR	8	UP_4	
9	LOW_4	WT	9	LOW_4	
10	UP_5	BK	10	UP_5	
11	LOW_5	BR	11	LOW_5	
12	VCC10IN	RD	12	VCC10IN	
13	VCC10IN	OR	13	VCC10IN	
14	VCC10IN	YE	14	VCC10IN	
15	GND	GN	15	GND	

CNW-15486-00




Figure 375
Boards- CNW-15486-00

Parts Number: 20CNW001548601					
A: Inverter A(VF-nC3M)			B: Inverter BOX terminal (ML-20-8P)		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
A1	RL1A	RD	B1	T1	
A2	SL2A	WT	B2	T3	
A3	TL3A	BK	B3	T5	
A4	EARTH	GN	B4	EARTH	

CNW-15487-00




Figure 376
Boards- CNW-15487-00

Parts Number: 20CNW001548700					
A: Inverter B(VF-nC3M)			B: Inverter BOX terminal (ML-20-8P)		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
A1	RL1B	RD	B1	T2	
A2	SL2B	WT	B2	T4	
A3	TL3A	BK	B3	T6	
A4	EARTH	GN	B4	EARTH	

CNW-15488-00




Figure 377
Boards- CNW-15488-00

Parts Number: 20CNW001548800				
A: EMX-BYT2 SPK1 B			B: speaker (W4020CPA)	
A connector			B connector	
No.	Signal	CLR	No.	Signal
A1	LSPK+	RD	B1	LSPK+
A2	LSPK-	BK	B2	LSPK-
A3	RSPK+	-		
A4	RSPK-	-		

CNW-15489-00




Figure 378
Boards- CNW-15489-00

Parts Number: 20CNW001548900				
A: EMX-BYT2JLVDS1			B: NLB150XG02L-01 (CN1)	
A connector			B/C connector	
No.	Signal	CLR	No.	Signal
A1	+3.3V	BR	B1	LVDS_DATAP4
A2	+5V	RD	-	LVDS_DATAN5
A3	+3.3V	OR	B2	LVDS_DATAN4
A4	+5V	YE	-	GND
A5	EDP_DDC_SCL	GN	-	GND
A6	EDP_DDC_DAT	BL		LVDS_DATAP7
A7	GND	PL	B3	LVDS_DATAP6
A8	GND	GR	B4	LVDS_DATAN7
A9	LVDS_DATAP1	WT	B9	LVDS_DATAN6
A10	LVDS_DATAP0	BK	B6	GND
A11	LVDS_DATAN1	BR	B8	
A12	LVDS_DATAN0	RD	B5	GND
A13	GND	OR	B7	LVDS_CLK2P
A14	GND	YE	B10	LVDS_CLK1P
A15	LVDS_DATAP3	GN	B18	LVDS_CLK2N
A16	LVDS_DATAP2		B12	LVDS_CLK1N
A17	LVDS_DATAN3		B17	GND

Parts Number: 20CNW001548900				
A: EMX-BYT2JLVDS1			B: NLB150XG02L-01 (CN1)	
A connector			B/C connector	
No.	Signal	CLR	No.	Signal
A18	LVDS_DATAN2		B11	GND
A19	GND		B13	+12V
A20	GND		B16	+12V
A21	LVDS_DATAP5		-	-

CNW-15490-00




Figure 379
Boards- CNW-15490-00

Parts Number: 20CNW001549000				
A: EMX-BYT2 JBKL1			B: NLB150XG02L-01 (CN2)	
A connector			B connector	
No.	Signal	CLR	No.	Signal
A1	12V	BR	B5	VDD
A2	GND	RD	B4	GND
A3	LVDS_BKLTEN	OR	B3	BRTC
A4	LVDS_BKLADJ	YE	B2	PWM
A5	+5V	-	B1	NC

CNW-15491-00




Figure 380
Boards- CNW-15491-00

Parts Number: 20CNW001549100				
A: EMX-BYT2 USB3, B: CNW-15504, C: TSC-54/RU-F CN4				
A connector			B connector	
No.	Signal	CLR	No.	Signal
A1	+V5A_USB01	RD	C1	VBUS
A2	+5A_USB01	RD	B5	USBVBUS
A3	USB_DN1	WT	C2	D-
A4	USB_DN0	WT	B2	USBD-
A5	USB_DP1	GN	C3	D+
A6	USB_DP0	GN	B1	USBD+
A7	GND	BK	C4	GND
A8	"	BK	B4	USBGND
A9	-	-	-	-
A10	-	-	-	-

CNW-15492-00




Figure 381
Boards- CNW-15492-00

Parts Number: 20CNW001549200					
A,B: INVERTER(VF-nC3M)			C: RELAY POINT		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
A1	UT1A	RD	C1	MU	
A2	VT2A	WT	C2	MV	
A3	WT3A	BK	C3	MW	
A4	EARTH	GN	C4	EARTH	
B	SHIELD	GN		SHIELD	

CNW-15493-00




Figure 382
Boards- CNW-15493-00

Parts Number: 20CNW001549300					
A,B: INVERTER(VF-nC3M)			C: RELAY POINT		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
A1	UT1B	RD	C1	MU	
A2	VT2B	WT	C2	MV	
A3	WT3B	BK	C3	MW	
A4	E	GN	C4	EARTH	
B	SHIELD	GN		SHIELD	

CNW-15494-00




Figure 383
Boards - CNW-15494-00

Parts Number: 20CNW001549400					
A: GEARD MOTOR, B: RELAY POINT, C: SHIELD					
A connector				B/C connector	
No.	Signal	CLR	No.	Signal	
A1	MU	RD	B1	IU	
A2	MV	WT	B2	IV	
A3	MW	BK	B3	IW	
A4	EARTH	GN	B4	EARTH	
	SHIELD	GN	C	SHIELD	

CNW-15495-00




Figure 384
Boards- CNW-15495-00

Parts Number: 20CNW001549500					
A: CNW-15496			B: EB4015C-30C150-24V		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
A1	VCC5	RD	B1	BUZ+	
A2	BUZ_CUT	BK	B2	BUZ-	

CNW-15496-01




Figure 385
Boards- CNW-15496-01

Parts Number: 20CNW001549601					
A: DsuB connector			B~L: connectors		
A connector			B/L connector		
No.	Signal	CLR	No.	Signal	
A1	GND	BR	B1	GND	
A2	GND	RD	B1	GND	
A3	GND	OR	B2	GND	
A4	GND	YE	B2	GND	
A5	+VIN_12	GN	B3	+VIN_12	
A6	+VIN_12	BL	B3	+VIN_12	
A7	+VIN_12	PL	B4	+VIN_12	
A8	+VIN_12	GR	B4	+VIN_12	
A9	VCC24IN	WT	C3	VCC24IN	
A10	GND	BK	C5	GND	
A11	LED_CNT	BR	C1	LED_CNT	
A12	VCCBZ	RD	D1	VCCBZ	
A14	LED_CNT	YE	C2	LED_CNT	

Parts Number: 20CNW001549601				
A: DsuB connector			B~L: connectors	
A connector			B/L connector	
No.	Signal	CLR	No.	Signal
A15	BUZ_CNT	GN	D2	BUZ_CNT
A16	+PWR_BNT	BL	E5	+PWR_BNT
A17	+RESET	PL	E6	+RESET
A18	-PWR_LED	GR	E3	-PWR_LED
A19	+PWR_LED	WT	E1	+PWR_LED
A20	NRXD	BK	F1	NRXD
A21	NRXD	BR	G1	NRXD
A22	NTXD	RD	G4	NTXD
A23	NTXD	OR	F4	NTXD
A24	GND	YE	G6	GND
A25	NRXD	GN	H1	NRXD
A26	NTXD	BL	H4	NTXD
A27	NDSR	GR	H5	NDSR
A32	NRXD	RD	I1	NRXD
A33	NCTS	OR	I7	NCTS
A34	NTXD	YE	I4	NTXD
A35	NRTS	GN	I8	NRTS
A36	GND	BL	I6	GND
A37	NRXD	PL	J1	NRXD
A38	NCTS	GR	J7	NCTS
A39	NTXD	WT	J4	NTXD
A40	NRTS	BK	J8	NRTS
A41	POWSW	BR	K1	POWSW
A42	GNDS	RD	K2	GNDS
A45	POWLED_A	GN	L1	POWLED_A
A46	POWLED_K	BL	L2	POWLED_K

CNW-15497-01




Figure 386
Boards- CNW-15497-01

Parts Number: 20CNW001549701				
A: DDU-50SF-F0+DD-C4J13-S1 (DsuB connector), B: TPB-03854 (CN2), C: TPB-03853(CN7)				
A connector			B/L connector	
No.	Signal	CLR	No.	Signal
B1	VCC24_3	WT	B6	PWR_BD_CN
A1	GNDP		B5	GNDP
A2	GNDP		B5	GNDP
A3	GNDP		B4	GNDP
A4	GNDP		B4	GNDP
A5	VCC12		B3	VCC12
A6	VCC12		B3	VCC12
A7	VCC12		B2	VCC12
A8	VCC12		B2	VCC12
A9	VCCPATHLIGHT		C2	VCCPATHLIGHT
A10	GNDP		C3	GNDP
A11	LEDO		C4	LEDO
A12	VCCBZ		C5	VCCBZ
A13	N.C.		C6	GNDP

Parts Number: 20CNW001549701				
A: DDU-50SF-F0+DD-C4J13-S1 (DsuB connector), B: TPB-03854 (CN2), C: TPB-03853(CN7)				
A connector		CLR	B/L connector	
No.	Signal		No.	Signal
A14	LEDR		C7	LEDR
A15	BZ		C8	BZ
A16	XPWBTN_MB		C9	XPWBTN_MB
A17	SYS_RST		C10	SYS_RST
A18	XPS_ON		C11	XPS_ON
A19	LED+		C12	LED+
A20	MBRX1		C13	MBRX1
A21	MBRX2		C14	MBRX2
A22	MBRX2		C15	MBTX2
A23	MBTX1		C16	MBTX1
A24	GNDP		C17	GNDP
A25	MBRX3		C18	MBRX3
A26	MBTX3		C19	MBTX3
A27	SHUT_DOWN		C20	SHUT_DOWN
A28	MBRX4		-	N.C
A29	MBCTS4		-	N.C
A30	MBTX4		-	N.C
A31	MBRTS4		-	N.C
A32	MBRX5		C25	MBRX5
A33	MBCTS5		C26	MBCTS5
A34	MBTX5		C27	MBTX5
A35	MBRTS5		C28	MBRTS5
A36	GNDS		C29	GNDS
A37	MBRX6		C30	MBRX6
A38	MBCTS6		C31	MBCTS6
A39	MBTX6		C32	MBTX6
A40	MBRTS6		C33	MBRTS6
A41	POWSW		C34	POWSW
A42	GNDS		C35	GNDS
A43	SHUTDWSW		-	SHUTDWSW
A44	GNDS		-	GNDS
A45	POWLED_A		C38	POWLED_A

Parts Number: 20CNW001549701				
A: DDU-50SF-F0+DD-C4J13-S1 (DsuB connector), B: TPB-03854 (CN2), C: TPB-03853(CN7)				
A connector			B/L connector	
No.	Signal	CLR	No.	Signal
A46	POWLED_K		C39	PWLED_K
C1	VCC24_3	WT	C40	MB_SIG_CONE CT

CNW-15498-01




Figure 387
Boards- CNW-15498-01

Parts Number: 20CNW001549801				
A: CNW-15496			B: LED	
A connector			B connector	
No.	Signal	CLR	No.	Signal
A1	VCC3	RD	B1	VCC3
A2	LED_CHG	BK	B2	GND

CNW-15499-01




Figure 388
Boards - CNW-15499-01

Parts Number: 20CNW001549901				
A: TPB-03853(CN31), B: TPB-03854(CN1), C: TPB-03851(CN11), D:TPB-03850(CN14), E: TPB-03850(CN3), F/G: E stop switch board				
A/B/C/D connector			B/C/D/F/G connector	
No.	Signal	CLR	No.	Signal
A1	VCC24_3	WT	A24	MAIN_CONECT
A2	RX_MAIN1		D5	COM2RX
A3	TX_MAIN1		D3	COM2TX
A4	RX_MAIN2		D7	COM2RX2
A5	TX_MAIN2		D6	COM2TX2
A6	RX_INV1		C11	RXINV
A7	TX_INV1		C10	TXINV
A8	RX_PLC1		C3	RXRELAY1
A9	TX_PLC1		C2	TXRELAY1
A10	RX_PLC2		C13	RXRELAY2

Parts Number: 20CNW001549901				
A: TPB-03853(CN31), B: TPB-03854(CN1), C: TPB-03851(CN11), D:TPB-03850(CN14), E: TPB-03850(CN3), F/G: E stop switch board				
A/B/C/D connector			B/C/D/F/G connector	
No.	Signal	CLR	No.	Signal
A11	RX_PLC2		C12	TXRELAY2
A12	TRG_IN1		C6	SEN10
A13	RX_INV2		C18	RXINV2
A14	TX_INV2		C17	TXINV2
A15	ENC_INI1_A		C4	ENCA
A16	ENC_IN1_B		C5	ENCB
A17	RX_N101		D4	COM1RX
A18	TX_N101		D2	COM1TX
A21	GNDS		D9	GNDS
A23	TRG		C7	TRG
B1	VCC24_3	WT	B20	MAIN_PWR_CONE_CT
B2	VCC24		G1	VCC24
B3	VCC24		G2	VCC24
B4	VCC24_MAIN	-/WT	E1	VCC24_IN
B5	VCC24MOT		C14	VCC24IN
B6	VCC24MAIN	-/WT	E2	VCC24_IN
B7	VCC24		C15	VCC24IN
B8	VCC24_MAIN	-/WT	E3	VCC24_IN
B9	VCC24MOT		C16	VCC24IN
B10	VCC24_MAIN	-/WT	E4	VCC24_IN
B11	GNDP		C21	GNDP
B12	GNDP	-/WT	E7	GNDP
B13	GNDP		C22	GNDP
B14	GNDP	-/WT	E8	GNDP
B15	GNDP		C23	GNDP
B16	GNDP	-/WT	E9	GNDP
B17	ESW_IN		F1	STOP
B18	GNDP	-/WT	E10	GNDP
B19	ESW_IN		F2	STOP
C1	VCC24IN	WT	C24	TEST_RELAY
D1	VCC3A	WT	D10	TEST_RELAY
C20	SHIELD	GN		SHIELD

CNW-15500-01




Figure 389
Boards- CNW-15500-01

Parts Number: 20CNW001550001					
A: TPB-03850(CN12), B: TPB-03850(CN11), C: TPB-03852(CN2), D: TPB-03852(CN1),					
A/B connector			C/D connector		
No.	Signal	CLR	No.	Signal	
A1	VCC24IN	WT	A26	VCC24IN	
A2	VCC24AD		C2	VCC24IN	
A3	VCC24AD		C3	VCC24IN	
A4	VCC24AD		C4	VCC24IN	
A5	GNDP		C5	GNDP	
A6	GNDP		C6	GNDP	
A7	GNDP		C7	GNDP	
A8	TXD1		C8	RXD2	
A9	RXD1		C9	TXD2	
A10	TXD2		C10	RXD21	
A11	RXD2		C11	TXD21	
A12	GNDS		C12	GNDS	
A14	TXD_MLOG		C14	RXD_MLOG	
A15	RXD_MLOG		C15	TXD_MLOG	
A16	TXD_FPGABOTH		C16	RXD_FPGABOTH	
A17	RXD_FGADSP		C17	TXD_FPGAFLASH	

Parts Number: 20CNW001550001				
A: TPB-03850(CN12), B: TPB-03850(CN11), C: TPB-03852(CN2), D: TPB-03852(CN1),				
A/B connector			C/D connector	
No.	Signal	CLR	No.	Signal
A18	SELDSP1		C18	SELDSP1
A19	SELDSP2		C19	SELDSP2
A20	GNDS		C20	GNDS
A21	SHDSP		C21	SHDSP
A22	DSPRESET		C22	DSPRESET
A23	TMAD		C23	TM
B3	GNDS		D3	GNDS
B4	GNDS		D4	GNDS
B5	SEN1_O		D5	SEN1
B6	SEN2_O		D7	SEN2
B7	SEN3_O		D6	SEN3
B8	SEN4_O		D9	SEN4
B9	SEN5_O		D8	SEN5
B10	SEN6_O		D11	SEN6
B11	SEN7_O		D10	SEN7
B12	SEN8_O		D12	SEN8
B1	VCC5PASS	WT	B14	TEST_SENS
D1	VCC5	WT	D14	TEST_PASS
A25	SHIELD	GN		SHIELD

CNW-15501-01




Figure 390
Boards - CNW-15501-01

Parts Number: 20CNW001550101					
A: TPB-03851 (CN4)			B: Inverter A (VF-nC3M)		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
A1	VCC24IN	WT	A20	TEST_INVA	
A10	ACONV_CM		B1	CC_A	
A11	ACONV_FWD		B2	F_A	
A12	ACONV_REVE		B3	R_A	
A13	ACONV_X1		B4	S1_A	
14	ACONV_X2		B5	S2_A	

CNW-15502-01




Figure 391
Boards - CNW-15502-01

Parts Number: 20CNW001550201				
A: TPB-03851 (CN5)			B: Inverter B (VF-nC3M)	
A connector			B connector	
No.	Signal	CLR	No.	Signal
A1	VCC24IN	WT	A20	TEST_INVA
A10	BCONV_CM		B1	CC_B
A11	BCONV_FWD		B2	F_B
A12	BCONV_REVE		B3	R_B
A13	BCONV_X1		B4	S1_B
14	BCONV_X2		B5	S2_B

CNW-15503-01




Figure 392
Boards - CNW-15503-01

Parts Number: 20CNW001550301					
A: EMX-BYT2 COM4			B: CNW-15452		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
A1	NRXD	BR	B1	U1_TXD	
A4	NTXD	RD	B2	U1_RXD	
A6	GND	OR	B3	GNDS	

CNW-15505-00




Figure 393
Boards - CNW-15505-00

Parts Number: 20CNW001550500					
A: CNW-15496			B: Power switch		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
A1	POWSW	RD	B1	NO	
A2	GNDS	BK	B2	C	

CNW-15508-00




Figure 394
Boards - CNW-15508-00

Parts Number: 20CNW001550800					
A: TPB-03850			B: CNW-15491		
A connector			B connector		
No.	Signal	CLR	No.	Signal	
A1	P0	RD	B1	P0	
A2	YA	BL	B2	YA	
A3	CM2	WT	B3	CM	
A4	YB	GN	B4	YB	
A5	CM3	BK	B5	CM	
	SHIELD	GN	B6	SHIELD	

Recommended parts



Parts list

Name	Parts Number
Mail board (TPB-3850)	41025990100100
Transport board (TPB-3851)	41025990300100
Relay board (TPB-3853)	41025990300300
Power distribution board (TPB-3854)	41025990300400
Switch board (TPB-3948)	41025990300100
B scale A/D board (TPB-3273)	41025990500100
C scale A/D board (TPB-3273)	41025990500200
A/D control board (TPB-3852)	41025990300200
Gate board receiver (TPB-3283)	41022390800400
Gate board emitter (TPB-3282)	41022390800300
Passage sensor board (small) receiver (TPB-3864)	41025990300600
Passage sensor board (large) receiver (TPB-3866)	41025990300800
Passage sensor board (small) emitter (TPB-3863)	41025990300500
Passage sensor board (large) emitter (TPB-3865)	41025990300700
Touch panel relay board (TSC-54/RU-F)	10MXASYTSC54RF
Power supply board (SWF150P-24)	10XPWU0SWF150
LCD	10AXLCD0N15XG2
Touch panel	10EXETC04344S1
Stacklite board (TPB-3926)	41025990301100
Mother board (EMX-BYT2-A1-01R)	41025990800100
SSD (OsAPL installed)	41025990800200
Main memory (4Gb)	10MXSUBMEM4G06
Built-in battery	10BX2ND05HRTSK
Breaker	10SFBRKBW32P20
Noise filter	10FXNFLTAH2683
electromagnetic switch	10SFRLLOSC050G
Circuit protector	10S0BRK0BA2125
Emergency (E) stop SW	10SFPSW0AM2VDF
Blinker for gate (shading plate)	20TPB100362301
Blinker for pass sensor (shading plate)	41025990300900

Name	Parts Number
Drive belt (common to A and B conveyors)	30J35306PK0950
Conveyance belt (for A conveyor)	41025901500100
Conveyance belt (for B conveyor)	41025901500200
Drive roller	41025907600100
Driven roller	41025907600200
Bearing unit	41025960004100
Adjuster	41025960004000
Main motor ASSY	41025960004400
Inverter	10KXACC04PYA30
Loadcell (B scale)	41025960004200
Loadcell (C scale)	41025960004300

CHAPTER 6 LOG, FIRMWARE, DATA

Log acquisition

Common operation

Use USB memory for log acquisition:



Figure 395
Log acquisition - Measurement screen

1. With the **Measurement** screen displayed, Select **Setting** to display the **Maintenance** screen for general users.

2. Tap [Maintenance].



Figure 396
Log acquisition - Maintenance

NOTE >

The login user is different for **Get lot** and **Maintenance** record log acquisition. Both will be presented here.

3. With the Login screen displayed, tap [Maintenance] to check the box next to **Maintenance**.



Figure 397
Log acquisition - Login

4. Tap in the text field next to Password to display the Numeric keypad window.
5. Enter the pass code **8715** into the Numeric keypad window. Then tap **[Enter]**.




Figure 398

Log acquisition - Numeric keypad window

6. With the Login window displayed, tap **[Login]**.



Figure 399

Log acquisition - Login

7. Locate the USB ports on the right side of the display. Turn the cover clockwise to access the 4 USB ports.

8. Insert the USB memory into the open USB port.



Figure 400
Log acquisition - USB ports

9. When using a secure USB, a Password authentication window will display, requesting a password. Enter the password by tapping in the text box and using the soft keyboard that will display. Tap **[Open drive]** to make the USB drive available.



Figure 401
Log acquisition - USB ports

Log acquisition operation

The Cubiscan 200 SQ maintains a log of various functions. These logs may be accessed from the **Log** menu in the side panel. This data will display in the corresponding screen and may be saved to a USB device.

Complete the following steps to display and save data to a USB drive:

- Log acquisition can be performed from the Log menu. Tap **[+]** next to **Log** to reveal the log acquisition selections. The following selections are available:
 - Measurement
 - Mileage
 - Error recording
 - Control services
 - Display app.
 - Maintenance log
- With **Maintenance** screen displayed, choose the data to acquire by tapping the selection beneath the **Log** menu in the side panel.



Figure 402

Log acquisition - Measurement screen

- Logs may be acquired for only the select relevant dates or for all dates. Tap the **∇** to the right of the **Date** to select a date. All data for that date

will display a list of data for that date. Select the data you wish to retrieve, then tap [Save] to get the log data.



Figure 403
Log acquisition - Saving log data

- To acquire and save all data, tap [Save All].




Figure 404

Log acquisition - Retrieve all data logs

- In either case, the Destination drive selection window will appear. Tap ▾ to the right of the drive drop down, then select the drive of the USB memory.

NOTE ➤

When using a normal USB memory, select D drive. For secure USB memory, select E drive.

- Once the desired drive is chosen, tap [OK].



Figure 405

Log acquisition - Drive selection

The save location for files can be found in the sub-folder designated by the number of the machine from where the data was retrieved within the folder labeled **LOGOUT**. For example, **D://LOGOUT/01** would be the folder where the data file would be located for machine 01.

The log file name will differ according to the log file saved. The following table will illustrate the general file name formats for the various log acquisition data:

Log	File name format
Measurement	mresYYYYMMDD.csv
Error recording	error.log
Control services	SQMesSrvMMDD.log
Display app.	SQDispMMDD.log
Maintenance log	SetupLog.txt

NOTE 

YYYYMMDD and MMDD in the file names represent the date of the log. YYYY = the four-digit year, MM = the two-digit month, and DD = the two-digit day.

Device setting data



Common operation

Use USB memory for log acquisition:

With the **Measurement** screen displayed, Tap **Setting** to display the **Maintenance** screen for general users.



Figure 406
Device setting data - Measurement screen

7. Tap [Maintenance].



Figure 407
Device setting data - Maintenance

8. The login user is different for **Get lot** and **Maintenance record log acquisition**.
9. With the Login window displayed, tap **[Maintenance]**.
10. Tap in the text box next to **Password**.



Figure 408
Device setting data - Login

11. The Numeric keypad window will appear.
12. Enter the pass code **8715**, then tap **[Enter]**.
13. Tap **[Login]** after returning to Login window.




Figure 409
Device setting data - Numeric keypad window

14. Locate the USB ports on the right side of the display. Turn the cover clockwise to access the 4 USB ports.
15. Insert the USB memory into the open USB port.



Figure 410
Device setting data - USB ports

16. When using a secure USB, a Password authentication window will display, requesting a password. Enter the password by tapping in the text box and using the soft keyboard that will display. Tap [Open drive] to make the USB drive available.

Device setting data backup procedure

1. With the maintenance user **Maintenance** screen displayed. Tap **[+]** next to **Device settings**, then select **Recovery**. This will display the setting history.



Figure 411
Device setting data - Maintenance screen

- To save items in the history, select the items and tap [Export].



Figure 412
Device setting data - Setting history

- the Destination drive selection window will appear. Tap ▾ to the right of the drive drop down, then select the drive of the USB memory.

NOTE ➤

When using a normal USB memory, select D drive. For secure USB memory, select E drive.



Figure 413
Device setting data - Destination drive select

- After choosing a drive, tap [OK]. A processing message will appear briefly. The log is fully saved when the processing message disappears.

NOTE ➤

YYYYMMDD and MMDD in the file names represent the date of the log. YYYY = the four-digit year, MM = the two-digit month, and DD = the two-digit day.

Adjustment setting data backup procedure

1. With the maintenance user **Maintenance** screen displayed. Tap **[+]** next to **Adjustment settings**, then select **Recovery**. This will display the setting history.



Figure 414
Adjustment setting - Maintenance screen

- To save items in the history, select the individual items and tap [Export].



Figure 415
Adjustment setting - Export

- The **Destination drive selection** window will appear. Tap ▾ to the right of the drive drop down, then select the drive of the USB memory.

NOTE >

When using a normal USB memory, select D drive. For secure USB memory, select E drive.



Figure 416
Adjustment setting- Destination drive select

- After choosing a drive, tap [OK]. A processing message will appear briefly. The log is fully saved when the processing message disappears.



YYYYMMDD and MMDD in the file names represent the date of the log. YYYY = the four-digit year, MM = the two-digit month, and DD = the two-digit day.

Device setting data restore procedure

1. With the maintenance user **Maintenance** screen displayed. Tap [+] next to **Device settings**, then select **Recovery**. This will display the setting history.



Figure 417
Device setting data - Maintenance screen

- To import files in the history, tap **[Import]**.



Figure 418
Device setting data - Import

- The file explore will display. Select D drive (E drive for secure USB). Log files can be found in the **sq_ini** folder. Choose the folder with the corresponding machine number. Tap **▽** to the right of the drive drop down, then select the drive of the USB memory.

4. Select the file you want to import and tap **[Open]**.




Figure 419
Device setting data - File explorer

5. Tap **[OK]** after the Process completed message appears to close the window.

- Confirm that the file has been added to the setting change history item. You can rewrite the settings using the recovery option.



Figure 420
Device setting data - Added Files

- Select the added file and tap **[Recovery]**.
- Tap **[OK]** after the Processing completed window is displayed to close the window.



Figure 421
Device setting data - Recovery window

- After returning to the System restore screen, tap **[Exit]** to log out.

10. The Finish setting confirmation screen will appear. Ensure the check box next to Logout is checked, then tap [OK].




Figure 422
Device setting data - Logout

11. Exit maintenance mode and display the Update settings window.
12. Enter **teraoka** in the text box next to Signature by tapping in the text box and using the on-screen keyboard. Then tap [Update].



Figure 423
Device setting data - Update settings

13. Once the update is complete, the terminal will return to the measurement screen.

Adjustment setting data restore procedure

1. With the maintenance user Maintenance screen displayed. Tap [+] next to Adjustment settings, then select **Recovery**. This will display the setting history.



Figure 424
Adjustment setting data - Maintenance screen

- To import files in the history, tap **[Import]**.



Figure 425
Adjustment setting data - Import

- The file explore will display. Select D drive (E drive for secure USB). Log files can be found in the **sq_ini** folder. Choose the folder with the corresponding machine number. Tap ▾ to the right of the drive drop down, then select the drive of the USB memory.

4. Select the file you want to import and tap **[Open]**.




Figure 426
Adjustment setting data - File explorer

5. Tap **[OK]** after the Process completed message appears to close the window.

- Confirm that the file has been added to the setting change history item. You can rewrite the settings by performing the restoration work.



Figure 427
Adjustment setting data - Setting history

- Select the added file and tap [Restore].
- Tap [OK] after the Processing completed window is displayed to close the window.



Figure 428
Adjustment setting data - Recovery window

- After returning to the System restore screen, tap [Exit] to log out.

10. The Finish setting confirmation screen will appear. Ensure the check box next to **Logout** is checked, then tap [OK].
11. This will exit maintenance mode and display the **Update settings** window.
12. Enter **teraoka** in the text box next to **Signature** by tapping in the text box and using the on-screen keyboard. Then tap [Update].



Figure 429
Adjustment setting data - Update settings

13. Once the update is complete, the terminal will return to the **Measurement** screen.

Application installation



1. Unzip the program file **SQDPVX_X_X.zip** file to create an **Update** folder.
2. Copy the entire **Update** folder directly under the USB memory. The file name will have the format **SQDPVXXX.zip**, where **XXX** represents the firmware.
3. Start the Cubiscan 200 SQ.

- From the **Measurement** screen, stop the conveyor by tapping **[STOP]**.



Figure 430
Application installation - Measurement screen

- Locate the USB ports on the right side of the display. Turn the cover clockwise to access the 4 USB ports.
- Insert the USB memory into the open USB port.



Figure 431
Application installation - USB ports

7. When using a secure USB, a Password authentication window will display, requesting a password. Enter the password by tapping in the text box and using the soft keyboard that will display. Tap [**Open drive**] to make the USB drive available.
8. A message window will display in the upper right of the screen, indicating **Update program has arrived**. Tap [**Check for updates content**].



Figure 432
Application installation - Update message

9. The Update content window will then display. Tap [**Update now**].
10. The program installation will begin.




Figure 433
Application installation - Program installation

11. The Cubiscan 200 SQ will restart after installation completes.
12. Remove the USB memory before program starts. The installation is complete when the **Measurement** screen displays.

Firmware installation

Details of file:

Firmware	File (.txt)	File (.bin)
SH (Measurement control)	SH_UPDATE.txt	SH_VXXX.bin
N10 (Communication control)	SQ_UPDATE_AP.txt	SQ_VXXX.bin
The XXX in the file name designates the firmware version.		

1. Copy the firmware files (**txt** and **bin** files) to the USB memory. Where the save location is not specified, the file will be copied to a folder **FWUPDATE** in the USB memory.
2. With the **Measurement** screen displayed, select **Maintenance** to display the **Maintenance** screen for general users.



Figure 434
Firmware Installation - Measurement screen

3. Tap **[Maintenance]** to display **Login** window.



Figure 435

Firmware Installation - - Login window

4. With the **Login** window displayed, tap **[Maintenance]** to check box, then tap in the text field next to Password to display the Numeric keypad window.
5. Enter the pass code **8715** into the Numeric keypad window. Then tap **[Enter]**.




Figure 436

Firmware Installation - Numeric keypad window

6. With the login window displayed, tap [Login].



Figure 437
Firmware Installation - Login

7. Locate the USB ports on the right side of the display. Turn the cover clockwise to access the 4 USB ports.
8. Insert the USB memory into the open USB port.



Figure 438
Firmware Installation - USB ports

9. When using a secure USB, a Password authentication window will display, requesting a password. Enter the password by tapping in the text box and using the soft keyboard that will display. Tap [**Open drive**] to make the USB drive available.
10. With the **Maintenance** screen for maintenance users displayed, tap [**+**] next to **Adjustment** to reveal selections.

11. Select **Firmware** to display the **Firmware** screen.




Figure 439
Firmware Installation - Firmware screen

12. From the **Firmware** screen, tap **[Import]** to display the File selection window.
13. Select the drive that contains the file you wish to import. Typically, the file will be found on the D drive in the folder labeled **FWUPDATE** (drive E for secure USB).
14. Tap ▾ to the right of the file type item. To import SH firmware, select **SH_UPDATE.txt**. To import N10 firmware, select **SQ_UPDATE_AP.txt**.

15. Select each file, then tap [Open].




Figure 440
Firmware Installation - File selection window

16. The imported file will be displayed in the list within the update window.

- The firmware files are only stored on the SSD, not on the board. To install the firmware on the board, select the file to be installed from the list of firmware files, then tap **[Import]**.




Figure 441
Firmware Installation - Firmware file selection

18. The Firmware update window will display. Tap in the text box under **Signature** using the soft keyboard, then tap **[Write]**.




Figure 442
Firmware Installation - Firmware update window

19. A progress bar will appear at the bottom of the Firmware update window, indicating that install had begun.
20. When the install is complete, the Update success window will display. Tap **[OK]** to complete installation.

CHAPTER 7 ADJUSTMENT

Forced startup method

This procedure is only for repair work, not for customer operation. When the power is turned on, the Cubiscan 200 SQ will wait for 8 minutes to start up to prevent initial drift. You can cancel the startup waiting state by using the forced startup method.

1. Turn on the main power switch of the 200 SQ.
2. At start, the warming up notification will display.
3. With the Warming up notification displayed, swipe from the bottom left corner of the notification window to the top right.



Figure 443
Forced startup method - Warm up notification

4. When the Warming up notification window closes, the Cubiscan 200 SQ is ready for use.



Figure 444
Forced startup method - Ready screen

Weight adjustment

There are two steps to adjust the weight: 2-point and 3-point span adjustment. It is recommended to adjust the weight with a 3-point span for accuracy.

2-Point span adjustment procedure

1. With the **Measurement** screen displayed, tap [**Setting**].

- From the **Maintenance** screen for general users, tap **[Maintenance]**.



Figure 445

2-Point span adjustment - Maintenance screen

- From the Login window, tap the text box next to **Password** to display the Numeric keypad window.



Figure 446

2-Point span adjustment - Login

4. Enter the passcode **8715**, then tap **[Enter]**.




Figure 447
2-Point span adjustment - Passcode

5. At the Login window tap **[Login]**.

- At the maintenance user **Maintenance** screen, select **Adjustment** from the left side panel and tap **[Span]**.



Figure 448

2-Point span adjustment - Adjustment

- From the **Span adjustment** screen, check the box for 2-point adjustment method by tapping **[2 points]**.
- Enter the value of the weight used. Then, tap ∇ next to the unit to select either **kg** or **lbs**.
- Ensure that the weigher is free of all objects then tap to check the box "I have confirmed that nothing is on the device".
- Tap **[Start span adjustment]**.

11. The Processing message will appear. After the system has done processing, you will be prompted to put a 25 kg weight on Scale B.



Figure 449

2-Point span adjustment - Span adjustment prompt

12. After placing the 25kg weight, tap [OK]. Again, the Processing message will appear.
13. When the system is done process a prompt swill appear indicating, "Completed the adjustment". Tap [Yes, I understand] to confirm completion.



Figure 450

2-Point span adjustment - Adjustment completed

14. Once completion of adjustment is confirmed, the **Span adjustment** screen will appear. Tap **[Exit]**.



Figure 451
2-Point span adjustment - Exit

15. The Finish setting message window will display. Check the box next to **[Logout]** by tapping, then tap **[OK]**.




Figure 452
2-Point span adjustment - Logout

16. The Update settings window will display. Tap in the text box next to **Signature** and enter the password **teraoka** with the soft keyboard.

17. Tap **[Update]** to save the span data. If you do not press **[Update]**, the span data will be lost.



The screenshot shows a dialog box titled "Update settings". It contains the following fields and buttons:

- Date:** 2020/01/15 12:23:42
- Authority:** Maintenance
- Note:** (empty)
- Signature:** teraoka
- Display-Device setting:** (empty)
- Buttons:** Update (blue), Destruction (red), Cancel (grey)

Red boxes highlight the "Update" button and the "Signature" field.

Figure 453
2-Point span adjustment - Update settings

18. The **Measurement** screen will display when the adjustment is complete.

3-Point span adjustment procedure

1. With the **Measurement** screen displayed, tap **[Setting]**.

- From the **Maintenance** screen for general users, tap **[Maintenance]**.



Figure 454

3-Point span adjustment - Maintenance screen

- From the Login window, tap the text box next to **Password** to display the Numeric keypad window.
- Enter the passcode **8715**, then tap **[Enter]**.



Figure 455

3-Point span adjustment - Login

- At the Login window tap **[Login]**.

- At the maintenance user **Maintenance** screen, select **Adjustment** from the left side panel and tap **[Span]**.



Figure 456
3-Point span adjustment - Adjustment

- From the **Span adjustment** screen, check the box for 3-point adjustment method by tapping **[3 points]**.
- Enter the value of the first weight used. Then, tap ∇ next to the unit to select either **kg** or **lbs**.
- Enter the value of the second weight used. Then, tap ∇ next to the unit to select either **kg** or **lbs**.
- Ensure that the weigher is free of all objects then tap to check the box **"I have confirmed that nothing is on the device"**.
- Tap **[Start span adjustment]**.

12. The Processing message will appear. After the system has done processing, you will be prompted to put a 25 kg weight on Scale B.




Figure 457

3-Point span adjustment - Span adjustment prompt

13. After placing the 25kg weight, tap **[OK]**. Again, the Processing message will appear.
14. After the system has done processing, you will be prompted to place the next weight on Scale B.
15. After placing the 50kg weight, tap **[OK]**. Again, the Processing message will appear.
16. When the system is done process a prompt swill appear indicating, **"Completed the adjustment"**. Tap **[Yes, I understand]** to confirm completion.




Figure 458

3-Point span adjustment - Adjustment completed

17. Once completion of adjustment is confirmed, the **Span adjustment** screen will appear. Tap **[Exit]**.



Figure 459

3-Point span adjustment - Exit

18. The Finish setting message window will display. Check the box next to **Logout** by tapping, then tap **[OK]**.




Figure 460

3-Point span adjustment - Logout

19. The Update settings window will display. Tap in the text box next to **Signature** and enter the password **teraoka** with the soft keyboard.

20. Tap **[Update]** to save the span data. If you do not press **[Update]**, the span data will be lost.

The screenshot shows a dialog box titled "Update settings". It contains the following fields and buttons:

- Date:** 2020/01/15 12:23:42
- Authority:** Maintenance
- Note:** (empty)
- Signature:** teraoka
- Display-Device setting:** (empty)
- Buttons:** Update (blue), Destruction (red), Cancel (grey)

Red boxes highlight the "Update" button, the "Signature" field, and the "Authority" field.

Figure 461
3-Point span adjustment - Update settings

21. The **Measurement** screen will display when the adjustment is complete.

Conveyor height/horizontal adjustment

Adjustment leg position




Figure 462
Adjustment leg position - Full conveyor view

Leg height adjustment procedure

1. Loosen the **nut (B)** by turning counter clockwise to unlock the leg as shown in figure.




Figure 463

Leg height adjustment - Loosening nut (B)

2. Adjust leg height, by turning **nut (C)** clockwise to lower leg or counter-clockwise to raise leg.




Figure 464

Leg height adjustment - Adjusting nut (C)

3. Repeat for each leg.

Horizontal confirmation adjustment method

1. Use a level to ensure the conveyor is properly leveled at each point **A** to **D** as shown in the figure.




Figure 465
Horizontal confirmation - Leveling conveyor

2. If the conveyor is not level at any point, adjust the corresponding legs as needed to make that point level. The following table will help identify which legs to adjust to level each point:

Point of leveling	Legs to adjust
A	A and C
B	B and D
C	C and D
D	A and B

3. Once the four points **A** to **D** are level, ensure the conveyor is at the desired height.

4. Make any needed adjustment to the height (see "Leg height adjustment procedure" on page 353). Repeat leveling procedure, checking each of the four points of leveling.
5. After confirming conveyor is level and at the desired height, tighten leg nut (B) by turning clockwise to secure the leg at the desired height.




Figure 466
Horizontal confirmation- Securing nut (B)

6. Repeat for each leg.

Transport surface height adjustment

1. To adjust the height of the transport surface to match the height of a front and rear conveyor, use the procedure discussed previously to adjust height (see "Leg height adjustment procedure" on page 353).

2. After the 200 SQ is at a height that is aligned to front and rear conveyors, ensure that transport surface is level (see "Horizontal confirmation adjustment method" on page 354).




Figure 467
Transport surface height - Front and rear conveyor

NOTE >

Do not raise the CS 200 SQ transport surface above the front conveyor. Collisions with conveyor may occur. Collisions from incoming objects along the conveyor may cause deviations in weighing, leading to errors in measurement.

Conveyor belt slipping adjustment

Adjuster position for belt adjustment




Figure 468
Belt adjustment - Adjuster position

Reference position

Check the position of the each adjuster and mark on the scale as show in the corresponding figure of each reference position:



Figure 469
Reference position - B1: B conveyor front




Figure 470
Reference position - B2: B conveyor back




Figure 471
Reference position - A1: A conveyor front




Figure 472
Reference position - A2: A conveyor back

The marked position will be the reference point to be adjusted when replacing and installing the belt and rollers. Since there are individual differences in equipment, there is no standard for the scale.

Belt slipping adjustment method

Belt slippage overview

If the tension on the belts for either conveyors differs, the belt will misalign, causing slippage. The belt will shift in the direction of stronger belt tension.




Figure 473
Belt slippage overview - Good tension




Figure 474
Belt slippage overview - Front side stretching




Figure 475
Belt slippage overview - Back side stretching

Conveyor A belt adjustment

1. Loosen the 4 hexagonal screws securing the adjust on the side where the belt does not bend (the side where the belt separates).




Figure 476
Conveyor A belt adjustment - A1: A conveyor front




Figure 477

Conveyor A belt adjustment - A2: A conveyor back

2. Loosen **hexagonal nut (A)** affixed to the frame, then turn **bolt (B)** counter-clockwise to increase tension of belt. When turning **bolt (B)**, keep within the range of one rotation (approx. 1.25 mm).




Figure 478

Conveyor A belt adjustment - Front adjustment




Figure 479
Conveyor A belt adjustment - Back adjustment

Conveyor B belt adjustment

1. Loosen the 4 hexagonal screws securing the adjust on the side where the belt does not bend (the side where the belt separates).




Figure 480
Conveyor B belt adjustment - B1: B conveyor front




Figure 481
Conveyor B belt adjustment - B2: B conveyor rear

2. Loosen **hexagonal nut (A)** affixed to the frame, then turn **bolt (B)** counter-clockwise to increase tension of belt. When turning **bolt (B)**, keep within the range of one rotation (approx. 1.25 mm).




Figure 482
Conveyor B belt adjustment - Front adjustment




Figure 483
Conveyor B belt adjustment - Rear adjustment