

QBIT-DB CUBISCAN 225-HS SETUP

QUICK REFERENCE GUIDE

This quick reference guide provides instructions for setting up Qbit-DB to connect to a Cubiscan. For more detailed instructions, or if you are using an operating system older than Windows 7, see the *Cubiscan Qbit-DB User Guide*.

1 ➤ Make sure that Qbit-DB is installed on your computer.

2 ➤ Connect your computer to the Cubiscan. See your Ethernet Setup quick reference guide or Cubiscan manual for more information on connecting a Cubiscan to a computer.

3 ➤ Open Qbit-DB and go to **Tools > Options > Cubiscan**.

4 ➤ Select the **Cubiscan 225** as your Cubiscan model.

5 ➤ Select **Network port**, and enter the default IP address of **10.1.100.100** and the default IP Port setting of **1050**. Click **OK**.

6 ➤ When you are finished, click OK.

Your Cubiscan should now be connected to Qbit-DB.

The screenshot shows the 'Options' dialog box with the 'Cubiscan' tab selected. The 'Unit of measure options' section on the left includes 'Dimension units' (Inches selected), 'Weight units' (Pounds selected), 'Volume units' (Cubic inches selected), and 'Dimensional weight units' (Domestic selected). The 'Cubiscan options' section on the right includes 'Communication ports' (Network port selected), 'Cubiscan model' (Cubiscan 225 selected), and 'Site ID'. The 'IP address' field is set to 10.1.100.100 and the 'IP port' field is set to 1050. The 'OK' button is highlighted with a green checkmark.

