

CUBISCAN 25 SETUP

QUICK REFERENCE GUIDE

This quick reference guide provides instructions for assembling and setting up the Cubiscan 25. For more detailed instructions on setting up the Cubiscan 25, see the *Cubiscan 25 Operations and Technical Manual*.



UNPACKING >

- 1 > Remove the Ethernet and power cables, the TRENDnet Ethernet adaptor box, the calibration cube, and the glass platforms. The platforms are in a protected cardboard box beneath the measuring gate.
- 2 > Remove all necessary cardboard supports and lift the Cubiscan 25 out of the crate (this will require two people). Be careful while moving the Cubiscan 25 as the gate is free moving.
- 3 > When the Cubiscan 25 has been placed in your preferred location, remove the foam shipping supports.

ASSEMBLY

- 1 > Carefully place a glass platform onto the platform frame. Store the extra platform in a safe location.
- 2 > Loosen the four scale thumb screws (2 screws located at each end of the Cubiscan 25) until the weighing platform is able to move freely. These screws are indicated in the images on the right.
- 3 > Connect the AC power cord to the power connection located on the right side of the controller box.

